

# ENTRAPASS™

GLOBAL EDITION



High Performance Access Control and Integrated Security System

## Reference Manual

# **KANTECH**

DN1316-0612/ Version 3.18

© 2006 Tyco Safety Products, Canada, Ltd. All rights reserved.  
Specifications may be modified without notice.

## SENSORMATIC ELECTRONICS CORPORATION KANTECH – TYCO SAFETY PRODUCTS END-USER LICENSE AGREEMENT

FOR KANTECH Software Provided With or Without Products or Components

### IMPORTANT - READ CAREFULLY

**KANTECH Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:**

- This End-User License Agreement (“EULA”) is a legal agreement between You (the company, individual or entity who acquired the Software and any related Hardware) and Sensormatic Electronics Corporation (“KANTECH”), the manufacturer of the integrated security systems and the developer of the software and any related products or components (“HARDWARE”) which You acquired.
- If the KANTECH software product (“SOFTWARE PRODUCT” or “SOFTWARE”) is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and “online” or electronic documentation.
- Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement.
- By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, KANTECH is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

### SOFTWARE PRODUCT LICENSE

**The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.**

#### 1 GRANT OF LICENSE - This EULA grants You the following rights:

- a Software Installation and Use - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.
- b Storage/Network Use - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device (“Device”). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.
- c Backup Copy - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.

#### 2 DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

- a Limitations on Reverse Engineering, Decompilation and Disassembly - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of KANTECH. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.

- b **Separation of Components** - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.
- c **Single INTEGRATED PRODUCT** - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.
- d **Rental** - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.
- e **Software Product Transfer** - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies, You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT
- f **Termination** - Without prejudice to any other rights, KANTECH may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.
- g **Trademarks** - This EULA does not grant You any rights in connection with any trademarks or service marks of KANTECH or its suppliers.

### 3 COPYRIGHT

All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by KANTECH or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content, which may be accessed through use of the SOFTWARE PRODUCT, are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by KANTECH and its suppliers.

### 4 EXPORT RESTRICTIONS

You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to US export restrictions.

### 5 CHOICE OF LAW

This Software License Agreement is governed by the laws of the State of New York.

### 6 LIMITED WARRANTY

- a **NO WARRANTY**  
KANTECH PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. KANTECH DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.
- b **CHANGES IN OPERATING ENVIRONMENT**  
KANTECH shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-KANTECH SOFTWARE or HARDWARE PRODUCTS.
- c **LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK**  
IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, KANTECH'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE US DOLLARS (USD\$5.00). BECAUSE SOME JURIS-



- DICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
- d     DISCLAIMER OF WARRANTIES  
THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF KANTECH. KANTECH MAKES NO OTHER WARRANTIES. KANTECH NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.
- e     EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY  
UNDER NO CIRCUMSTANCES SHALL KANTECH BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWN TIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

**WARNING: KANTECH recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.**



# Table of Contents

**Chapter 1 •Introduction ..... 1**

Entrapass Main Features .....2

Entrapass Manual and Help .....4

    Using the Reference Manual ..... 4

    Getting Help ..... 4

    Technical Support ..... 4

System Architecture .....5

**Chapter 2 •Software Installation..... 7**

System Requirements .....8

    Video Applications ..... 8

    Workstation and Gateway Applications with NCC ..... 8

    NCC8000 or DOS Application ONLY ..... 8

    Additional Requirements ..... 9

Installation Kit .....10

Installation Steps .....11

    To Install Entrapass Software .....11

    To Add Optional Components/Features .....11

System Installation .....12

System Registration .....22

    To Register the System .....22

Additional System Components .....24

System Components Edition .....26

    To Assign a Descriptive Name to an Application .....26

Communication with the Entrapass Server .....27

    To Establish Communication with the Server .....27

Internal Global Gateway Installation (NCC8000) .....28

    To Edit the Config.sys File .....28

External Global Gateway Installation (NCC8000) .....29

External Global Gateway Configuration (NCC8000) .....30

System Update .....31

    Before Updating Your Software .....31

    To Update your Software .....31

Removing the Entrapass Software .....35

**Chapter 3 •Getting Started ..... 37**

Session Start and End .....38

    To Start the Primary Server .....38

    To Start the Gateway Program .....40

    To Start the Entrapass Workstation .....41

    To Access Information on the Workstation Connection Status .....44

    To Modify Your Work Area Properties .....44

    To Retrieve Hidden Windows on the Desktop .....45

Express Setup .....46

System Stand-Alone Utilities .....47

Entrapass Workstation Toolbar .....48

Basic Functions .....50

To Find Components .....	50
To Find a Card .....	52
To Use an Extended Selection Box .....	53
To Select Components .....	53
To Select a Specific Folder .....	55
To Select a Specific Site or Gateway .....	56
To Print .....	56
To View Components Links .....	57
<b>Chapter 4 •System Devices .....</b>	<b>59</b>
<b>EntraPass Applications Configuration .....</b>	<b>60</b>
To Configure an EntraPass Application .....	61
Defining General Parameters .....	61
Defining Security Parameters .....	62
Defining Filters .....	63
Defining Message Controls .....	65
Defining Alarm Controls .....	67
Defining Network Alarms .....	68
Defining e-Mail Report Options .....	69
Configuring a Gateway Application .....	70
Configuring General Parameters for a Gateway .....	70
Configuring an Oracle/MS-SQL HR Interface .....	70
Configuring an Oracle/MS-SQL HR Interface .....	71
To Create Server Databases Manually .....	73
Creating the Operator Manually in the MS-SQL/Oracle Server .....	73
Creating the KANTECH Operator for an MS-SQL Server .....	73
Creating the KANTECH Operator for an Oracle Server .....	74
To Configure the Mirror Database and Redundant Server .....	74
To Configure the SmartLink .....	77
Configuring SmartLink Connection Options .....	78
To Configure the EntraPass Video Vault Application .....	80
<b>EntraPass Gateways Configuration .....</b>	<b>85</b>
To Configure a Corporate Gateway .....	86
To Configure a NCC 8000 Gateway .....	89
To Configure a Global Gateway .....	92
To Configure a KT-NCC Gateway .....	94
<b>Sites/Loops Configuration .....</b>	<b>101</b>
To Set Up Communication Timing .....	102
To Configure a Direct RS-232 Connection Type .....	102
To Configure an Ethernet Kantech IP Link Connection Type (Corporate Gateway Only) .....	103
To Configure an Ethernet Polling Connection Type .....	106
To Configure a Dial-Up (RS-232) Modem Connection Type .....	107
<b>Controllers Configuration .....</b>	<b>110</b>
To Configure General Parameters for KT Controllers .....	110
To Configure a KT-100 Controller (Corporate Gateway, Global and KT-NCC Gateways) .....	112
To Configure a KT- 200 Controller .....	113
Defining KT-200 Expansion Devices .....	114
Defining KT-200 auxiliary devices .....	114
To Program KT-2252 Elevator Controllers .....	115
To Program REB-8 Elevator Controllers .....	117
Defining REB-8 Relays .....	118
To Configure a KT-300 Controller (Corporate, Global and KT-NCC Gateways ) .....	119
To Configure the KT-300 Combust module .....	120
To Define Controller Options for Corporate/Global Gateways .....	122
<b>Controller Event Buffer Overflow Message .....</b>	<b>125</b>
<b>Doors Configuration .....</b>	<b>126</b>

To Define General Parameters for a Door .....	126
To Define Door Keypad Options .....	127
To Define Door Contact Options .....	129
To Define REX (Request to Exit) Options .....	130
To Define Miscellaneous Options .....	131
To Define Elevator Doors .....	132
To Define a Door Under a Global/KT-NCC Gateway .....	133
To Configure Door Events (Corporate Gateway Only) .....	135
To Define Options for a KT-100 and KT-300 (Corporate Gateway Only) .....	136
To Configure External Alarm System Interfaces (Corporate Gateway Only) .....	137
<b>Relays Configuration .....</b>	<b>141</b>
To Define Relays .....	141
<b>Inputs Configuration .....</b>	<b>143</b>
To Define Inputs Under a Corporate Gateway .....	143
To Define Input Under a Global Gateway .....	144
To Define Relays and Inputs .....	145
To Define an Input for an Elevator Door .....	146
To Enable Remote Event Reporting (Corporate Gateway) .....	147
To Define an Input for a Group of Doors .....	147
<b>Output Devices Configuration .....</b>	<b>149</b>
To Define General Options for an Output .....	149
To Associate Events with Auxiliary Outputs .....	150
<b>Chapter 5 •Video Integration .....</b>	<b>151</b>
<b>Video Server Configuration .....</b>	<b>152</b>
To Define the Video Server Communication Settings .....	152
To Enhance the Security of Video Servers .....	154
To Define the EntraPass Video Vault .....	155
<b>Camera Definition .....</b>	<b>157</b>
To Define a Camera .....	157
To Define Presets and Patterns .....	158
To Define Events Recorded by a Camera .....	159
Selecting Camera Events and Schedules .....	159
To Associate a Camera with an Icon .....	160
<b>Video Views Definition .....</b>	<b>162</b>
To Define General Parameters for a Video View .....	162
<b>Video Views Creation and Modification .....</b>	<b>165</b>
To Modify a Video View .....	165
<b>Video Triggers .....</b>	<b>167</b>
To Define Video Triggers .....	167
<b>Recording Parameters .....</b>	<b>169</b>
To Set up Recording Parameters .....	169
To Set Up Stop Recording Parameters .....	170
<b>Video Event List .....</b>	<b>172</b>
To Use the Video Event List .....	172
To Find Video Events .....	172
To Play Video Segments .....	178
To Link Video Clips with Key Frames .....	180
To Export Video Files .....	181
To Protect a Video with a Password .....	182
<b>Video Playback .....</b>	<b>184</b>
To View a Video Playback .....	184
<b>Current Recording .....</b>	<b>186</b>

To View the Current Recordings .....	186
<b>Video Desktop .....</b>	<b>188</b>
To Display a Video View .....	188
<b>Exported Video Viewing .....</b>	<b>190</b>
<b>EntraPass Video Vault Browsing .....</b>	<b>191</b>
To View a Video Segments Archived in EntraPass Video Vault .....	191
<b>Chapter 6 •Definitions .....</b>	<b>193</b>
<b>Schedules Definition .....</b>	<b>194</b>
To Define a Schedule .....	195
Creating a 2-day Continuous Interval .....	196
<b>Alarm Systems Definition (Global/KT-NCC/NCC 8000) .....</b>	<b>197</b>
Alarm System Capabilities .....	198
Common Inputs .....	198
Perimeter and Volumetric Detection .....	198
Arming Procedure .....	199
Disarming Procedure .....	199
Disarm When "No Disarm" Schedule is Valid Procedure .....	200
Postponed Arming Procedure .....	200
Alarm Partition .....	201
<b>Areas Definition (Global/KT-NCC/NCC 8000 Gateways Only) .....</b>	<b>208</b>
<b>Guard Tour Definition (Global/KT-NCC/NCC 8000 Gateways Only) .....</b>	<b>211</b>
<b>Floors Definition .....</b>	<b>214</b>
<b>Event Relays Definition (Global/KT-NCC/NCC 8000 Gateways Only) .....</b>	<b>215</b>
To Define Event Relays .....	215
To Print Event Relay .....	216
<b>Graphics Definition .....</b>	<b>217</b>
To Define Components of a Graphic .....	217
To Design the Background for the Graphic Window .....	219
To Assign System Components to Graphic Icons .....	220
<b>Holidays Definition .....</b>	<b>222</b>
<b>Chapter 7 •Operations.....</b>	<b>223</b>
<b>The Operations Toolbar .....</b>	<b>224</b>
The Operation Dialogs Toolbar .....	224
<b>The Operations Contextual Menu .....</b>	<b>225</b>
<b>The Component Status Window .....</b>	<b>226</b>
<b>Manual Operations on the Gateway .....</b>	<b>228</b>
To Select a Gateway .....	229
To Perform a Soft Reset .....	229
To Perform a Hard Reset .....	229
To Reload Gateway Data .....	230
<b>Manual Operations on Sites .....</b>	<b>231</b>
To Perform Manual Operations on a Site .....	231
Communication Options Available from the Toolbar .....	232
Communication Status Messages Available in the List .....	232
<b>Manual Operations on Controllers .....</b>	<b>234</b>
To Select a Controller .....	235
To Perform a Controller Soft Reset .....	235
To Perform a Controller Hard Reset .....	235
To Manually Reload a Controller .....	236

To Manually Reload a Firmware Controller .....	236
To Manually Unlock a Reader Keypad .....	236
To Manually Reset a Reader Power .....	236
To Calculate the Number of Cards In and Cards Out .....	236
To Reset the Cards In and Cards Out Counters .....	236
<b>Manual Operations on Doors .....</b>	<b>238</b>
To Select a Door or a Door Group .....	239
To Lock a Door Manually .....	239
To Unlock a Door Manually .....	239
To Unlock a Door Temporarily .....	240
To Reset a Door Schedule .....	240
To Enable a Door Reader .....	240
To Disable a Door Reader .....	240
<b>Manual Operation on Elevator Doors .....</b>	<b>241</b>
To Select an Elevator Door .....	242
To Lock Floors from Elevator Doors .....	242
To Unlock Floors from Elevator Doors .....	242
To Temporarily Unlock Floors from Elevator Doors .....	243
To Reset an Elevator Door Schedule .....	243
To Enable an Elevator Floor .....	244
To Disable an Elevator Floor .....	244
<b>Manual Operations on Relays .....</b>	<b>245</b>
To Select Relays .....	245
To Manually Deactivate a Relay .....	246
To Manually Activate a Relay .....	246
To Activate a Relay Temporarily .....	246
To Reset a Relay Schedule .....	247
<b>Manual Operations on Inputs .....</b>	<b>248</b>
To Perform Manual Operations on Inputs .....	248
To Manually Return an Input to its Normal State .....	249
To Setup Continuous Input Supervision .....	249
To Stop Monitoring an Input .....	249
To Temporarily Stop Input Supervision (Shunt) .....	249
<b>Manual Operations on Alarm Systems .....</b>	<b>250</b>
To Perform Manual Operations on an Alarm System .....	250
To Manually Arm an Alarm System .....	251
To Manually Disarm an Alarm System .....	251
To Manually Modify the Alarm System Postponement Delay .....	251
<b>Guard Tour State .....</b>	<b>252</b>
To Start a Guard Tour .....	252
<b>Manual Operation on Areas .....</b>	<b>254</b>
<b>Chapter 8 •Users.....</b>	<b>257</b>
<b>Cards Definition .....</b>	<b>258</b>
To Issue a New Card .....	258
To Create New Cards Using the "Save as" Feature .....	259
To Issue Cards Using the Batch Load Feature .....	259
To View and Verify PINs .....	261
To View Cards Assigned the Same PIN .....	261
<b>Cards Handling .....</b>	<b>263</b>
To Edit a Card .....	263
To Find a Card .....	263
To Delete a Card .....	263
To Customize Card Information Fields .....	263

<b>Cardholder Access Levels Assignment</b>	<b>265</b>
To Assign an Access Level to a Cardholder	265
To Assign Additional Access Levels (Global/KT-NCC/NCC 8000 Only)	266
<b>Card Use Options Definition</b>	<b>267</b>
To Add Comments to a Card	268
To Limit Card Usage	269
To Assign Pictures and Signatures	269
Assigning a Picture from a File	270
Assigning a Picture Using a Video Camera	271
To Import a Signature from a File	272
To Add a Signature from a Signature Capture Device	273
To Work with Photos and Signatures	274
Extracting Part of an Image	274
Editing a Picture/Signature	277
To Print Badges	278
Selecting a Badge Printer	278
Previewing and Printing Badges	279
<b>Badges Designing</b>	<b>281</b>
To Create a Badge Template	281
Specifying Properties for a Badge Layout	282
Editing a Badge Layout	283
Modifying the Number of Sides	283
Modifying the Background Color	285
Adding Objects to a Badge Layout	287
Incorporating Card Information Fields	287
Aligning Objects in the Template Layout	289
Modifying Card Fields Properties	289
Modifying Picture Properties	291
Adding Static Text Objects	293
Adding Bar Codes	294
Setting Up Barcode Properties	296
Adding The Current Date	296
Adding An Image	299
Placing Other Design Objects	301
Placing a Rectangle	303
To Validate Card Access	303
<b>Cards Printing</b>	<b>305</b>
To Print Cards	305
<b>Last Transactions Display</b>	<b>309</b>
To View the Last Transaction	309
<b>Card Access Groups Definition</b>	<b>311</b>
<b>Access Levels Definition</b>	<b>313</b>
<b>Visitor Cards Definition</b>	<b>315</b>
To Create a Visitor Card when Creating a New Card	315
To Create a Visitor Card Using the Card Template	315
<b>Card Types Definition</b>	<b>316</b>
To Create a New Card Type	316
<b>Day Passes Definition</b>	<b>317</b>
To Create a Day Pass	317
To Create a New Day Pass Using the "Save as" Feature	318
<b>Batch Operations on Cards</b>	<b>319</b>
To Perform Operations on a Group of Cards	319
<b>CSV Files Import and Export</b>	<b>321</b>
To Use a Predefined Pattern	321



To Create a New Import/Export Pattern .....	322
To Export Cards .....	323
To Import Cards .....	326
To Correct Import/Export Errors .....	328
<b>Chapter 9 •Groups .....</b>	<b>331</b>
Controller Group Creation .....	332
Door Group Creation .....	333
Relay Group Creation .....	334
Input Group Creation .....	335
Access Level Groups Grouping .....	336
Floor Group Creation .....	337
<b>Chapter 10 •System Status .....</b>	<b>339</b>
Connection List .....	340
To View the System Connection List .....	340
Text Status .....	342
To Display a Component Status .....	342
Numerical Status .....	344
To View the Numeric Status of a Specific Gateway .....	344
Graphic Status .....	345
To View a Controller Status .....	345
Video Server Status .....	347
To View Video Server Status .....	347
To Enable/Disable Video Archiving .....	347
Database Status .....	348
To View Information About the Database .....	348
Server State .....	350
<b>Chapter 11 •System .....</b>	<b>351</b>
Operators Definition .....	352
To Create or Edit an Operator .....	352
Security Level Definition .....	356
To Create/Modify an Operator Security Level .....	356
To Define Login Options for an Operator .....	357
To Filter Applications Available to an Operator .....	359
To Filter Gateways and Sites Available to an Operator .....	360
To Filter Controllers Available to an Operator .....	361
To Filter Doors Available to an Operator .....	362
To Filter Access Levels .....	363
To Filter Card Types Available to an Operator .....	364
To Filter Reports Available to an Operator .....	365
To Filter Video Servers .....	366
To Limit Access to a Specific Camera .....	367
To Filter Video Views .....	369
To Hide Card Information .....	369
To Assign Video Custom Buttons .....	370
Event Parameters Definition .....	372
To Define Events Parameters .....	372
To Create and View Associations .....	374
Creating an Association .....	375
Viewing an Association .....	376

Deleting and Restoring Associations .....	376
To Print Event Parameters .....	378
<b>Instructions Definition .....</b>	<b>379</b>
To Define an Instruction .....	379
To Define a SmartLink Instruction .....	380
Inserting an e-Mail Command in a SmartLink Macro .....	381
Inserting a Pager Command in a SmartLink Macro .....	383
<b>Message Filters Definition .....</b>	<b>385</b>
To Define Event for a Message Filter .....	385
<b>Database Structure Definition .....</b>	<b>389</b>
To View the Database Components .....	389
<b>Chapter 12 •Entrapass Desktops .....</b>	<b>391</b>
<b>Work Area Customizing .....</b>	<b>392</b>
To Change the Display Properties .....	392
<b>Specific Desktop Customizing .....</b>	<b>394</b>
To Customize a Desktop (Full Access Operator) .....	394
To Customize a Desktop for a "Read-Only" Operator .....	396
To Transfer a Customized Desktop .....	397
<b>Message List Desktop .....</b>	<b>398</b>
To View and Sort System Events .....	398
To Customize Event Display in the Message Desktops .....	399
To Perform Tasks on System Messages .....	401
<b>Picture Desktop .....</b>	<b>404</b>
To Modify Pictures Display Options .....	404
<b>Filtered Messages Desktop .....</b>	<b>406</b>
To Configure a Filtered Messages Desktop .....	406
<b>Historical Report Desktop .....</b>	<b>407</b>
To Configure a Historical Reports Desktop .....	407
To Create and Edit Historical Reports .....	408
To Display Historical Report State in Real-Time .....	408
To Play Archived Video Recordings from a Desktop Message List .....	410
<b>Alarms Desktop .....</b>	<b>411</b>
To Define an Alarms Desktop .....	412
To View System Alarm Messages .....	413
To Display Alarm Desktops Automatically .....	415
To Acknowledge Alarms/Events .....	416
Acknowledging an Alarm Message .....	417
Acknowledging Alarms from the Alarms Desktop .....	418
<b>Instruction Desktop .....</b>	<b>419</b>
To View an Instruction about an Alarm Message .....	419
<b>Graphic Desktop .....</b>	<b>421</b>
To View Graphics in the Graphic Desktop .....	421
<b>Network Alarms Desktop .....</b>	<b>423</b>
To View Network Alarms .....	423
<b>Video Desktop .....</b>	<b>425</b>
To Define a Video Desktop .....	425
To Use the Video Desktop .....	425
<b>Video Server Status .....</b>	<b>427</b>
To View the Video Server Full Status .....	427

<b>Chapter 13 • Reports</b>	<b>431</b>
<b>Quick Report Definition</b>	<b>432</b>
To Define a Quick Report	432
<b>Historical Reports Definition</b>	<b>435</b>
To Define a Default "All Events" Report	435
To Define a Custom Historical Report	436
Defining Components for an Historical Report	437
Defining Card Options for an Historical Report	438
To Define a Card Use Report	439
To Define Automatic Report Schedules	440
Specifying Additional Options for an Automatic Report	442
To Define a Report Output Format	443
To Request Historical Reports	445
To Request an Event Report	447
<b>E-mailed Reports</b>	<b>448</b>
To Define a Report to Send by e-Mail	448
<b>Time and Attendance Reports Definition</b>	<b>450</b>
To Define Time and Attendance Reports	450
<b>Time and Attendance (T &amp; A) Reports Request</b>	<b>453</b>
To Request a T and A Report Manually	453
<b>Operations On Time and Attendance</b>	<b>454</b>
To Add Transaction in the Time and Attendance Database	454
<b>Report State</b>	<b>457</b>
<b>Reports Viewing</b>	<b>458</b>
To Display a Report	458
To Preview Historical Reports	459
To Preview Time and Attendance Reports	460
<b>Chapter 14 • EntraPass Options</b>	<b>461</b>
<b>Card Format Modification</b>	<b>462</b>
To Define a Display Format	462
<b>Authentication Password Modification</b>	<b>464</b>
To Change the Authentication Password	464
<b>System Language Selection</b>	<b>465</b>
To Change the System Language	465
<b>Keypad Family</b>	<b>466</b>
<b>Printers Selection and Configuration</b>	<b>467</b>
To Select and Set Up a Log Printer	467
To Select and Set Up a Badge Printer	468
<b>System Date &amp; Time Modification</b>	<b>469</b>
<b>Multimedia Devices Configuration</b>	<b>470</b>
To Select an Alarm Sound	470
To Define Video Options	471
To Set Up the Signature Capture Device	472
<b>System Parameters Configuration</b>	<b>474</b>
Server Parameters	474
Server Logs	474
Redundant Server	475
Logout and Idle	475
Schedule	476
Disk Space	477

Diagnostic .....	478
Network Alarm .....	479
Icon Status .....	480
Gateway Parameters .....	480
NCC Global Features .....	480
KT-NCC .....	481
Firmware Parameters .....	481
KT-300 .....	482
KT-100 .....	482
KT-NCC .....	483
KT-IP .....	483
Image Parameters .....	483
Picture and Badging .....	484
Graphic .....	485
Report Parameters .....	485
CSV .....	486
Disk Space .....	486
User Name Format .....	487
Video Parameters .....	487
Parameters .....	488
Snap .....	489
Time Parameters .....	490
PIN Parameters .....	490
<b>Backup Scheduler .....</b>	<b>492</b>
To Schedule Automatic Backups of the System Database .....	493
<b>Custom Messages .....</b>	<b>495</b>
To Set Up Custom Messages .....	495
<b>System Registration .....</b>	<b>496</b>
<b>Database Integrity Verification .....</b>	<b>497</b>
To Perform a Quick Verification of the Database Integrity .....	497
<b>Chapter 15 •The EntraPass Server Module .....</b>	<b>499</b>
<b>The Server Launch .....</b>	<b>500</b>
<b>Server Connection list .....</b>	<b>502</b>
To View Applications Connected To The Server .....	502
To View the System Log .....	502
To View System Errors .....	503
<b>Backups .....</b>	<b>505</b>
To Create Backups of Type D, A, and T .....	505
To Restore Data (D, A and T) .....	507
<b>Server Utilities Usage .....</b>	<b>508</b>
<b>System Language Modification .....</b>	<b>510</b>
<b>Chapter 16 •System Utilities .....</b>	<b>511</b>
<b>Database Utility .....</b>	<b>512</b>
To Verify the Database Integrity .....	512
To Update Database Fields .....	512
<b>Database Utility, Server .....</b>	<b>514</b>
To Run the Database Utility .....	514
To Verify Database Index (Server) .....	515
To Verify Database Links .....	515
To Verify Database Archive Files .....	516
To Verify Time & Attendance Files .....	516

To Verify Database Hierarchy .....	516
To Swap Descriptions .....	516
To Clean the Database .....	517
<b>Entrapass Video Vault .....</b>	<b>518</b>
To Install the Entrapass Video Vault .....	518
To Launch the Entrapass Video Vault .....	520
To Manage Archived Video Segments .....	521
<b>Vocabulary Editor .....</b>	<b>524</b>
To Install the Vocabulary Editor .....	524
To Translate the System Language .....	524
To Integrate your Custom Language in Entrapass .....	528
To Distribute the New System Vocabulary .....	530
To Update the Server Vocabulary .....	530
To Upgrade the System Vocabulary .....	533
<b>Express Setup Program .....</b>	<b>534</b>
To Configure a NCC 8000/Global Site Using Express Setup .....	534
To Configure a Site Under a Corporate Gateway Using Express Setup .....	537
To Configure a Controller Using Express Setup .....	540
Defining Relays .....	541
Defining Inputs .....	542
Defining Auxiliary Outputs .....	542
<b>Quick Viewer .....</b>	<b>543</b>
<b>PING Diagnostic .....</b>	<b>545</b>
<b>Workstation—Configuration Program .....</b>	<b>547</b>
<b>KL-8000 Database Converter Program .....</b>	<b>548</b>
<b>Global Updater Program .....</b>	<b>552</b>
<b>Migration Utility .....</b>	<b>554</b>
To Migrate Entrapass Global Edition Version 1 to Version 3 .....	554
Migrating the Version 1 Server Database .....	554
<b>The Gateway Interface .....</b>	<b>556</b>
To Start the Gateway .....	556
To Reload the Gateway .....	556
<b>CardGateway Program .....</b>	<b>558</b>
To Install the CardGateway .....	558
To Configure the CardGateway .....	558
To Start the Program .....	559
<b>The SmartLink Interface .....</b>	<b>562</b>
To Configure the SmartLink Application .....	562
Starting the SmartLink Application .....	562
<b>Network Consumption .....</b>	<b>563</b>
<b>Chapter 17 •Animated Icons .....</b>	<b>565</b>
Alarm Systems .....	566
Controllers .....	568
Doors .....	570
Relays .....	574
Inputs .....	577
Sites and Gateways .....	579
Gateway (Gateway Software Interface): .....	581
Entrapass Application .....	582
Others .....	582

<b>Chapter 18 •Entrapass Bandwidth .....</b>	<b>585</b>
<b>Transactions between Entrapass Applications .....</b>	<b>586</b>
Communication Protocols .....	586
TCP/IP Protocol .....	586
Serial Communications .....	586
<b>Communication between Workstation and Server .....</b>	<b>587</b>
Display of Events, Pictures and Graphics on the Workstations .....	587
Component Status Query .....	588
Manual Operations .....	588
Saving and Modifying Data .....	589
Between Workstation and Server .....	589
Polling Between Server and Applications .....	590
<b>Communication with Global Gateway (Reloading Data) .....</b>	<b>592</b>
With the Controller .....	592
With the Global Gateway .....	593
Reloading Firmware to Controllers .....	596
Update between Components .....	596
Polling Between Gateway and Controllers .....	597
Controller Events .....	598
<b>Communication between Server and SmartLink .....</b>	<b>601</b>
Interaction between Applications .....	601
Bandwidth Required to Send Command Lines .....	602
<b>Communication between Main Server and Redundant Server .....</b>	<b>603</b>
Bandwidth Used by the Mirror Database .....	603
Bandwidth Used by the Redundant Server .....	604
Copy between Mirror Database and Main Server .....	604
<b>System in Idle Mode .....</b>	<b>605</b>

# Chapter 1 • Introduction

Welcome to EntraPass, a powerful multi-user access control system that provides all the features required in the most demanding applications.

**What Is EntraPass?** EntraPass is a comprehensive, menu-driven access control software package. Among the many features EntraPass offers, you will find:

- Remote communication capability (with Corporate Gateway only)
- Remote site management capability
- SmartLink interface with paging systems, HVAC systems, e-mail and more
- Redundancy server for fail-safe operation (optional)
- Integrates KT-NCC Network Communications Controller and Gateway
- Kantech IP Link module
- KT-200, KT-100 and KT-300 compatibility
- Express setup
- Local anti-passback, Global anti-passback, area management, secondary access levels, interaction between door controllers, guard tours, DayPass for temporary visitors
- Elevator control
- Integrated Badging capability
- Interactive floor plans
- Configurable desktops by operator
- Card Gateway (optional)
- Multiple reader technology
- External alarm system interfacing
- Alarm system partitioning
- Time and Attendance reporting
- e-mail reports capability
- Visual diagnostics
- Video Integration with American Dynamics family of Intellex® Digital Video Management System (DVMS)
- Live video display, recorded video playback, local event logging and saving
- Video archiving via EntraPass Video Vault (optional)
- Vocabulary editor included

**What Is Access Control?** Access control consists of a set of components (door readers, exit detectors, motion detectors, etc.) that are professionally installed and electronically controlled. System workstations are used to receive event messages, acknowledge alarms, modify the system database, etc. A supporting advantage of access control is that all system events are carefully archived and can be easily retrieved for inspection purposes.

## Entrapass Main Features

**SmartLink.** Entrapass enables organizations to interface to most intelligent devices such as CCTV multiplexers, alphanumeric pager systems, automated e-mails, HVAC systems, LCD panels, video matrix switchers, etc., using an RS-232 or network connection between one of the Entrapass SmartLink workstation and an external device.

Advanced system integration can be accomplished by using the bi-directional SmartLink to communicate with software applications such as Time and Attendance systems, Badging systems, Human Resource Management systems, Student Registration systems, etc., through TCP/IP, an RS-232 port or with DLLs. This allows complete and real-time data exchanges between systems, eliminating redundant data entry.

**Redundant Server & Mirror Database (Optional).** The Redundant Server & Mirror Database option provides an alternative duplication mechanism in case of failures and errors of the Primary Server. The mirror database creates a real-time copy of the system database on the Redundancy Server. In the event of failure of the primary server, the mirror database launches the Redundancy Server which supports all the features and functionality of the primary server. Once the primary server returns online, all archives are merged and the entire database is copied from the Redundancy Server.

**KT-NCC Controller and Gateway.** Entrapass is compatible with the KT-NCC Network Communications Controller that is perfect for customers looking for a better way to access control for a widely-dispersed environment without running extensive amounts of cable from each remotely located controller back to the server. When combined with the powerful Entrapass Global Edition software, the KT-NCC allows customers to more effectively utilize critical global security features for unsurpassed security.

**Kantech IP Link Module.** Entrapass is compatible with the Kantech IP Link module that provides a secure ethernet connection that serves as a polling device that will control the excess bandwidth by communicating to the gateways only when necessary. The Kantech IP Link module's main function is to relay information between the controllers and the gateway.

**KT-100, KT-200, KT-300 Controllers.** Entrapass is compatible with Kantech's KT-100, KT-200 controller and KT-300. (The NCC-8000 gateway is only compatible with KT-200). This has an added benefit when upgrading existing sites that require more flexibility and improved user interfaces. It also allows installers to select the controller that best suits their customers' needs and budget.

**Express Setup.** The Express Setup utility enables installers to automatically define and configure the most standard system components. This saves installation time and prevents setup errors. With Express Setup, the system is fully functional and ready to test the hardware and wiring before the installer makes the customized changes necessary for a particular site.

**Elevator Control Capability.** Entrapass allows installers to program up to 64 floors per elevator cab using expansion devices such as KT-PC4216, KT-PC4204 or REB-8 (16 floors maximum). This indispensable feature in a multi-tenant building allows facility managers to restrict specific floor access to authorized cardholders.

**Integrated Badging.** The Integrated Badging feature was added to Entrapass to allow users to design and print badges. Pictures and signatures can be imported or, with the necessary devices, captured and incorporated into cards for printing badges.



**Interactive Floor Plans.** EntraPass can import and display high-resolution graphics created on CAD-type systems, allowing you to design a graphic-based system that operators can use with minimal training. Interactive icons can be added to floor plans to display component status and offer full manual operation of the component in real-time.

**Configurable Desktops by Operator.** With EntraPass, each Operator can be assigned up to 8 configurable desktops. These desktops display selected windows featuring message events, user photos, filtered events, alarm instructions, high-resolution graphics and videos, and global alarms. Desktops can contain any combination of windows.

**Interfacing with External Alarm Panels.** KT-100 and KT-300 controllers allow users to arm, disarm, and postpone the arming of an external alarm panel through a Corporate Gateway. This allows EntraPass to easily integrate with an external alarm system.

**Partitioning Alarm System.** With EntraPass Global Edition, a site can be divided into 100 alarm system partitions. Each alarm partition can then be configured with any number of readers, door contact, motion detectors, sirens, user access rights and arming schedules.

**Time and Attendance Feature.** The Time and Attendance feature is a low-cost alternative to high-priced dedicated Time and Attendance systems. It enables operators to print or download time sheets in a CSV format to a payroll system.

**Visual Diagnostics.** EntraPass offers on-screen real-time visual representation of the system devices, with conditions updated in real-time, including high resolution floor plans that can be imported and displayed on screen. Interactive system icons can be added to the graphic to display component status in real-time. Manual operations may be performed from the real-time system graphic.

**Enhanced Video Integration.** EntraPass adds real-time monitoring capability to the Corporate and Global series as a response to the growing importance of video in access control systems. Integration with American Dynamics' Intellex® digital video management system through the powerful Intellex Application Programming Interface (API) provides real-time video monitoring as well as video playback. Video can be linked to real-time video monitoring as well as video playback. Video can be linked to access events and recorded from one to sixteen cameras from different Intellex units simultaneously. Presets, sequences, dome control and 1x1, 2x2, 3x3, and 4x4 views are available through the EntraPass software. All cameras can be called up directly from a floor plan simply by double-clicking on the camera or dome icon. Operators can configure viewing parameters for digital video applications through an EntraPass Global or Corporate Edition user interface.

**EntraPass Video Vault (Optional).** EntraPass Video Vault enables all video clips from an Intellex alarm or an EntraPass video alarm to be automatically stored as Audio Video Interlaced format (.AVI) files or Kantech Video Intellex (.KVI), Kantech Video Archive (.KVA) and American Dynamics' Network Client's video format (.IMG) which can be password protected. Each EntraPass Video Vault may be connected to as many Intellex units as defined within the EntraPass software. Video may be saved to up to 24 pre-programmed hard drive locations. A .bmp image may be associated automatically with each video clip, and a thumbnail image may be created on the first frame of the video clip.

**Vocabulary Editor.** The system is multilingual. It is available in English, French, Spanish and German. It can also be translated in up to 99 languages.

## Entrapass Manual and Help

### Using the Reference Manual

The *Reference Manual* is designed for Entrapass system installers, administrators and users. You may refer to the hard copy of the manual or to the on-line version in pdf format.

To download an updated version of Acrobat Reader, browse to <http://www.adobe.com>.

### Getting Help

Our window-level help will provide you with immediate and context-related help. Press [F1] on your keyboard to display the help related to the active window or select [Help] [Contents] from the Entrapass menu.

For immediate help, use the Help button, found in all the system window. You may also use the right-click option; it may either display a shortcut menu or the help file of the active window.


### Technical Support

If you cannot find the answer to your question in this manual or in the Help files, we recommend you contact your system installer. Your installer is familiar with your system configuration and should be able to answer any of your questions.

Should you need additional information, please call our Technical Support Help desk, Monday to Friday 8:00 AM to 8:00 PM E.S.T. (GMT -5:00)

Phone	+1 (450) 444-2030
Fax	+1 (450) 444-2029
US & Canada	1 888 222-1560 (Toll Free Number)
Internet	<a href="http://www.kantech.com">http://www.kantech.com</a>
E-mail	<a href="mailto:kantechsupport@tycoint.com">kantechsupport@tycoint.com</a>

# System Architecture





---

## Chapter 2 • Software Installation

Before any installation takes place, make sure that the computers on which the software will be installed meet the necessary requirements.

For information concerning hardware equipment installed with the software, refer to the documentation supplied with the hardware.

This chapter contains information related to the EntraPass software. You will find:

- System requirements
- Software installation and upgrading

Depending on the system configuration, there are different system hardware requirements for the installation of the EntraPass software.

## System Requirements

Make sure that the computer on which you are installing the software meets the following requirements:

- Operating Systems: Windows® 98 (Second edition)/NT/2000/XP/2003 Standard and Enterprise Server Editions
- Processor: Pentium III at 800 MHz (minimum)
- RAM: 256 MB RAM minimum
- Minimum free hard disk space: 4 GB
- Color depth (for Video Integration): 24-bit (16 million colors)
- Screen resolution: 1024 x 768
- Graphic adapter: 32 MB
- 48X DVD/CD-ROM drive
- Network Interface card: 10/100 Base-T network adaptor
- 

### Video Applications

- Pentium III with 256 MB RAM recommended
- Windows® 2000/XP/2003 Standard and Enterprise Server Editions
- Windows® XP Home and Professional
- Graphic adapter with at least 32MB of RAM
- Monitor with a resolution of at least 1024 x 768

### Workstation and Gateway Applications with NCC

- Windows® 98 Operating System ONLY (DOS is required for NCC program and is not available with NT or 2000)
- Pentium III processor at 450 MHz (minimum)
- 64 MB RAM (128 MB recommended)
- 2 GB HDD minimum
- 17 inch screen (1024 x 768 minimal resolution)
- 4 MB Graphic adapter card
- 10/100 MBPS Ethernet TCP/IP Network card

### NCC8000 or DOS Application ONLY

- DOS Version 6.22 or higher Operating System (DOS is required for the Global Gateway program and is not in Windows®)
- Pentium III processor at 450 MHz (minimum)
- 64 MB RAM (128 MB recommended)
- 2 GB HDD minimum
- Requires EMS memory

---

## Additional Requirements

For several applications, you can use the following devices:

- A video capture card—to capture user images for card identification
- A sound card—to use warning sounds when an alarm is reported
- A badge printer—to print badges (Badging)
- A signature capture device—to capture signatures (Badging)
- A log printer—(dot-matrix or laser) to print events (messages and alarms)
- A Report printer—(laser) to print reports

## Installation Kit

The EntraPass installation package contains EntraPass software CD as well as the *Reference Manual* DN1316 . It also contains a CBLK-10 kit including 100-foot cable, 2 connectors from KT-200/KT-300 and a DB9 to DB25 adaptor.

Your installation CD allows you to install the basic components of your EntraPass:

- 1 Server application and 1 Workstation application (for configuration purposes)
- Report Viewer
- Vocabulary Editor
- KT-NCC capabilities
- 5 additional workstation applications
- 1 Global Gateway application
- SmartLink and SmartLink Network Interface

The installation CD also contains system advanced options. They require an additional license:

- 8 additional workstation applications (up to 128+1)
- 16 NCC 8000 Gateways, 16 Global Gateways and up to 40 Corporate Gateways
- Redundant Server & Mirror Database application
- Oracle/MS-SQL HR Interface application



**NOTE:** Additional options can only be installed after the EntraPass Server has been registered. They require an additional license.



## Installation Steps

The InstallShield Wizard will guide you through the installation steps. All you need to do is to enter the System Installation Code (located on the software CD) and follow the instructions displayed on the screen.

### To Install EntraPass Software

The system will be up and running in three steps! Installers need to:

- 1 Install the software using the System Installation Code located in the CD pocket.
- 2 Register the system using the Registration Confirmation Code provided by Kantech Customer Assistance.
- 3 Install the first components that are part of the installation kit (5 workstation applications and 1 Gateway; the first workstation application is automatically installed during the installation of the EntraPass Server).



***NOTE:** The software is fully functional even before it is registered. However, an unregistered system is restricted to ten cards. Moreover, there is an automatic logout after 1 hour of idle time, that is, when there is no action on the keyboard. After an automatic logout, operators need to enter a 20-character password; it is displayed in the lower part of the screen, in a yellow box.*

***NOTE:** During installation of the EntraPass Global Server, you are given the option of installing the Global Gateway and SmartLink. All components will be installed on the same computer.*

### To Add Optional Components/Features

Four steps are required to install additional components/features to your system. And there are two ways of doing it:


- 1 Use your installation CD-ROM to install additional components all at once, or go through the Server or Workstation Registration window to add individual components to your system.
- 2 Call Kantech to obtain or register the component/option Option Code (located on the Option Certificate) and get the Registration Confirmation Code.
- 3 Enter the Registration Confirmation Code in the Registration window and activate the option.
- 4 Install the component or option using the Installation Code (if applicable). The Installation Code is generated by the system; it is displayed in the Registration window.



***NOTE:** You need to establish communication between the EntraPass Server and the computer where the new component/option is installed (if applicable). Perform this step only if you have installed the component/option on a computer other than where the EntraPass Workstation application has been installed.*

## System Installation

- 1 Before you begin the installation, make sure that no EntraPass application is running.
- 2 Insert the software CD into the CD-ROM drive. The installation program should start automatically if your computer is configured to autorun. If the installation program does not start automatically, click **Start > Run**, then enter **d:\Setup.exe** (where d: is the CD-ROM drive) in the displayed field. The system displays the installation setup window.




- 3 Before you go any further, you must select which language you wish to install the system in. English is selected by default.




**NOTE:** The system language depends on the language you select when installing the software. For example, if you select “French”, it will be the system default language at start up.

- 4 Click Next. The Welcome screen will be displayed.




- All the installation windows look the same as the Welcome window.
  - You will notice the software version you are about to install is located at the top left.
  - The middle section of the window contains the instructions you will follow throughout the installation process. The instructions will be updated automatically when you click **Next**.
  - **Back** and **Next** buttons are available at the bottom of the screen to allow navigating back and forth within the installation screens if you wish to verify or modify a parameter you previously setup.
  - You can **Cancel** the installation at any time.

- 5 Click Next to continue the installation. The Setup Start window will be displayed.




- 6 Select the operation(s) you wish to perform. The first set of options are for new installs and the last option is for updates. During the first installation, you will only be able to select one of the install options. We suggest that you install the first option in the list.
- **Install Server, Database and Workstation:** This option will install the Entrapass Global Edition system. It will be grayed out if the application is already installed on the machine.
  - **Install Additional Workstation:** This option is selected when you are installing an additional workstation. It will be grayed out if a server or a workstation is already installed on the machine.
  - **Install Entrapass System Options:** This feature allows installing Entrapass options (Gateways, SmartLink, Video Vault, MS-SQL Mirror Database and Redundant Server, etc.). You will need to contact Kantech Systems Help desk to get the registration key number to install the system options. see *"System Registration"* on page 22. The feature will be grayed out if all options have already been installed on the machine.
  - **Install Entrapass System Tools:** This option allows installing Entrapass System Utilities (Vocabulary Editor, Report Viewer, Video Viewer, SmartLink Network Interface, etc.). An option is greyed out if the utility has already been installed on the machine.
  - **Update Installed Applications:** This option will be grayed out if the system has not been installed previously. To update your Entrapass system, see *"System Update"* on page 31.

7 Click Next. The Serial Number window will be displayed.



8 Enter the Serial Number for the Entrapass Global Server or Software. The information is located in the CD pocket. Make sure to enter the correct digits. The Next button is only enabled if the serial number is valid.

- 9 Click Next. The Setup window will be displayed, indicating the installation progress. Once completed, the system displays the software End-User License Agreement.




- 10 Click I accept... if you understand and agree with the conditions described in the end-user license agreement or click I do not accept... to cancel the installation.




**NOTE:** You will not be able to complete the installation if you refuse the terms of the license agreement. The Next button will remain grayed out until you select I accept...


11 Click Next. The Customer Information screen will be displayed.



- 12 Enter the User Name and the Company Name.
- 13 Select the user type: Anyone who will use this computer or Only the person currently logged in and registered in the system.
- 14 Click Next. You will be prompted to select the system and database language.
- 15 Select the primary language. You can select a secondary language or leave the selection to None.




16 Click OK. The Choose Destination window will be displayed.




17 Click Next to accept the default installation folder indicated in the window.

- If you want to change the directory where to install the application, click **Change**. The Choose Folder dialog will pop up where you can select the new installation directory.
- Type in the destination directory where you want to install EntraPass or double-click the directory structure all the way down to the destination directory. Then, click **OK**. The path will be indicated in the Choose Destination Location window.







18 Click Next. The Ready to Install window will be displayed.



- 19 If you need to review the parameters you've setup, click Back. If everything is ready for the installation, click Next. The system starts the installation and displays the installation setup window.
- 20 During the installation process, you will be prompted to Install the Intellex API now?
- If the API is not already installed, click Yes.
  - If the API is already installed, click No.



- 21 Once the first option installation is completed, the system will prompt you to consult the Read Me file. You can also select to install the applications as services. Applications that run as services will automatically restart after a system shut down even if accidental.




- 22 Click Next. The system will verify if there are any other applications or utilities you can install. If this is the case, the following message will popup on screen:


- If you want to install other applications, click Yes and start over at number 4.



**NOTE:** If the application you want to install requires a serial number, you must call the Kantech Technical Support Desk to register the system before you can go any further: see "System Registration" on page 22.



- If the installation is completed and you do not wish to install other applications, click No. The InstallShield Wizard Completed window will popup:



- 23 You can select to restart your computer at this time or do it later.
- 24 Remove the cd from the cd drive.
- 25 Click Finish to complete the installation.



**NOTE:** *You must restart the computer after the installation.*


- 26 Your next step will be to contact Kantech Technical Support desk to get your registration key number for the systems different components. Follow the instructions in the next section of this manual.

## System Registration


It is recommended to register the system as soon as possible so that users can install additional options and use the access system with no restrictions. In fact, though the system is functional even before the system registration, it is limited to only 10 cards. Moreover, when the system is not yet registered, operators are logged out after one hour of idle time; then they have to enter the randomly-generated 20-character password each time they are logged out.

### To Register the System


- 1 Click the Server icon on the computer desktop. You may also start the EntraPass Server from the Windows® Start menu (Start > EntraPass Global Edition > Server > Server)



- 2 Click Login / Logout button. The Operator Login window appears.



- 3 Enter Kantech in the User name field (not case sensitive). Enter the temporary 20-character password displayed at the bottom of the Operator login window (the temporary password appears on new installations only and is highlighted in yellow). The System registration window appears.



- 4 Click the Temporary password in use (...) yellow button to register the system. The System Registration window appears. This button is visible on new installations only.
- 5 Enter the Registration Confirmation Code provided by Kantech, then click OK. The OK button is only enabled when the registration code is valid.




**NOTE:** If you exit the Server main window without registering the system, the Change Authentication Password window is displayed. It is no longer displayed when the system has been registered.

## Additional System Components

Once the Server has been registered, you may install additional system components. These include EntraPass applications and other utilities such as the EntraPass Video Vault application. Before you install system components, make sure that the designated computer meets the minimum requirements.

You do not need to call Kantech Technical Support Help Desk to install the first two workstation applications and the first gateway application. These are part of the installation package.

- 1 In the Server main window (or Workstation application option window), click the Registration icon. The System registration window appears.




**NOTE:** The EntraPass Server is supplied with five workstation applications and one Global Gateway application. One workstation application is automatically installed when the Server is installed. It is used for configuration purposes. It does not appear in the lower pane because it is automatically installed and registered. Use the installation CD and the Installation Codes to install the four additional workstation applications. Make sure that the computer on which they will be installed meets the minimum requirements.

- 2 Click the Print button to print the Installation Codes, so that you can take the codes where you are installing the workstation or gateway applications. To avoid errors, do not copy the codes on a piece of paper.



**NOTE:** When you install an advanced option (for example an additional gateway), you can configure its sites using the Express Setup utility.

- 3 From the System registration window, select the component you want to install. Then select the Click here to install component button (left-hand pane). The Component Registration (Name of component) window appears.



Component registration (Additional Workstations)

System Serial Number: FC92, 04D9, C031, BA96, G563

Option Serial Number: [ ][ ][ ][ ] OK

Please contact Kantech Systems to register your system

Phone: +1 (450) 444-2030  
Toll free: 1-888-222-1560 (US & Canada)  
Fax: +1 (450) 444-2029  
E-mail: kantechsupport@tycoint.com

Registration Confirmation Code: [ ][ ][ ][ ]

Cancel

- 4 Enter the Option Serial Number (located on the Option Certificate) then call Kantech Customer Assistance (phone numbers are displayed on-screen) to get the Registration Confirmation Code.
- 5 Enter the Registration Confirmation Code, then click OK. The OK button is only enabled when the correct Registration Confirmation Code has been entered.




**NOTE:** When you have entered the correct Registration Confirmation Code, the system generates an Installation Code. Blue flags identify components that have been created, but not yet activated. Green flags indicate components that have been activated.

## System Components Edition

EntraPass enable users to assign custom names to applications for easy identification in system events. You can also modify components names in their definition menu (Devices > EntraPass Applications).

### To Assign a Descriptive Name to an Application

- 1 From the Registration window, select an application, then click the Edit button. The Edit a component window appears.
- 2 Enter a descriptive name for the selected EntraPass application in the Description fields. It is recommended to enter two names, one in the primary language and the second in the secondary language if EntraPass is run in two languages.
- 3 Check one or more appropriate option(s):
  - **Workstation locked:** check this option if this application will be installed on a computer and be used only for receiving system events.
  - **Locked for authentication:** check this option if you want the computer where you have installed the EntraPass application not to send its authentication data to the server.
  - **Use specific password for authentication:** check this option if you want to assign a specific password to this workstation. If you select this option, enter the password in the Authentication password field.



**NOTE:** The Application type field displays the type of the selected EntraPass application. For instance, it will display “Corporate Gateway” if the selected application is a Corporate Gateway application. This identification is also displayed in the EntraPass application definition window (Devices > Defining an EntraPass application).



## Communication with the EntraPass Server

After an EntraPass application has been installed on a computer, communication with the EntraPass Server must be established between the two computers. The following steps will assist you in configuring and establishing the first communication between the workstation application and the EntraPass Server using the proper protocol.



**NOTE:** Before you proceed, make sure that the Server is online. If it is not, launch it.


### To Establish Communication with the Server

- 1 From the Windows® Start menu, click on Start > Programs > EntraPass Global Edition > EntraPass application (x) > Register to Server utility. You may also start the EntraPass application; the system automatically launches the registration program when an application attempts to connect to the Server before it is registered.



**NOTE:** The Registration window also appears when you launch an application before the EntraPass Server is online. When this happens, simply start the EntraPass Server.

- 2 Click to select the communication protocol that is used between the EntraPass Server and the EntraPass application.
  - **NetBEUI:** The NetBEUI protocol (NetBIOS Enhanced User Interface) uses the computer name to communicate with devices. Enter the name of the computer where the EntraPass Server software is installed (case sensitive). The name of the current computer is displayed in the status bar. You may use the Scan button to browse and to display existing computer names.
  - **TCP/IP:** Enter the TCP/IP address of the computer where the EntraPass Server program is installed. The EntraPass Server TCP/IP address appears in the Server status bar.
  - **Local:** Enter Local when registering a component on the same computer as the EntraPass Server software is installed. This option will take the address from the Server software.
- 3 Check the Provide local TCP/IP address button if this EntraPass workstation connects to the EntraPass server using a VPN (Virtual Private Network) connection. Type the IP address used by the VPN application. This address is provided by the VPN application and is usually accessible by clicking on the minimized VPN icon found in the system tray.
- 4 You may enter an Authentication Password if you want operators to use a specific password when they register EntraPass workstations to the EntraPass Server.



---

## Internal Global Gateway Installation (NCC8000)

Under Windows® 98, the EntraPass application and the Gateway can be installed on the same computer. If this is the case, add the following lines in the Config.sys file.

### To Edit the Config.sys File

- 1 From the Windows Start menu, select Run.
- 2 In the Run dialog box, enter: Sysedit.
- 3 From the displayed files, select CONFIG.SYS and enter the following lines:
  - dos = high,umb
  - break = off
  - device = c:\WINDOWS\himem.sys
  - device = c:\WINDOWS\emm386.exe ram 592
  - files = 20
  - buffers = 20
- 4 Reboot the computer.


## External Global Gateway Installation (NCC8000)

If the Global Gateway is installed on a separate computer (not with the Gateway), perform the following steps:

- 1 Use a different computer to perform these steps. First, make sure DOS version 6.22 or higher is installed on the computer that will be used as the Global Gateway.
- 2 Connect a RS-232 cable—using proper adaptors—to the COM port where the gateway is installed and to the COM1 port where the Global Gateway program will be installed.



***NOTE:** The COM1 serial port of the Global Gateway computer is used to communicate with the Gateway software interface, NO OTHER COM PORT SHOULD BE USED; OTHERWISE COMMUNICATION WILL NOT WORK. Furthermore, if the “COM1” port is defective, you must change the computer.*

- 3 Create a boot diskette (under Windows 98). To create a boot diskette: Insert a formatted diskette in A:\. From the Windows® Desktop, double-click My Computer icon. From My Computer window, right-click  button, then select Format from the short-cut menu. From the Format window, under Other Options, check Copy system files, then click the Start button.
- 4 Once the diskette is formatted and system files are copied, you must “Explore” the CD (go in Explorer) and copy (see note below) all the files located in the Global Gateway directory of the CD to the bootable diskette,



***NOTE:** Do not forget to remove the “Read Only” attribute on all the files. From the diskette, press CTRL + A to select all the files, then right-click and select “properties”. Remove the check mark from the “read-only” field.*

- 5 On certain installations it may be necessary to load the following drivers. To do so, you have to add the following two lines to the config.sys file:
  - DEVICE = C:\DOS\HIMEM.SYS
  - DEVICE = C:\DOS\EMM386.exe



***NOTE:** HIMEM.SYS and EMM386.EXE are memory management drivers used to free conventional memory—first 640K of memory on a computer. These drivers free up as much conventional memory as they can and allow the Global Gateway software to use this free conventional memory to run properly. It may be necessary to load these drivers because not using them may result in Global Gateway malfunctioning. For example, this would cause the Global Gateway to not respond properly or even stop responding when certain requests are made, like activate/deactivate a relay. Loading these drivers frees the conventional memory needed for running the Global Gateway program. Even though this particular problem does not appear on all installations, it is necessary to add these lines to prevent any problem.*

- 6 Remove the diskette from the computer. Shutdown the computer where the Global Gateway program will be installed, insert the bootable diskette into the Global Gateway floppy drive and power-up the computer. The installation will be carried out automatically. When the installation is complete, 9 beeps will be heard.
- 7 Remove the diskette, shut down the computer and reboot it. The Global Gateway will list the serial devices found on the PC, on-board COM ports and KLEXP-08 COM port expansion board, and start scrolling through the different baud rates in search of the gateway.

---

## External Global Gateway Configuration (NCC8000)

To configure the external Global Gateway so it can communicate with the gateway, follow these steps:

- 1 Start an EntraPass application or the EntraPass Configuration Program.
- 2 In the Device tab, select the Gateway Definition menu.
- 3 From the list, select the gateway that will be used with the Global Gateway.
- 4 In the NCC connection area, select "RS-232".
- 5 In the RS-232 Gateway configuration area, select which Serial port is used on the gateway's computer to communicate with the Global Gateway and select the Baud rate used between the gateway and the Global Gateway.
- 6 Click Save.

## System Update

When you update your software, the system automatically detects the components that are installed and updates them.

It is highly recommended to update your system when the system is at its minimum use (Friday night, for example.)

### Before Updating Your Software

- 1 Perform a complete backup of your system database. For more information on how to perform a backup, see *"Backups"* on page 505.
- 2 If you have a Redundant Server & Mirror Database option installed, you **MUST** shutdown the Redundant Server **FIRST**.
- 3 Shutdown the EntraPass Server and all other EntraPass applications. **No applications should be running when you perform a system update.**




***NOTE:** The update will be performed on all components of your system at once. Once the update is complete, **DO NOT START THE** Redundant Server and Mirror Database yet.*

- 4 Verify the system database (see *"Database Utility"* on page 512) to make sure that no errors are detected.
- 5 Once you have verified the database and no errors are present, start the EntraPass Server. Once the Server is up-and-running, start the Redundant Server & Mirror Database. It is essential to start the Server **before** starting the Redundant Server and the mirror database.
- 6 Once all applications have been updated, we strongly recommend that you reload the gateways to ensure that all data will be refreshed and sent to controllers (Operations > Gateway reload).
- 7 You may also use the View connected List menu item to verify the status of all the system gateways and EntraPass applications. For details, see *"The EntraPass Server Module"* on page 499.


### To Update your Software

- 1 Insert the software installation CD into the CD-ROM drive. The installation program should start automatically if your computer is configured to autorun. If the installation program does not start


- automatically, click Start > Run, then enter d:\Setup.exe (where d: is the CD-ROM drive) in the displayed field. The system displays the installation setup window.
- 2 Click Next. The Welcome window will be displayed.




- 3 Click Next. The Setup Start window will be displayed.




- 4    Select **Update Installed Applications** and click **Next**. The **Previous Software** window will be displayed, listing all the software that are currently installed on your machine.



- 5    Click **Next** to continue. The update will start and all programs currently installed on your machine will be updated.



- 6 Click the **View** button to read the Read-Me File that contains information on the updates that were done to the different applications. When you are done with this file, close it. You will automatically return to the Setup End window.
- 7 Click **Next**. The system will verify if there are any other applications or utilities you can install. If this is the case, a message will popup on screen:




- If you want to install other applications, click **Yes** and start over at number 2.



**NOTE:** If the application you want to install requires a serial number, you must call the Kantech Technical Support Help Desk to register the system before you can go any further: see "System Registration" on page 22.

- If the installation is completed, click **No**. The Maintenance Completed window will popup:



- 8 You can select to restart your computer at this time or do it later.
- 9 Remove the cd from the cd drive.
- 10 Click **Finish** to complete the installation.




**NOTE:** After the update, you must restart the computer in the order prescribed at the beginning of this chapter, see "Before Updating Your Software" on page 31.



## Removing the Entrapass Software


If you need to remove the Entrapass software from the computer, you will use the **Add/Remove Programs** option in the Control Panel.

- 1 Click **Start > Settings > Control Panel**.
- 2 When the Control Panel is opened, click **Add/Remove Programs** to open the dialog.
- 3 Select the program you want to delete from the list and click **Remove**. The Entrapass Uninstall program dialog will display on the screen.



- 4 Select the application you want to uninstall. If you want to uninstall Entrapass completely, check the **Uninstall all applications** box.
- 5 Click **Next**. The process will begin.

- 6 When the uninstall process is completed, the Maintenance completed dialog will display on the screen.



- 7 Click Finish to exit the wizard.
- 8 Restart your computer.

## Chapter 3 • Getting Started

This chapter introduces operators to the EntraPass system graphical user interface and basic functions.

To start an EntraPass session, you have to launch the EntraPass Server, the Gateway and the Entrapass Workstation. The server is a dedicated computer on a network that manages the access control system database. It is used to receive and dispatch information from the gateways. Gateways receive information from sites and transmit it to the server. EntraPass Workstations enable operators to access and program the system database and components.



***NOTE:** In the EntraPass Global and Corporate Edition, the Redundant Server & Mirror Database option may be enabled to monitor the activity of the Primary Server and to serve as an alternative if the Primary Server fails.*

The software allows operators to start the gateway and the workstation application at the same time by clicking on the Gateway-Workstation icon located on the desktop.



***NOTE:** All authorized system operators must have a unique and confidential login name and password that should be assigned by the system installer/administrator. It is very important to restrict access to the EntraPass workstations to authorized personnel only.*

## Session Start and End

- 1 From the Windows® Start menu, click Start > Programs > EntraPass Global Edition > Server / Workstation > (EntraPass application), where the EntraPass application may be a Workstation only application, a Gateway application, or any system stand-alone utility. You may also start the program from the EntraPass shortcut icon on your desktop.
- 2 On startup, the application attempts communication with the Server. The display language depends on the settings of the operator who was previously logged on the EntraPass. English is the software default language.




**NOTE:** You have to start the EntraPass server first. If you start an EntraPass workstation before starting the server, you are prompted to register your application to the server even when the application has already been registered. If the application has been registered, you just have to start the server.


## To Start the Primary Server

The EntraPass Server is used for:

- Displaying all the applications connected to the server, the system event and system error logs
  - Registering new connections (workstation applications, gateway applications, client applications such as SmartLink, Video Vault, Report Viewer, etc.)
  - Performing backups (Data, Archives, Time and Attendance databases)
  - Restoring data (data, archive, Time and Attendance databases)
  - Verifying database integrity
  - Changing the database language
- 1 Start the Server (from Windows® Start menu or from the desktop). The Server startup window displays a progress bar as well as the information related to the server startup process.




- 2 From the EntraPass Server window, click the Login/Logout button to login.




**NOTE:** To allow an operator to login to the server, the System Administrator must select the option “Allow login on server”, during the “Operator security level” definition (*System > Security Level*). For more information, see “Security Level Definition” on page 356.

- 3 Enter the login information in the Operator login dialog box. The default User name is kantech. It is not case sensitive. The default Password is kantech, in lower case; it is case sensitive.



**NOTE:** The system keeps the last five usernames, allowing operators to select their username from the drop-down list. To delete a username from the list, simply select it, then press *Delete* on the keyboard.

- 4 Once you have entered the correct login information, the EntraPass Server main window appears. Select the desired tab or the corresponding menu item to perform an operation or to display system information.




**NOTE:** The status bar indicates the communication status: Green: Communication is OK, Red: Communication problems.

- 5 Point the cursor to the status flag (colored rectangle) to enable a hint describing the displayed information: the first two colored rectangles indicate the server database open state and the database locked state.
  - If the first status flag is red, this indicates that the system database is not open. This could be due to a backup or a database verification in progress. If it is purple, this indicates that the database is locked because a backup is being restored or the Mirror database is copying data.
  - If the second status flag is red, this indicates that the database is unavailable. This happens when the server is processing data or updating the database.

## To Start the Gateway Program

The gateway program may be installed on the same computer as the server or the EntraPass workstation application, but it is recommended to install it on a dedicated computer.

- 1 Start the gateway (from Windows® Start menu or from the desktop). You do not need to enter a password or a username. The EntraPass Global Edition main window appears.



- 2 You may right click anywhere in the Gateway window to display a submenu:
  - Minimize minimizes the Gateway window
  - Send to tray sends the window to the status (tray) bar
- 3 Pay attention to the progress bars; they indicate:
  - Configuration data received from the server: this indicates configuration data such as card modifications are being sent to the gateway from the server.
  - Data requested by workstation: this is requested data such as a status request.
  - Messages sent to server: these messages originating from a controller are sent to the server.



**NOTE:** The *Gateway type* field indicates the gateway that is running. It may be a Corporate Gateway or a Global Gateway.

- 4 You may select the System menu item to login, to logout, or to perform a gateway reload.
- 5 You may select the Gateway menu item if you want to choose a gateway. The number of gateways that are communicating with the server is displayed on status bar in the Gateway main window.



**NOTE:** The status flags show the communication status. The first status flag indicates the status of the communication with the server. If red, this indicates that the server is not communicating with the Gateway. This can occur when the server is offline (you may then start the server). The system date and time, the number of gateways and the server IP address appear also on the status bar.

## To Start the EntraPass Workstation

An EntraPass workstation is a computer where the EntraPass monitoring application has been installed. It enables operators to access and program the system database and components. Make sure that the server is online when you start the EntraPass workstation software.

On startup, the workstation application attempts communication with the Server. The display language depends on the settings of the operator who was previously logged on the system. English is the software default language.




**NOTE:** Start the EntraPass server first. If you start an application before starting the server, you are prompted to register your application to the server even when the application has already been registered. If the application has been registered, you just start the server.

- 1 Start EntraPass workstation (from Windows® Start menu or from the desktop).




- 2 Click the Login/logout button on the toolbar.



**NOTE:** When the server is off-line, the first status flag (colored rectangles of the status bar) turns red; the Login/logout button is disabled. If this happens, launch the server; the EntraPass workstation will resume its operation.




- 3 Enter your Operator User name and Password. The password is case sensitive. The default User name is kantech. It is not case sensitive. The default Password is kantech, in lower case; it is case sensitive.




*NOTE: If you cannot log on properly, check if the Caps Lock key is activated. When proper login data have been entered, the system menu, toolbar and status bar are enabled.*

*NOTE: Operators are not allowed to login on more than one Entrapass workstation at a time. However, an operator may login on the Entrapass Server and Entrapass workstation at the same time.*



## To Access Information on the Workstation Connection Status


- 1 Click any tab to access the system toolbar or select a menu item to access the system menu. In the lower part of the window, color-coded flags indicate the communication status: Green, communication is OK; Red: communication problems; Blue: a report is pending.
- 2 Move the cursor over the colored rectangles to show details about the network status, the network database status and the workstation application report status.
- 3 Move the cursor over the displayed numeric values to show details. It will indicate, in order, the system date and time, the operator's name, items in the Alarms desktop, alarms to be acknowledged, etc.
- 4 Double-click (or single click, depending on your system settings) any number in the status bar to display the Status information window.



**NOTE:** It is recommended to use the *Login/logout* button when you exit EntraPass programs. This ensures that the system databases are shutdown properly.

## To Modify Your Work Area Properties

- 1 Right click anywhere in the main window to display the Properties window. It allows you to customize the window buttons as well as the background color.



- 2 To modify the size of the toolbar buttons, select one of the following:
  - **Small buttons:** small buttons are displayed below menu items
  - **Large buttons with images:** components icons are displayed on large buttons

- Large buttons without images: no icons are displayed
- 3 In the Miscellaneous section, make the appropriate choice:
    - Display menu: only the menu bar appears. No icons are displayed. Right-click the work area to modify the properties.
    - Display toolbar: the menu bar and the toolbar are displayed.
  - 4 Select a background color for the work space.


## To Retrieve Hidden Windows on the Desktop

EntraPass allows you to work with multiple windows opened in the Desktop area. When a window is minimized or sent to the background, it completely disappears from the screen. A command in the workstation contextual menu can help you retrieve the dialogs.

- If the window was minimized, the command in the menu will bring it at the front of the screen where you will be able to maximize it.
- If the window was sent to the background, the command in the menu will bring it to the foreground.

This command applies for desktop screens, configuration screens, operation screens, status screens, database screens and report screens.

- 1 Right-click the background area of the workstation window. A contextual menu will popup.



- 2 In the example above, the Status screen was sent to the background. Clicking the Status screen command in the menu will bring it back to the foreground.

## Express Setup

Express Setup allows you to configure system components such as sites and controllers, as well as devices associated with these components such as doors and inputs. This utility reduces programming to a minimum, allowing the installer to test the installation and system components. You may use it to configure a site or to define controllers associated with a site.

When used to configure a site, it allows installers to associate this site to a gateway. It also allows installers to configure the site rapidly, giving minimum configuration information about the controllers connected to it.

You may launch Express Setup from Windows® Start menu: Start > Programs > EntraPass Global Edition > Server > Express Setup or by clicking the Express Setup icon from a number of EntraPass workstations' windows.



**NOTE:** There are two versions of the Express Setup program: Express Setup NCC configures Global Gateways only, and Express Setup configures Corporate Gateways only.

When used to configure a controller, it allows operators to assign default values to a controller and to its associated devices (input, relays and output). In this case, it is launched at a system message box or from a controller definition menu.



**NOTE:** You have to login to the server when you launch Express Setup. In fact, as the program allows you to modify the system devices configuration, it is essential to authenticate yourself before proceeding with any modification.

For details on Express Setup, see "Express Setup Program" on page 534.

---

## System Stand-Alone Utilities












EntraPass includes a number of stand-alone utilities that allow operators to perform a variety of tasks including verifying the system database or changing the system language. The following is a list of EntraPass stand-alone utilities:







- **Database Utility:** This program is intended to re-index archived files, update database fields, verify archived files, verify the database integrity, verify the database index, verify the database links and verify the database hierarchy. This utility is run while the server is shutdown.
- **Express Setup:** Program used to configure all the components related to a gateway including the type of readers used, type of connection, number of sites, number of controllers in a site, etc.
- **PING Diagnostic:** Program used to diagnose network related problems.
- **System Report Viewer:** Program used by the operator to view reports without having to start a Workstation. When this utility is installed, operators can view reports sent by other workstations using the EntraPass e-mail feature.
- **Vocabulary Editor:** Simple and easy program used to translate the software in the language of your choice.
- **Workstation (Configuration Program):** Program, similar to a standard workstation, used by the system administrator to configure the system logical and physical components.
- **Migration Utility:** Program used to transfer information relating to software and database for the upgrade from Special Edition to Corporate Edition or Corporate to Global Edition.

These utilities may be launched from the Windows® Start menu of any computer where Entrapass Server or EntraPass workstations are installed. For details on EntraPass stand-alone utilities, see *"System Utilities" on page 511*.

## EntraPass Workstation Toolbar

EntraPass windows display most of the following buttons. They are an easy way to access the system functions. Usually, a “hint” is displayed when you move the cursor over an icon. You may access the EntraPass toolbar from any EntraPass workstation window. Icons vary according to the window that is open. Most of the icons are similar to icons you are familiar with and that are used in the computer industry.

Button	Description
	The <b>New</b> button is used to insert new information in the system database. This may be adding a site, a card, a schedule, a controller, etc.
	The <b>Save</b> button saves all the information you have entered since the last save. Information is saved directly in the system.
	The <b>Save As</b> button allows operators to save all of the information of an existing component under a new name without affecting the original component. When using this option while issuing a card, it allows you to create a new card or save under a new card number without having to modify the information of the original card.
	The <b>Delete</b> button is used to delete the currently selected record. As a security against accidental deletion, a warning is displayed prompting you for confirmation. When a component is erased, all links with other items are erased as well. However, the records (archives) are kept in the database after an item is erased.
	The <b>Print</b> button: depending on which menu you are working in, the <b>Print</b> button can be used to print reports, card lists, event parameters, etc.
	The <b>Parent</b> button allows operators to display their search in a hierarchy or to divide searches by gateways, site and controller (according to the menu). This button becomes useful when the system database increases in size; you can find a specific item by selecting its parent items.
	The <b>Link</b> button enables operators to see all instances of an item in other menus. For more information, see <i>"To View Components Links" on page 57</i> .
	The <b>Find</b> button allows operators to find a specific item or component in the system database by using a specific character string. For more information, see <i>"To Find Components" on page 50</i> .
	The <b>Express Setup</b> button allows installers and system administrators to configure system devices by assigning default settings.
	The <b>Close</b> button is used to close a menu or a sub-menu. If you forget to save your information before closing a menu, the system displays a window prompting you to confirm the “save” operation before closing the menu.
	The <b>Cancel</b> button is used to cancel all modifications that were made since the last time a valid save was performed. The system will prompt you to confirm the operation.

Button	Description
 Help	Use the <b>Help</b> button to view the help content on a specific subject.
 OK	The <b>OK</b> button is used to save and accept the modifications, additions or deletions made to a record in the database of the system.
	The <b>Select all</b> button is used to select all the items or components displayed in a list.
	The <b>Unselect all</b> button is used to unselect all the items or components that were previously selected in a list of choices.
	In several system windows, operators have access to graphic and animation buttons. These buttons are particularly useful when you want to display the status of a component before performing an operation on that component. The <b>Enable graphic</b> button is used for example in the Status menu and in the Operations menu. When enabled, this button displays the image related to the selected component (i.e.: door) and displays also the associated components (i.e.: reader). To display components in real-time, this button must be used with the <b>Enable animation</b> button.
	The <b>Enable animation</b> : when enabled, this button automatically enables the <b>Enable graphic</b> button. This activates the current component (i.e.: door) and displays its status in real-time. For example, if you wish to lock a door which was previously unlocked, the reader's image (also visible) will be modified; the green dot will change to red.
Right-click	The <b>Right-click</b> shortcut menus allow operators to enable a shortcut menu from which they can choose a specific command depending on the active menu.

## Basic Functions

Following are the basic system operations:


- Find components
- Select components
- Print lists or reports
- View links between components

### To Find Components

The Find Components function allows operators to find a specific item or component in the system database by using a specific character string.

There are two types of Find Components dialogs: One that can be accessed from any EntraPass window toolbar; One that will be accessed through all the dialogs that pertain to users.


- 1 From any EntraPass window toolbar, click the binoculars button.



- 2 Enter a keyword to start the search. To reduce the search results, check one of the boxes:
  - **Start with:** Results will list all components that start with the text you specify, in alphabetical order, and will include the rest of the list of components available in the database.
  - **Begins with:** Results will list only components that start with the text you specified.



- Contains: Results will list all components that contain the text you specify.




- 3 Click OK. The system displays the list of the components found according to the search string.
  - To cancel a search in progress, click the Cancel button.



**NOTE:** When you select one of the three search options, (Start with, Begin with and Contains), the selection will be selected by default the next time you open this dialog.

## To Find a Card

- 1 From any EntraPass window that pertains to users, click the binoculars button in the toolbar.



- 2 Enter a keyword to start the search. To reduce the search results, check one of the boxes:
  - **Start with:** Results will list all components that start with the text you specify, in alphabetical order, and will include the rest of the list of components available in the database. (refer to the screen on the left in the example below.)
  - **Begins with:** Results will list only components that start with the text you specified. (Refer to the screen on the right in the example below.)
  - **Contains:** Results will list all components that contain the text you specify.
- 3 To display the contents of one of the Card Information field with the results of the search, click the Index icon and select which field you want to display.

- 4 To view the picture that corresponds to the entry selected in the list, click Details. This will open a picture window next to the current dialog.



- 5 Click OK. The system displays the list of the components found according to the search string.
- To cancel a search in progress, click the Cancel button.



**NOTE:** When you select one of the three search options, (Start with, Begin with and Contains), the selection will be selected by default the next time you open this dialog.

## To Use an Extended Selection Box

An extended selection box allows you to view all components of a drop-down list by right-clicking on the list. This option is available where a drop-down list exists for components such as applications, controllers, and doors. If the option is available, a hint box is displayed when the cursor is placed over the drop-down list.


Available text filters in the extended selection box:

- Contains
- Starts with
- Ends with
- Exact word
- Selected


## To Select Components

The Component selection function allows operators to select one or more system components. The method employed may be context sensitive.


- 1 From the active window, click the Select Components button. It opens a secondary window from which you may select appropriate options.
- 2 You may need to check options that are displayed or use the Select All button (left) to select all the displayed options. You may also select Single to view components that are not grouped or select Group to view the existing groups.




- 3 From the displayed list, select the component/group you want to display. You may check the View sub-components option to display the components associated with the selected components.
- 4 Where available, use the Select all button to select all the components, or use the Clear all button to remove the check marks from the selected components. Click Cancel to return to the previous window without any selections or changes.



- 5 Another selection method may be used as displayed in the following Controller Status window. Right click inside the window to display an Extended Selection Box with a complete listing of components.



- 6 Set the required number of columns in the Extended Selection box window to display all components as required. A Text Filter may be employed to limit the listing.



- 7 Click OK to apply selections and return to previous window.

### To Select a Specific Folder

You may need to browse through the network or hard drive to locate a specific folder for backups, for example.

- 1 From the active window, click the Select button (it is identified by "..."). It opens a secondary window from which you may select a specific folder.
- 2 To change the destination folder, browse the Drives drop-down list (lower part of the window). You may click the Refresh drive list to make sure that the displayed list is up-to-date.
- 3 Once you locate the folder you are searching, click OK to go back to the active window.

## To Select a Specific Site or Gateway

Entrapass offers you the ability to associate a specific component with a specific gateway/site. For example, you can define a specific holiday for a specific site or gateway.

- 1 From an active window, click the New icon. The system displays the Select Gateway/Site window.
- 2 Double-click a Site/Gateway from the displayed list then click OK.
- 3 Assign a meaningful name to the component being defined.
- 4 Follow the steps to complete the task.

## To Print

Operators may need the Print function to:

- Print a list of cards
  - Print event parameters
  - Print event-relay association
  - Setup a report for printing
- 1 From any Entrapass window, click the Print icon.
  - 2 Select the components you wish to include in your list. You can use the Select all button (if available) to include all the displayed components in the list.
  - 3 When you select Print empty fields option (if available), the list will include the titles of the fields even if they are empty.
  - 4 When you have finished selecting the fields, you can preview your list before you actually print it. When you preview the list, you can:
    - Define the printer setup
    - Print a hardcopy of your report or list
    - Save the report or list for later use with the Quick Viewer program or load an existing report. For more information on this program, see *"Quick Viewer" on page 543*.
  - 5 If you want to modify the settings, close, modify and print your list.
  - 6 You can use the Font button to select a specific font and font size for your list.
  - 7 To select or modify a font selection:
    - Select the font type from the Font menu. A preview of your selection will be displayed in the Sample box.
    - Choose the formatting attribute from the Font Style menu (regular, italic, bold or bold italic).
    - Enter the font size from the Size menu (10 or 11 is a default). The smaller the font, the more items appear on your list.

- 8 You can also select a color from the Color menu (black is a default). The changes appear automatically in the sample box. Click on OK when you are done. Use the Preview button from the Print window to preview your output before printing.



**NOTE:** If there is no printer configured for the computer, an error message appears.


### To View Components Links

The View links function allows you to view all instances of an item within other menus. Therefore, it is possible to see all links an item has with other items.




**NOTE:** You can use the *View links* button before you delete a component from the database in order to see which menus will be affected by the deletion. You can also print the links of a selected component.

- 1 From any menu window, select a component and click the Link button. All the components that are associated with the selected component are displayed.
- 2 The icons that are located on the left side of the components indicate the component type. For example, if you select the Always valid schedule (in the Schedule definition menu) and click the Link button, the system will display a list of all the menus in which this schedule is used.



**NOTE:** In the highlighted example, the *Always valid* schedule is used as the REX (Request to EXit) schedule in the Door definition menu. You can right-click an item to select a category. For example, if you right-click and select Access levels, only the access levels in which this schedule is defined are displayed.

- 3 To view the links of the selected door with other components of the system, select the door, then click the Link button again:



- 4 All system components that are associated with the selected door appear. In this example, the "door" is used in the Administrator access level; users granted this access level are allowed access to the selected door.
- 5 Click the Print button to print the information displayed on the screen.



## Chapter 4 • System Devices

After the installation of the system hardware and software, you have to configure the access system devices. These include software components (Entrapass applications, Gateways, SmartLink, Redundant Server and Database and Entrapass Video Vault) and physical components (controllers, relays, doors, etc.).



**NOTE:** *It is recommended to use the Express Setup utility to save configuration time and to prevent setup errors. In addition, using Express Setup allows you to test the hardware and wiring immediately after the installation.*

You run the Express Setup utility when you are configuring gateways, sites or controllers for the first time. You may run the Express set up utility by clicking its icon in Entrapass windows. You may also launch the Express Setup utility from the Windows® Start menu or from the System Registration window or from a system prompt, when, for instance, you are adding a controller to your system. For detailed information about using the Express Setup utility, see "Express Setup Program" on page 534.



**NOTE:** *If you are using the Video Integration feature, Entrapass enables you to assign all system components into a video view; the same way you assign them to system interactive floor plans (graphics). To do this, you simply select the video view where you want the system component (Entrapass application, site, gateway, controller, etc.) to appear. Video views are defined in the Video menu (Video tab > Video views).*

---

## Entrapass Applications Configuration

The minimum configuration of an Entrapass software package includes a server, a workstation application (Entrapass monitoring application) and a gateway application.

The gateway application can be integrated with the Entrapass workstation on the same computer.

The software package comprises a number of applications including:

- A workstation application
- A server application,
- One Global Gateway application,
- And a number of utilities such as the Vocabulary editor, the Express Database utility, etc.

It is recommended to install the Entrapass server on a dedicated computer for system stability.


The Entrapass application dialog allows operators to configure computers where Entrapass is installed. This includes configuring computers where you have installed: the Entrapass Workstation software, the Gateways, the Mirror Database and Redundant Server programs, as well as computers where you have installed the SmartLink Interface, if applicable.

To configure the Entrapass applications, you have to define:

- General parameters applicable to all computers where Entrapass is installed
- Security parameters (applicable to all Entrapass applications)
- Filters (to define which gateways and Entrapass applications will send messages to the Workstation application being configured).
- Message/alarm controls.

## To Configure an EntraPass Application

- 1 From the EntraPass main window, select the Devices tab, then click the EntraPass applications icon. The EntraPass applications main window appears.



**NOTE:** Items displayed in the EntraPass application window vary depending on the selected EntraPass application. For example, if the selected application in a workstation-type application, tabs such as *Workstation*, *Gateway and Site*, etc., are displayed. If the selected application is a Redundant server, the *Redundant server* tab appears

- 2 From the EntraPass application drop-down list, select the application you want to configure. This list displays all EntraPass applications that have been installed and registered. The Application type drop-down list displays the type of the selected item. It may display Workstation, Gateway, Redundant Server & Mirror Database, etc.
- 3 Assign a name to the selected EntraPass application. If you are running the software in two languages, for example in English and French, you may assign a name in English and in French.
- 4 Click the save button to activate the new application.

## Defining General Parameters

The General tab allows you to specify the system behavior when the operator is inactive, that is when there is no action on the keyboard (idle time).


- 1 For added security, specify the system behavior when the operator is inactive. This feature provides additional security to prevent access to the system by an unauthorized person. The default delay is 20 minutes. You may keep the default delay or change it.
  - Select the **Send to tray on idle** if you want the EntraPass applications to be minimized when there is no action on the keyboard. If you do this, you have to specify the period after which the application will be minimized if there is no action on the keyboard: in the **Send to tray on**

- idle, enter the delay after which the EntraPass applications will be minimized and sent to the task bar.
- Select the **Automatic Logout on idle** option if you want the EntraPass applications to logout when there is no action on the keyboard. If you do this, you have to specify the period after which the application will be minimized: in the Automatic logout on idle enter the delay after which the Operator will be automatically logged out, (the option has to be checked).
- 2 If the Video feature is enabled, the Video view field appears. If this is the case, select the Video view in which you want the defined component to appear. For details on defining video views, see *"Video Views Definition" on page 162*.
- 3 From the Graphic list, you may select the graphic to which the EntraPass applications is assigned, if applicable. For details on defining graphics, see *"Graphics Definition" on page 217*.

## Defining Security Parameters

This section applies to all EntraPass applications: EntraPass Workstations, Gateways, SmartLink (if installed), Redundant Server & Mirror Database, etc.

- 1 From the EntraPass applications window, select the Parameters tab.



- 2 Make the appropriate choices:
  - **Disable application:** if selected, the operator will not be able to start the application. This field must be used with caution.
  - **Disable authentication to server:** When this option is checked, it is no longer possible to register the EntraPass application to the server.
  - **Encryption:** select this option if all incoming or outgoing messages for this application should be encrypted.
  - **Auto disable authentication:** if selected, the system will automatically disable authentication when the application has authenticated itself for the first time.
  - **Allow auto-connection:** if selected, the EntraPass workstation will automatically attempt to connect itself to the server following a communication failure.


- **Display login list:** if checked, this option tells the system to save the five last login names to make them available for selection when opening new sessions. This option offers a fast way to open a session since an operator has only to select a user name and enter a password. You may however leave this field to its default setting (unchecked) for increased security; this will oblige operators to enter both a valid user name and password before accessing EntraPass.
- **Must be login to close application:** checking this option will oblige operators to login before they exit an EntraPass program.
- **Suspend messages:** if this option is selected, all incoming messages for this EntraPass applications will be suspended. Use this option for an EntraPass workstation that is used only to configure components or when messages are not required.
- **Operator must login at least once to display messages:** checking this option will oblige the operator to login at least once with a valid username and password before system messages can be viewed.
- **Display description in title bar:** check this box to display EntraPass applications description in the window titlebar (top).
- **Display description in taskbar:** check this box to display EntraPass applications description in the window taskbar (bottom).
- **Disable video:** check this option to hide the video view options from this EntraPass workstation user interface. If this option is checked, the Video Events List, Video Playback and Video desktop options are disabled in the system. Operators with appropriate user permissions will be able to configure the Video option but will not be able to view live or recorded video segments.
- **Notify when remote sites must be updated:** check this option to tell the system to send a notification before updating remote sites. When this option is enabled, operators will receive a notification before updating site communicating via a modem. If this option is selected, operators will receive a notification each time data related to sites (such as schedules, controllers, etc.) are modified. They will have the choice of updating remote sites (Yes), refusing the change (No) or clicking Details so that they can select specific sites to be updated.

## Defining Filters

The **Workstation** tab allows you to select which applications will send messages to the workstation application being defined. This feature provides the ability to restrict incoming messages to a computer. For example, you may decide that the application being defined will not receive messages from the SmartLink application. To do so, simply uncheck it (by clicking it) from the list; messages from SmartLink will not be sent to this workstation.


The **Gateway** tab is similar to the Workstation tab but only appears when the selected EntraPass application is a workstation.

## Filters for Incoming Messages from Workstations.



- In the lower pane, select the application that will send messages to the EntraPass workstation being defined. Messages are sent via the EntraPass server.


## Filters for Incoming Messages from Gateways and Sites.



- Select the gateway and site that will send messages to the EntraPass application being configured. The selected gateway/sites send their messages via the EntraPass server.

## Defining Message Controls

- 1 Click the Messages tab to define how messages should be processed when the EntraPass workstation is connected (or not) to the server.



**NOTE:** Messages desktops are configured in the Desktop definition menu. For details, see *EntraPass Desktops* on page 391.

- 2 In the Message control section:
  - Specify the number of messages that will be kept on the server when the EntraPass workstation is off-line, that is, when it is not connected to the server. The server buffers a maximum of 100,000 messages per EntraPass workstation (default: 5,000).
  - Specify the number of messages that will be kept on the workstation. There is a maximum of 100,000 messages per EntraPass workstation. By default, it keeps 5,000 messages.



**NOTE:** The EntraPass workstation will always keep newer events. To view older events, you have to request a historical report. For details on requesting reports, see *Reports* on page 431.

- 3 Specify if the Server should keep newest or oldest messages when its buffer reaches the defined maximum number:
  - **Keep older messages:** The Server will keep the oldest messages and archive the newest messages when the EntraPass workstation is off-line and when the Server buffer is full.
  - **Keep newer messages:** The Server will keep the newest messages and archive the oldest messages when the EntraPass workstation is off-line and when its buffer is full. Messages are processed on a first in - first out basis.

- 4 You may want to create exceptions to the EntraPass workstation configuration by checking **Apply operator parameters for messages** options. When this option is enabled, operator settings have priority over EntraPass workstation settings.



***NOTE:** If the **Apply operator parameters for messages** option is selected all events will be filtered according to the EntraPass workstation configuration, and filtered again according to the security level of the operator who is currently logged on the EntraPass workstation. If the “Apply operator parameters for messages” option is selected and no operator is logged in, or the EntraPass workstation is off-line, events will NOT be buffered by the server.*

- 5 In the **Clear Message Desktops** section, specify when messages should be cleared:
  - On logout (on a regular logout by an operator)
  - On workstation shutdown (when the EntraPass workstation is completely shutdown)
- 6 In the **Picture information** section, select the field content that will be displayed below the cardholder picture. The **Show cardholder information with picture** drop-down list contains 10 definable fields (Card information 1, Card information 2, etc.).




***NOTE:** By default, the field displays “card information #1” to “card information #10”. These labels may be customized. For more information on renaming card information labels, see “To Customize Card Information Fields” on page 263.*

- 7 In the **Status icon refresh delay** section, specify the time interval at which the EntraPass applications refreshes the condition reported by the status icon visible in the status bar. Refresh delays range from 0.01 to 4.59 sec. in increments of 0.01 sec.
- 8 You can define the **Maximum Records in Report Desktop** that can be retrieved from archived files and displayed on screen. The maximum is 200,000.



## Defining Alarm Controls

- 1 Click the Alarms tab to define how alarms should be processed when the EntraPass workstation is connected (or not) to the server.



**NOTE:** Alarms desktops are configured in the Desktop definition menu. For details, see *EntraPass Desktops* on page 391.

- 2 In the Alarm control section:
  - Specify the number of alarms that will be kept on the server when the EntraPass workstation is off-line, that is, when it is not connected to the Server . The Server buffers a maximum of 100,000 alarms per EntraPass workstation (default: 5,000).
  - Specify the number of alarms that will be kept on the workstation. There is a maximum of 100,000 alarms per EntraPass workstation. By default, it keeps 5,000 alarms.



**NOTE:** The EntraPass workstation will always keep newer events. To view older events, you have to request a historical report. For details on requesting reports, see *Reports* on page 431.

- 3 Specify if the Server should keep newest or oldest alarms when its buffer reaches the defined maximum number:
  - **Keep older alarms:** The Server will keep the oldest alarms and archive the newest alarms when the EntraPass workstation is off-line and when the Server buffer is full.
  - **Keep newer alarms:** The Server will keep the newest alarms and archive the oldest alarms when the EntraPass workstation is off-line and when its buffer is full. Alarms are processed on a first in - first out basis.

- 4 You may want to create exceptions to the EntraPass workstation configuration by checking **Apply operator parameters for alarms** options. When this option is enabled, operator settings have priority over EntraPass workstation settings.




**NOTE:** If the *Apply operator parameters for alarms* options are selected all events will be filtered according to the EntraPass workstation configuration, and filtered again according to the security level of the operator who is currently logged on the EntraPass workstation. If the *Apply operator parameters for alarms* options are selected and no operator is logged in, or the EntraPass workstation is off-line, events will NOT be buffered by the server .

- 5 In the Clear Message Desktops section, specify when alarms should be cleared:
  - On logout (on a regular logout by an operator)
  - On workstation shutdown (when the EntraPass workstation is completely shutdown)
- 6 You may define the acknowledgement parameters. Checking **Display alarm message box** will send an acknowledgement message box even if the operator is working in another application. When this option is enabled, you have to enter the delay during which the acknowledgement message box will be suspended. At the end of the delay, an alarm message box will be displayed again requiring an acknowledgement from the operator.
- 7 You can check the **Disable auto display of video views** option to prevent video views from being automatically displayed by this workstation. In fact, video views defined as alarms and associated with components are automatically displayed when the component goes in alarm.
- 8 You may check the option **Send message on acknowledge time-out** to generate an “acknowledge time-out” event when the operator fails to acknowledge an event during the time-out delay specified in the **Acknowledge time-out delay** field. The message will be sent to the Message desktop and the Alarms desktop. For more information on EntraPass desktops, see *EntraPass Desktops* on page 391.

## Defining Network Alarms

Network alarms are setup in the EntraPass applications **Alarm Network** tab.



- 1 Specify whether all the system (network) alarms will be reloaded on startup. System alarms are stored in the server database. If the No reload on startup option is checked, operators will have to manually reload the system alarms.




**NOTE:** Manual reload of the system alarms can be done through the Network Alarms desktop. To do so, open the desktop, right-click on an item and select **Refresh** from the contextual menu. You may want to check this option for fast startup; it is useful when the system has a slow connection.

## Defining e-Mail Report Options

EntraPass offers users the ability to send and to view reports using e-mail capabilities. e-mails can be sent in two formats: report pack files (rpf) and comma separated values (CSV).

- **rpf files:** this file is a compressed report file. It can be opened with a double-click. To view rpf files, users must install a new version of EntraPass Workstation package or the Report Viewer (Set up window) utility found on the installation CD or on Kantech Web site ([www.kantech.com](http://www.kantech.com)).
  - **CSV files:** these files can be viewed using Excel or any text file editor.
- 1 From the EntraPass applications main window, select the E-mail tab.



- 2 In the E-mail server (SMTP or Exchange) field, enter the name of the E-mail server that will be used for sending e-mails.
- 3 In the Port field, enter the number of the port that will be used for sending e-mails (usually 25).
- 4 Enter a valid E-mail address in the From field. This e-mail address will be used for authenticating the e-mail server.



**NOTE:** To view reports sent from EntraPass, the Report Viewer utility must be installed on computers where EntraPass is not installed. To install this utility: Installation CD > Setup window.


## Configuring a Gateway Application

The EntraPass Gateway converts the information received from a controller or a site and transmits the converted data to the server that in turns transmits it to the appropriate EntraPass application. It also converts the information received from the EntraPass workstation and transmits it to controllers. The gateway interfaces the sites and the EntraPass application.

The gateway application allows you to monitor the controller sites connected to the gateway. EntraPass Global Edition installation package includes one Global Gateway. Global, NCC 8000, Corporate Gateways and KT-NCC can be used in EntraPass Global Edition. You may add up to 40 Corporate Gateways, 128 Global Gateways and 128 KT-NCC Gateways to your EntraPass software.

### Configuring General Parameters for a Gateway

- 1 From the EntraPass application drop-down list, select the gateway application you want to configure. When the selected application is a gateway type, the Application type field in the General tab displays "Gateway".



- 2 For details on defining the system behavior on idle, see *"EntraPass Applications Configuration"* on page 60.
- 3 To define security parameters for the gateway application, see *"Defining Security Parameters"* on page 62.

### Configuring an Oracle/MS-SQL HR Interface

The Oracle/MS-SQL HR Interface creates a real-time mirror copy of the EntraPass card databases (Card table, Card group table, Card type table and Badge table) in MS-SQL or Oracle database. In addition, it allows operators to interact with the system card database from their MS-SQL or Oracle programs. Operators can add, modify and delete cards, or obtain card-related information from the EntraPass card database.

The card information is updated in all the databases, whatever the program used to modify or to update the database; MS-SQL HR Interface ensures that the modifications are conveyed to the server and then sent to the workstations.



**NOTE:** The Oracle/MS-SQL Interface requires an additional license.


Make sure that the MS-SQL or Oracle client software is installed on the same computer as the Oracle/MS-SQL HR Interface. It is not recommended to install the Oracle/MS-SQL HR Interface on a computer where EntraPass is installed. Installing the two applications on the same computer may cause problems during data exchange between EntraPass and the Oracle or MS-SQL server.

To configure the Oracle/MS-SQL HR database Interface you have to define:

- General parameters (applicable to the Oracle/MS-SQL HR Database Interface), including the EntraPass application security parameters
- Database parameters, including the database access rights


## Configuring an Oracle/MS-SQL HR Interface

- 1 From the EntraPass application drop-down list, select Oracle/MS-SQL HR Interface.



- 2 Define the application on which you have installed the Oracle/MS-SQL HR Interface. For more details, see *"EntraPass Applications Configuration"* on page 60.
- 3 Select the Parameters tab to define security parameters for the Oracle/MSSQL HR Interface. For details, see *"Defining Security Parameters"* on page 62.

- 4 Select the MS-SQL/Oracle Interface tab to indicate how the EntraPass software will communicate with the client database and to define the database access rights.



- 5 From the Database type drop-down list, select the database server: Oracle 8.0 server, Oracle 7.3 server or SQL server. Be sure to select the correct server version since the database configuration is different from one version to another.



**NOTE:** If the wrong version is selected, the Oracle/MS-SQL HR Interface will not communicate and will not be able to connect to the server.

- 6 Enter the database server name in the Server name field.
- 7 Type the name of the requested Oracle or SQL database in the Database Name field.
- 8 If you are using an Oracle server, type the name of the data file which points to the data you wish to access in the Oracle Data File field.



**NOTE:** Oracle and SQL servers may be configured to contain more than one database. Accessing an SQL database requires pointing to its name while accessing an Oracle database requires pointing to its name and specific data file. Refer to your network administrator for access parameters to the database specific to your application.

- 9 Check the Use administrator Access for Initialization option, if applicable. Checking this option enables you to enter a valid administrator username and password.



**NOTE:** It is important to check this box. If you do not, you must manually create the database, the username and password in the database server.

- 10 Enter the Administrator user name and Administrator password. The program will automatically create the database, username and password in the server database

- 11 In the Database Access area, enter a username and password which will be used by the card gateway to connect to the Oracle/SQL database.



*NOTE: The database access procedure does not allow the card gateway to create or modify an existing user profile on an Oracle/SQL server.*

- 12 Check the Keep deleted records option if you want to keep the record of a card, even when the card is deleted from the EntraPass database. The record will be kept in the Oracle/MS-SQL HR Interface database.



*NOTE: If you do not select this option, deleted records will be physically and permanently erased from the Oracle/MS-SQL HR database.*

*NOTE: When EntraPass creates the card database automatically in the SQL or Oracle Server, it allows a maximum of 50MB for the card database. If you want to increase the size of the database, you must create the database manually, as detailed in the following section.*

## To Create Server Databases Manually

In order to integrate the database with EntraPass, you have to create the database that will be used and then create the Kantech operator in the database. If your system is using an MS-SQL server, proceed as follows:

### Creating the Operator Manually in the MS-SQL/Oracle Server

The first step in integrating MS-SQL/Oracle with EntraPass is to create the database that will be used.

- 1 Right-click the Database folder and select New Database.
- 2 Enter the database name in the Database name field.
- 3 Click OK once you have entered the name of the database.

### Creating the KANTECH Operator for an MS-SQL Server

You have to create an operator that the Oracle/MS-SQL HR Interface will use to log on the MS-SQL server.

- 1 Right-click Logins and select New Login.
- 2 Enter kantech (lower case) in the Name field.
- 3 Make sure that the SQL Server Authentication option is checked.
- 4 Enter kantech (in lower case) as the password in the Password field.
- 5 Click the Database Access tab.
- 6 Check the name of the database created in step 2. When you select this option, the bottom part of the window displays "Database Roles - Permit in database role".
- 7 In order to be able to modify the database, check the Public and db\_owner options and click OK to save and exit. You will be prompted to confirm the password.
- 8 Enter kantech (lower case) and click OK to exit.

## Creating the KANTECH Operator for an Oracle Server

- 1 Log on the ORACLE server as the administrator. Default name "kantech" may be used.
- 2 Create a database. Default database name "KanCard" may be used.
- 3 Create a logon profile. Default username and password "kantech" may be used.
- 4 Assign the kantech operator the permission "Owner".



**NOTE:** If any defaults are changed, there must be a consistent Database name, User name and Password between the Database and EntraPass software.

## To Configure the Mirror Database and Redundant Server

The Mirror Database monitors the communication between itself and the Primary Server. The Mirror Database is a real-time copy of the system database and Windows system registry entries.

When communication between the Mirror Database and the Primary Server fails, the Mirror Database automatically initiates the delay after which the Redundant Server is automatically started to replace the Primary Server.

The Mirror Database & Redundant Server program cannot run on the same computer as the Entrapass software server. The Mirror Database & Redundant Server should be installed on a dedicated computer.




**NOTE:** You can operate the system with more than one Mirror Database & Redundant Server. The Mirror Database & Redundant Server feature requires an additional license.

To configure the Mirror database & Redundant server workstation, you have to define:


- General parameters applicable to the Mirror Database & Redundant Server, including security parameters
- Redundant Server parameters
- Restore parameters
- Security parameters
- KT-NCC parameters



- 1 From the EntraPass application drop-down list, select the Mirror Database and Redundant Server application.



- 2 To define parameters in the General tab, see *"Defining General Parameters" on page 61.*
- 3 Select the Parameters tab to define security parameters for the Redundant Server and Mirror Database. For details, see *"Defining Security Parameters" on page 62.*
- 4 Move to the Redundant Server tab to define communication parameters for the Redundant Server and Mirror Database.



- 5 Select the protocol that is used to communicate with the computer where the Mirror Database is installed: **None**, **TCP/IP** (network server), **NetBEUI** (computer name) or **Automatic**.



**NOTE:** When you select **TCP/IP**, the **Redundant server address** field is enabled to allow you to enter the TCP/IP address of the computer hosting the Redundant Server and Mirror Database. The field can also be edited when you select **NetBeui**.


**NOTE:** If **Automatic** is checked, the IP address of the computer hosting the Redundant Server and Mirror Database will be sent to the server for broadcast to all workstations on the network. This option is particularly useful if you don't know the IP address or if the computer is set to a dynamic IP address or if the computer is connected to a DHCP server.

- 6 Enter the redundant server IP address.
- 7 Select the course of action the redundancy server must take when it cannot connect with the Communication server on startup.
- 8 Specify the options for starting the Redundant Server when the main server shuts down: this may be automatically on a normal shutdown (when an operator shuts down the EntraPass server) or on an abnormal shutdown. The Mirror Database will start the Redundant Server when the delay indicated in the **Wait before start server** field has expired.



**NOTE:** If you do not check the **Start server automatically** option, the **Redundant Server** **will not** start when the primary server is closed under normal conditions (i.e. operator shutdown). Therefore, it will be necessary to start it manually.

- 9 Specify the system's course of action when the server returns to normal (On server restore): enter the delay after which the Redundant Server will be stopped when the primary server returns to its normal functioning. During this time, the Redundant Server will continue to prevail (maximum allowed: 59:59 minutes).
- 10 Move to the **Restore Parameters** tab to define the redundant server's course of action when the main server comes back up after a shut down.



- To automate the restore process from the redundant server, check the Automatic process on restore box. The rest of the options become enabled.
- Check the appropriate boxes depending on the features you have installed, and the restore process you want to activate.




**NOTE:** You can select Restore or Merge.

- **Restore:** Will transfer the whole database that contains all the transactions from the redundancy server to the main server and overwrite any data created on the main server.
- **Merge:** Will only transfer data from the redundancy server when the transactions cannot be found on the main server.



**NOTE:** When using the Merge feature, data will not be transferred in cases where, for example, a card has been modified on the redundant server and the main server simultaneously while the main server was disconnected.

11 Move to the KT-NCC tab to define a public IP address for the KT-NCC, when applicable.



- If you want to activate the Inbound Server Router address, check the box.
- You may enter the Public IP address or the Domain name.

## To Configure the SmartLink

The SmartLink application allows operators to interface the EntraPass access control software with any intelligent device such as video matrix switchers, paging systems, e-mail application, etc., using an RS-232 connection between one of the EntraPass workstations and the external device. Integration with other systems can also be accomplished through software DLLs. SmartLink can be used to connect to another computer to exchange information and update it automatically in real-

time. It also enables EntraPass to receive and send messages, reports or commands, and to communicate with client applications.




**NOTE:** The SmartLink feature requires no additional license.

EntraPass allows you to configure the SmartLink communication mode. For more information on SmartLink and how it works, see your *SmartLink Reference Manual*.


## Configuring SmartLink Connection Options

- 1 From EntraPass application drop-down list, select the system SmartLink application.



- 2 Define the workstation on which you have installed the SmartLink interface. For more details, see *"Defining Security Parameters"* on page 62.
- 3 Configure the SmartLink workstation security parameters. For more details, see *"Defining Security Parameters"* on page 62.

- 4 Click the SmartLink tab to view and setup the SmartLink connection parameters.



- 5 From the Mode enabled drop-down list, select the mode that is used:
- The Unidirectional or Message mode is used to process the contents of instructions that are generated when an event programmed with an instruction occurs. Instructions are defined in the Instruction definition menu and assigned to events in the Event Parameters menu. For details on defining instructions, see *"Instructions Definition" on page 379*.
  - The Bidirectional or Command mode is used to process the requests corresponding to commands received by the serial port or by the network, and to return the appropriate response from the process to the sender.



**NOTE:** When you start the SmartLink application, the connection options for the serial port and network modes are retrieved from the EntraPass Server. If the network connection mode of the SmartLink is different from "none", the SmartLink application will be started to allow a client application to connect to the SmartLink application, either to execute commands or to receive messages sent through the network or both process simultaneously.

- 6 Check the Bypass event parameter preset option if you want to ignore all default settings of the Event Parameter definition menu (System > Event Parameters). By default, all events are programmed to be sent to all workstations (including the SmartLink workstation). Check this option to avoid receiving unnecessary instructions and events that are not intended for the SmartLink application.



**NOTE:** You will have to "manually" create associations of events and instructions in the Event Parameter definition menu. For example, you could select the event "Door forced open" and send only a specific instruction to the SmartLink application that would send an e-mail.

- 7 Click the button to select a SmartLink startup instruction. The instruction you assign will be processed automatically when the SmartLink application is started. For details on defining SmartLink and other system instructions, see *"Instructions Definition" on page 379*.

- 8 To use the SmartLink option with the e-mail service, enter the E-mail server name and port in the E-mail server and port field.



**NOTE:** The e-mail port value is set to 25 by default. You may leave it as is or change this value to another available port on the network (between 0 and 65 535). For information about setting of the e-mail server, contact the network administrator.


- 9 In the SmartLink network connection section, you may want to define the status of messages in the Server.
- 10 In the SmarLink instructions section, you may define startup or default instructions.

## To Configure the EntraPass Video Vault Application

The EntraPass Video Vault application addresses the need for better video data archiving. This application retrieves video segments from the Video Servers connected to EntraPass and saves these video segments for future reference. In fact, video segments can be kept on the video server for a limited period of time. This period depends on the video server disk capacity and settings. In order to take full advantage of the Video Integration capability, EntraPass users who are running a video monitoring software need EntraPass Video Vault to manage their video archive database.


After installing and registering the EntraPass Video Vault application, you must define its environment among other EntraPass applications. For details about registering EntraPass Video Vault, see *"To Add Optional Components/Features" on page 11*. For details about using EntraPass Video Vault, see *"EntraPass Video Vault" on page 518*.

- 1 From the EntraPass Application drop-down list, select EntraPass Video Vault.



- 2 To define General parameters for the EntraPass Video Vault application, see *"Defining General Parameters" on page 61*.
- 3 To define security parameters for the EntraPass Video Vault application, see *"Defining Security Parameters" on page 62*.

- 4 Select Folder tab to specify the video file location and name structure. The settings defined in this window will be reflected in the way the video files will be displayed in the Browse Video Vault window (Video tab > Browse Video Vault).



- **Destination drive(s):** specify the list of drives where video segments will be archived. Video segments will be saved according to the disk space available on the drive and according to order of the selected drives.




**NOTE:** Destination drives that are displayed for selection correspond to the mapped network drives on your computer. They differ from a computer to another.

**NOTE:** By default, drives are listed alphabetically. You may decide to change this order according to the space available on each disk. The up/down green arrows allows you to change the sequence of drives to use for archiving. displayed for selection correspond to the mapped network drives on your computer. They differ from a computer to another.


- **Minimum free disk space (MB):** Enter the minimum free disk space allowed before the system sends a message that there is no more disk space in the EntraPass Video Vault.
- **Disk free space threshold (MB):** Enter the maximum threshold space allowed before the system sends a message that the EntraPass Video Vault has reached its disk space threshold.
- **Date field separator:** You can define the date field separator that will appear in the archived video directory.
- **Destination folder:** select the folder that will be used to archive video data. If you do not specify a target folder, no video segment will be archived. By default, video segments will be archived in C:\KantechVideoArchive folder.
- **Sub-folder structure:** Each combo box contains the criteria that will be used to create a sub-directory where to archive video data. For example, selecting Video Server Name will create a sub-directory for each video server where all corresponding video segments will be stored. If you go down further and select Day-yyyy-mm-dd, another sub-directory will be

created under Video Server Name to store video segments daily. You can go down to 5 levels of sub-directories.

- 5 Select File tab to define the file naming convention.



- **Filename structure:** Check the boxes that correspond to the information you wish to include in the file name.
  - **Separators:** You can define a field separator for the filename as well as data and time.
- 6 Select the Process tab to tell the system how archived video segments will be processed.



- **Default Video file format for your video archives:** You can archive video segments using the KVI, KVA, AVI or IMG formats.



- KVI stands for Kantech Video Intellex format. The KVI file contains thumbnail and video context information and places a watermark on embedded.img. It must be viewed with the Intellex Video Player that uses the American Dynamics API. You must make sure that the API has been installed on the client's computer.
- KVA stands for Kantech Video AVI format. The KVA file contains thumbnail and video context information with no watermark on the embedded .avi. Video files can be viewed using Windows Media Player or any other AVI player on the market.
- AVI stands for Audio Video Interlaced format. AVI video files are viewed using Windows Media Player.
- IMG is the Intellex native format. Video data are stored in Intellex format (.img) and can be viewed using the Intellex Video Player.



**NOTE:** KVI and KVA formats enable users to protect video files with a password and to specify key frames for any selected video event. Key frames offer a fast way for retrieving video segments based on a still image (bmp) representing the whole video sequence.

- Simultaneous video segment transfers: Select the number of simultaneous downloads. You cannot retrieve more than one video segment from one video server at a time. However, it is possible to retrieve more than one segment from more than one video server simultaneously. The minimum value is 1; the maximum is 8.



**NOTE:** A high number of retrievals requires more network bandwidth. As the flow of video data requires a great amount of network bandwidth, contact the Network administrator for these settings.


- Video segment duration-limit: Specify the minimum and maximum duration of the video segment to be archived. Moving the cursor over the editable field will activate a hint indicating the minimum and maximum duration. This feature can prove useful if you want to restrict the number of archived video segments. For example, the restriction can be based on the size of the record. For example, you can tell the system to ignore all video recordings with a duration of less than 10 seconds.
- Default password for KVI and KVA file formats: For increased security, check the box if you want to protect the archived video segments by a password. The KVI and KVA formats add the benefit of protecting your archived data with a password. Make sure to enter identical information in the Password and Password Confirmation fields. Operators with appropriate permission for viewing archived video segments will be required to enter a valid password before viewing the video segment.
- Kantech server polling frequency (m:ss) Using the slide bar to specify how often the Entrapass Video Vault will poll the Entrapass server.



**NOTE:** Keep in mind that network traffic will be affected by the polling frequency between the Entrapass Server, Workstations, Gateways and Video servers. Faster polling means higher network bandwidth use.

- 7 Click the Significant Frame tab to define the key images that will be used as thumbnails to preview video segments in the directories.

- You must select a setup type:



- Significant Frame:** The most representative still image of the video segment. This key image serves as a summary for the video segment. It can be used as a thumbnail, for example, when searching for a specific video segment.
- Significant Frame on Sequence:** This feature is used only with dome cameras where a pattern has been set for the camera to follow and the most representative still image of the video segment must be defined within that pattern.
- Significant Frame on Preset:** This feature is used only with dome cameras where preset positions have been defined. The most representative image of the video segment can be set taking in consideration the time needed by a camera to move from the first frame to the next preset position.
- You can select one of the Default Key Frame types for each significant frame setup type:
  - No image:** there will be no thumbnail for this video segment.
  - First frame:** The video segment will be represented by a still image of the pre-alarm recording. This automatically enables the Delay for Significant Frame (ss:cc) parameter, which is the delay calculated after the first frame to select the thumbnail image that will represent the video segment. Moving the cursor over the editable field will display the min./max. time range admissible.
  - Event Frame:** the video segment will be represented by the image that was captured when the alarm occurred.

## Entrapass Gateways Configuration

Entrapass Gateways convert the information received from a controller or a site and transmit the converted data to the server. Gateways also convert the information received from the server and transmit it to controllers.

Entrapass Global Edition supports three types of gateways: Corporate, NC-8000 and Global. It also supports KT-NCC gateway functionality. All gateways interface the sites and the server. Except for the KT-NCC, the gateways may be installed on a dedicated computer, or integrated with another Entrapass workstation.



***NOTE:** Entrapass Global Edition is shipped with a Global Gateway and KT-NCC Gateway functionality. Additional Gateways (Corporate, NCC 8000 and Global Gateways) require an additional license.*

The following table compares gateway capacities in Entrapass Global Edition:

Capacities	Corporate Gateway	NCC 8000 Gateway	Global Gateway	KT-NCC
Number	40	128	128	128
Local sites	32 sites (serial, 485, TCP-IP)	8 (loops)	32 loops (serial, 485, TCP-IP)	2 x RS-485 1 x RS-232 4 x IP
Dial up modems at host site	32 per gateway	N/A	N/A	N/A
Remote dial up sites	512 per gateway	N/A	N/A	N/A
On-line remote sites	32 per gateway	N/A	32	4 IP with switch/hub
Controllers	17,408 total (32 KT per site)	128 Total (16 per site KT-200 only)	1,024 per Global Gateway (32 KT per site)	128 per KT-NCC (32/COM Port x 3, 8 TCP/IP / site x4)
Readers/keypads per Gateway	34,816	256	2,048	256
Events for timer on/off	30	16	28	28


The following table shows Corporate gateway features:

Capacities	Corporate Gateway
Number	41

Capacities	Corporate Gateway
Local sites	32
Dial up modems at host site	32 per gateway
Remote dial up sites	512 per gateway
On-line remote sites	32 per gateway
Controllers	17,408 total (32 KT per site)
Readers/keypads per gateway	34,816
Events for timer on/off	30

## To Configure a Corporate Gateway

- 1 From the Devices definition tab, click the Gateway icon.



- 2 From the Gateway drop-down list, select the gateway to be configured.
- 3 Under the General tab:
  - Select a Graphic and Video view to which the Gateway is assigned, if applicable. The video view feature will only be activated If the video feature is enabled in Entrapass.


- If your Corporate gateway connects to the first controller of a remote site via modem, click the Host Modem Definition button to configure the modem communication options.

- Click on the New button to add a modem to the modem selection list.
- Configure the modem as per the example entries shown in the previous window and click OK to return to the Device definition window.



**NOTE:** For reliability and configuration consistency, Kantech currently supports the US Robotics Sportster external modem only. Moreover, the *Modem connection type* should be set to *Receive and transmit* while the *Modem settings* should not be changed. If you are uncertain about modem setup parameters, consult your network administrator for the settings which apply to your particular hardware configuration.

- 4 Under the Events tab, set the LED Timer on and Timer off for each event. A Corporate Gateway is configured to manage 30 events.




Events	Timer on (s.cc)	Timer off (s.cc)
1 Access granted	0:80	0:20
2 Access denied	0:05	0:20
3 Time-out on access granted	0:05	0:20
4 Waiting for keypad	0:20	0:20
5 Time-out on keypad	0:05	0:20
6 Bad code on keypad	0:05	0:20
7 Valid floor selection	0:80	0:20



**NOTE:** A Corporate Gateway-based system may support up to 41 Corporate Gateways.

- 5 Under the Keypad delays tab, define keypad options.



Keypad delays	Delays (KT-100 and KT-300 only)
Inter-digit delay (m:ss) 0:05	Invalid attempts before keypad disabled 0
Time-out on keypad (m:ss) 0:10	Keypad disabled duration (h:mm) 0:01
	Reset attempt counter (m:ss) 0:20

- In the Keypad delays section, enter the Inter-digit delay time (m:ss). It represents the maximum delay permitted between each selection of a keypad key by a user.
- Enter the Time-out on keypad delay (m:ss). It is set in seconds. It represents the maximum time allowed for users to begin entering their personal identification number at a keypad.




**NOTE:** The maximum time allowed for both the inter-digit and time-out on keypad delays is 4 minutes and 15 seconds.

- Using the up/down arrows, determine the number of Invalid attempts before keypad disabled. Users have a maximum of 255 invalid attempts before the keypad is disabled.
- Enter the Keypad disabled duration delay (h:mm). The maximum duration allowed is 4 hours: 15 minutes. When the counter reaches the maximum attempts counter, the keypad will be disabled for all cards.
- Enter the Reset attempt counter delay (m:ss). When the delay specified in this field is expired, the system will set the attempt counter to zero. The maximum delay is 4:15 minutes. If the value entered is greater than the maximum allowed, then the system will use the previous correct value.

## To Configure a NCC 8000 Gateway

NCC 8000 Gateway will only work on a dedicated DOS 6.2 computer or Windows 98 with a DOS shell.

- 1 From the Gateway list, select a NCC 8000 Gateway you want to configure.



- 2 Under the General tab:


- Using the up/down arrows, specify the number of controller loops connected to the NCC 8000 computer (maximum 8).



**NOTE:** Under a NCC 8000 Gateway, the system allows a maximum of 16 controllers per site and up to 8 sites per NCC 8000. Only KT-200 with EP-8002 eproms can communicate with a NCC 8000 Gateway.

- Select a Graphic view to which the gateway is assigned, if applicable. The Video View feature will only be activated if the video feature is enabled in Entrapass.


### 3 Move to the Gateway Configuration tab.



- Specify the connection type between the gateway and the NCC 8000 (same computer or separated).
- **RS-232**—If the NCC 8000 Gateway is installed on a dedicated computer, then the link between the NCC 8000 and the Gateway is established through an RS-232 serial link using a selected communication port. If this is the case, you have to specify the serial port as well as the baud rate used by the Gateway computer to communicate with the NCC 8000 Gateway.
- **Integrated with Gateway**—If the NCC 8000/Global Gateways and the software are installed on the same computer, indicate which port is used for the sites.
- If the NCC 8000 is connected using an RS-232, define the RS-232 Gateway Configuration:
  - **Serial Port**—Select the serial communication port used on the computer where the gateway is installed to communicate with an external NCC 8000/Global Gateway.
  - **Baud Rate**—Select the baud rate speed used between the computer where the gateway is installed to communicate with an external NCC 8000/Global Gateway.
- If the NCC 8000 is integrated to the gateway, you have to define the Site RS-232 Configuration in order to specify the COM to which the site is connected. If you select the **Integrated with gateway** option, the **Direct** section is enabled:
  - **Controller loop RS-232 configuration**: select the COM port used for communication. For information about COM ports used by the NCC 8000/Global Gateway, contact your Network Administrator.
  - Check the **View Global Gateway program** checkbox if you want to see the Global Gateway as a program running under Windows. Leave this option unselected to have the Global Gateway running transparently in Windows background.



4 Move to the Auxiliary output configuration tab.




The screenshot shows the 'Gateway' configuration window with the 'Auxiliary output configuration' tab selected. The 'Gateway' dropdown is set to '01 - (1) Global Gateway NCC 8000'. The language selection shows 'English' and 'French' both set to '01 - (1) Global Gateway NCC 8000'. Below the tabs, a table lists 7 events with their respective 'Timer on (s.cc)' and 'Timer off (s.cc)' values.

	Event	Timer on (s.cc)	Timer off (s.cc)
1	Access granted	0:00	0:20
2	Access denied	0:05	0:20
3	Request to exit granted	0:05	0:20
4	Request to exit denied	0:20	0:20
5	Waiting for keypad	0:05	0:20
6	Time-out on keypad	0:05	0:20
7	Bad code on keypad	0:00	0:20

- Set the Timer on and Timer off for each event. A NCC 8000 Gateway is configured to manage 16 events.

5 Move to the Keypad delay tab.



The screenshot shows the 'Gateway' configuration window with the 'Keypad delays' tab selected. The 'Gateway' dropdown is set to '01 - (1) Global Gateway NCC 8000'. The language selection shows 'English' and 'French' both set to '01 - (1) Global Gateway NCC 8000'. Below the tabs, the 'Keypad delays' section contains two input fields: 'Inter-digit delay (m:ss)' set to '0:05' and 'Time-out on keypad (m:ss)' set to '0:10'.

- In the Keypad delays section, enter the Inter-digit delay time (m:ss). It represents the maximum delay permitted between each selection of a keypad key by a user.


- Enter the Time-out on keypad delay time (m:ss). It is set in seconds. It represents the maximum time allowed for users to begin entering their personal identification number at a keypad.



**NOTE:** The maximum time allowed for both the Inter-digit and Time-out on keypad delays is 4 minutes and 15 seconds.


## To Configure a Global Gateway

- 1 From the Devices tab, click the Gateway icon.
- 2 From the Gateway list, select the Global Gateway you want to configure.




- 3 Under the General tab:
  - Use the up/down arrows to enter the **Number of controller loops**. The Global Gateway can physically support up to 8 controller loops.
  - Select a **Graphic** and **Video** view to which the gateway is assigned, if applicable. The **Video** View will only be activated If the video feature is enabled in EntraPass.

4 Move to the Events tab:



- Set the Timer on and Timer off for each event. A Global Gateway is configured to manage 28 events.

5 Move to the Keypad delays tab:



- In the Keypad delays section, enter the Inter-digit delay time (m:ss). It represents the maximum delay permitted between each selection of a keypad key by a user.

- Enter the Time-out on keypad delay time (m:ss). It is set in seconds. It represents the maximum time allowed for users to begin entering their personal identification number at a keypad.



**NOTE:** The maximum time allowed for both the inter-digit and time-out on keypad delays is 4 minutes and 15 seconds.

- Using the up/down arrows, determine the number of Invalid attempts before keypad is disabled. Users have a maximum of 255 invalid attempts before the keypad is disabled.
- Enter the Keypad disabled duration delay (h:mm). The maximum duration allowed is 4 hours: 15 minutes. When the counter reaches the maximum attempts counter, the keypad will be disabled for all cards. It is disabled for the delay specified in the Keypad disabled duration field.
- Enter the Reset attempt counter delay (m:ss). When the delay specified in the Reset attempt counter field is expired, the system will set the attempt counter to zero. The maximum delay is 4:15 minutes. If the value entered is greater than the maximum allowed, then the system will use the previous correct value.

## To Configure a KT-NCC Gateway

Before you start configuring your KT-NCC Gateway, make sure you consult with the Network Administrator to obtain the proper IP address to avoid network conflicts.

For complete information on the KT-NCC, please refer to the *KT-NCC Installation Manual*, DN1611 and the *KT-NCC Quick Configuration Guide*, DN1656.

There are four different network connections you can define and parameters will be setup according to your network architecture.

### **DHCP with Enterprise server IP address:**

Use this type of setup when assigning the company server IP address to communicate between the server and the KT-NCC.

### **DHCP with EntraPass server IP address:**

Use this type of setup when the EntraPass Global Edition server assigns IP addresses, and ONLY when no other DHCP server is connected to the LAN.



**NOTE:** Make sure that the Enable DHCP Server to KT-NCC box is checked in the Server Parameter dialog, under the KT-NCC tab.

### **Static IP address:**

Use this type of setup when you have a dedicated IP address for communicating between the EntraPass server and the KT-NCC.



**NOTE:** The initial configuration will be done through a Web page. Please refer to the *KT-NCC Installation Manual*, DN1611 and the *KT-NCC Quick Configuration Guide*, DN1656.


### **WAN:**

Use this type of setup in an environment where remote sites are protected with routers and they communicate with each other through the Internet.



**NOTE:** Make sure that the Enable DHCP Server to KT-NCC box is checked, the Public IP Address radio button is selected and that the IP address of the inbound router is entered in the Server Parameter dialog, under the KT-NCC tab.

- 1 In the EntraPass Workstation main window, move to the Devices tab and click Gateway.



- 2 In the General tab:
  - Click the down arrow next to the text box marked Gateway and scroll down the selection of gateways until you reach your KT-NCC Gateway. The KT-NCC Gateway will appear along with a number on the right-hand side of the dialog.
  - Select the Number of controller loops in the text box under Loop Configuration. The KT-NCC can physically support 7 controller loops.
  - In the KT-NCC Time Zone configuration area, you must select the appropriate Time zone setting.
  - Check the box underneath it if you want the system to Automatically adjust the clock for daylight saving changes.
  - Select a Graphic and Video view to which the gateway is assigned, if applicable. The Video View will only be activated If the video feature is enabled in EntraPass.

- Move to the Ethernet #1 tab to setup the KT-NCC network connection.

- Enter the KT-NCC MAC address. The first 6 characters in the MAC address (00-50-F9 in the example above) cannot be modified.



**NOTE:** The MAC address can be found on the KT-NCC board, underneath the Ethernet #1 port. It is a 12-digit hexadecimal code, with each two digits separated by a hyphen (that is: xx-xx-xx-xx-xx-xx).

- The following table indicates which parameters to setup depending on your network environment.

Parameter	DHCP Enterprise	DHCP EntraPass	Static IP	WAN
<b>Ethernet Port #1</b>	Checked	Checked	Checked	Checked
<b>Obtain an IP Address Automatically</b>	Selected	N/A	N/A	Selected
<b>Use the Following IP Address</b>	N/A	Selected	Selected	N/A
<b>IP Address</b>	Leave empty	KT-NCC IP Address	KT-NCC IP Address	Leave as is
<b>Subnet Mask</b>	Leave empty	KT-NCC Subnet Mask	KT-NCC Subnet Mask	Leave as is
<b>Gateway (Router)</b>	Leave empty	Leave empty	KT-NCC Gate-way Address	Leave as is
<b>Port</b>	18710	18710	18710	18710

Parameter	DHCP Enterprise	DHCP EntraPass	Static IP	WAN
<b>Enable Broadcast Assignment</b>	Checked	Checked	Checked	Checked
<b>Local IP Address LAN</b>	Leave empty	Leave empty	Leave empty	Leave empty
<b>Public IP Address (LAN/WAN)</b>	Leave empty	Leave empty	Leave empty	Selected and enter IP public address from Server Parameters dialog.
<b>Domain Name (LAN/WAN)</b>	Leave empty	Leave empty	Leave empty	Leave empty
<b>Use Inbound Server Router</b>	Leave empty	Leave empty	Leave empty	Checked




**NOTE:** We strongly suggest that you keep the Port number default value 18710.


- Network Response Time is set to **Average** by default. You can modify it to specify the polling frequency between the EntraPass server and the KT-NCC.

Parameter	Communication Timing
<b>Very fast</b>	Latency period: max 300 ms
<b>Fast</b>	Latency period: max 800 ms
<b>Average</b>	Latency period: max 1500 ms
<b>Slow</b>	Latency period: max 2500 ms
<b>Very slow</b>	Latency period: max 4000 ms
<b>Extremely slow</b>	Latency period: max 6000 ms

- 4 Move to the Ethernet #2 tab when you need a second Ethernet port for setting up IP loops.




- You will select to Obtain an IP address automatically when the server will assign an IP address.
  - You will enter the IP address, Subnet Mask and Router information when you want to use a fixed address.
- 5 Move to the Onboard Relays tab to define the activation event and longevity of any circuit connected to the relay terminals on the KT-NCC board.



- Select the Activation on event parameter for each enabled Onboard relay.
- If the activation is only temporary, make sure that you check the Temporary activation box.
- Enter the related activation period in the Timer fields.




6 Move to the Events tab:



- Set the Timer on and Timer off for each event. A KT-NCC Gateway is configured to manage 28 events.

7 Move to the Keypad delays tab:



- In the Keypad delays section, enter the Inter-digit delay time (m:ss). It represents the maximum delay permitted between each selection of a keypad key by a user.

- Enter the Time-out on keypad delay time (m:ss). It is set in seconds. It represents the maximum time allowed for users to begin entering their personal identification number at a keypad.



**NOTE:** *The maximum time allowed for both the inter-digit and time-out on keypad delays is 4 minutes and 15 seconds.*

- Using the up/down arrows, determine the number of Invalid attempts before keypad is disabled. Users have a maximum of 255 invalid attempts before the keypad is disabled.
- Enter the Keypad disabled duration delay (h:mm). The maximum duration allowed is 4 hours:15 minutes. When the counter reaches the maximum attempts, the keypad will be disabled for all cards. It is disabled for the delay specified in the Keypad disabled duration field.
- Enter the Reset attempt counter delay (m:ss). When the delay specified in the Reset attempt counter field is expired, the system will set the attempt counter to zero. The maximum delay is 4:15 minutes. If the value entered is greater than the maximum allowed, then the system will use the previous correct value.


## Sites/Loops Configuration

A site/loop is composed of controllers attached to the same serial port. The system can manage up to 32 local sites per Corporate Gateway, 8 sites per NCC 8000 Gateway, 7 physical sites/loops per KT-NCC Gateway, and 32 sites per Global Gateway. EntraPass also allows users to add up to 512 remote dial up sites per Corporate Gateway.

Corporate and Global Gateway sites are composed of KT-100, KT-200 and KT-300 controllers. Items displayed in the EntraPass Site/Loop window vary depending on the selected connection type. For example, if the selected connection type is an RS-232, an RS-232 tab will be displayed to configure the corresponding serial port and baud rate. If the connection type is dial-up, three extra tabs will be displayed for modem configuration.

Four types of connections are available: Direct (RS-232 and USB), Enhanced Ethernet (KT-IP), Ethernet (polling) and Dial-Up (RS-232) modem.

- 1 From the Devices window, click the Site/Loop icon.



- 2 Select the Gateway where the site will be configured.
- 3 If you are defining a new site/loop, assign a name to the new site and click the Save icon. The bullet next to the site/loop name will turn green.



**NOTE:** Under Global, NCC 8000 and KT-NCC gateways, site/loops are predefined via the gateway.

- 4 Under the General tab:
  - In the Hardware definition section, specify the number of controllers for the site. There may be up to 32 controllers per site. If the number specified is greater than the maximum allowed, the system will set the value to 32.
  - In the Daylight saving time option section, check the Use Windows daylight saving time setting box to automatically switch to daylight saving time according to Windows standard settings. Leave unchecked if you want to do it manually.

- If you are communicating with a remote site by modem, enter the time difference between gateway location and EntraPass server location in the Time adjustment based on Gateway timezone (h) field. This setting will allow events from the remote site to be displayed at local gateway time on EntraPass workstations located in different timezones.
- Select a Graphic and Video view to which the gateway is assigned, if applicable. The video view will only be activated If the video feature is enabled in EntraPass.
- Use the scroll list to select the Connection type between the computer and the gateway. This will determine which tabs will be displayed for configuration.



**NOTE:** This option is not available for NCC 8000 gateway.

## To Set Up Communication Timing

**Caution:** Do not use the **Communication timing** option. If you need to set up the communication delay and polling frequency, call Kantech Customer Assistance. Inappropriate use of this option may cause serious problems to the system. The Communication timings window shows the actual default settings. They must be preserved unless advised otherwise by Kantech Systems.


Waiting response delays (ms)	
On poll with messages request	500
On poll without message request	312
On poll with a serial number	312
On module state request	1125
On unassigned controller request	1125
On controller state request	1125
On sent messages	1875

Delays	
Controller failure timer (m:ss)	0:10
Poll delay #1 (s.cc)	0.20
Poll delay #2 (s.cc)	0.80
Poll delay #3 (s.cc)	1.00

## To Configure a Direct RS-232 Connection Type

This type of connection can be configured in EntraPass Global Edition for Global and Corporate gateways, as well as KT-NCCs to communicate via a RS-232 gateway.

- 1 When selecting the Direct RS-232 connection type option in the General tab, a RS-232 tab will become available.



- Select the Communication Port COM.
- Select the Controller's loop baud rate. The default rate is 19200 baud.


### To Configure an Ethernet Kantech IP Link Connection Type (Corporate Gateway Only)

This type of connection can be configured in the Entrapass Global Edition for Global and Corporate gateways to communicate via a Kantech IP Link module.



**NOTE:** For complete information on configuring the Kantech IP Link module, please refer to the Kantech IP Link Module Installation Manual, DN1670.

- 1 When you specify Enhanced Ethernet (KT-IP) from the Connection type drop-down list in the General tab, you will be able to access three extra tabs: KT-IP IP configuration, KT-IP Automated connection and KT-IP parameters.



- **MAC address:** Enter the Kantech IP Link module MAC address. The first 6 numbers in the MAC address (00-50-F9) cannot be modified.
- The Online box must be checked at all time.
  - **Obtain IP address automatically:** Check this option when configuring a Kantech IP Link module with a DHCP or automatic address.
  - **Use the Following IP Address:** Check this option when you want to assign a static address to the Kantech IP Link module. When selected the next three parameters will become available.
    - **IP Address:** Kantech IP Link module static IP address that should have been provided by the System Administrator. Make sure that the IP address is unique and belongs to the same segment than the Kantech IP Link module segment (for example: 192.168.0.X, X being the number that differs from the Kantech IP Link module address).
    - **Subnet mask:** This address should have been provided by the System Administrator. Make sure that the subnet mask is the same as the Entrapass Global Edition server.
    - **Gateway (Router):** You will enter the computer gateway address.
- Port 18810 is automatically assigned to the Kantech IP Link module by default. It is advisable not to modify it.
- The Gateway address will be used when in DHCP mode.
  - **IP address:** You will enter the computer gateway address.
  - **Domain name:** If necessary, you will enter the name provided by the System Administrator.

- 2 Move to the KT-IP automated connection tab if you are in a WAN environment.

The screenshot shows the 'Site / Loop' configuration window with the 'KT-IP Automated connection' tab selected. The 'Gateway' is set to 'Corporate Gateway' and the 'Site / Loop' is set to 'Corp Site #1 TCP/IP KT-300 Elevator'. The language is set to 'French'. The 'Broadcast configuration' box is checked, and the 'Local IP address (LAN)' is selected. The 'Public IP address (LAN/WAN)' and 'Domain name (LAN/WAN)' fields are empty. The 'Close', 'Cancel', and 'Help' buttons are at the bottom right.

- In a WAN environment, the **Broadcast configuration** box must be checked at all times.
    - **Local IP Address:** Will assign the Kantech IP Link module IP address automatically.
    - **Public IP Address (LA/WAN):** This IP address should have been provided by your internet provider.
    - **Domain Name (LAN/WAN):** This information should be provided by the System Administrator.
- 3 Move to the KT-IP Parameters tab to configure security and communication parameters.

The screenshot shows the 'Site / Loop' configuration window with the 'KT-IP Parameters' tab selected. The 'Encryption key' is set to 'SDFL32L23KLL5454' and the 'Controller's loop baud rate' is set to '38400'. The 'Delays' section shows 'Heartbeat frequency (mm:ss)' set to '01:00', 'Failsoft delay on gateway communication failure (mm:ss)' set to '01:00', and 'Retry count' set to '3'. The 'Close', 'Cancel', and 'Help' buttons are at the bottom right.

- **Encryption key:** You will enter a 16-digit hexadecimal code to secure your site.

- Controller's loop baud rate: Enter the controller's loop baud rate.



**NOTE:** For KT-200, the maximum baud rate is 19200.

- In the Delay section:
  - Heartbeat frequency (mm:ss): Enter the frequency to which you want the Kantech IP Link module to send a signal to the gateway to indicate it is online
  - Failsoft delay on gateway communication failure (mm:ss): Enter the delay before the gateway will consider the Kantech IP Link module has lost communication.
  - Retry Count: Enter the number of time the gateway should try communicate with the Kantech IP Link module before doing a hard reset.

## To Configure an Ethernet Polling Connection Type

This type of connection can be configured in EntraPass Global Edition for Global and Corporate gateways, as well as KT-NCCs to communicate with the gateway via the network (Lantronix).

- 1 When selecting the Ethernet (Polling) option in the General tab, an IP device tab will become available.

- Enter the terminal server IP address and Port number.
- Select the communication protocol:
  - TCP if the site communicates with the gateway through a terminal server using TCP protocol. In this case, you have to configure the terminal server. To do this, follow the manufacturer's instructions or refer to the Terminal server documentation.
  - UDP (User Datagram Protocol), a connectionless protocol that, like TCP, runs on top of IP networks. UDP offers a direct way to send and receive data over an IP network. It is used primarily for broadcasting messages over a network. Check this option if the site you are configuring uses this protocol.



## To Configure a Dial-Up (RS-232) Modem Connection Type

If you specified Dial-up (RS-232) modem from the Connection type drop-down list in the General tab, you will be able to access three extra tabs: Modem options, Modem schedule parameters and Miscellaneous.



**NOTE:** The Dial-up option is only available when selecting a Corporate gateway.

- 1 Select the Modem Options tab to set outgoing call behavior to site modem.

The screenshot shows the 'Site / Loop' configuration window with the 'Modem options' tab selected. The 'Gateway' is set to 'Corporate Gateway' and the 'Site / Loop' is 'Corp Site #1 TCP/IP KT-300 Elevator'. The 'Remote Baud rate' is 9600. The 'Code to access an outside line' is empty. The 'Remote phone number' is empty. The 'Modem brand' is 'US Robotics sportster 56K'. The 'Modem init settings' are 'AT&F&D2&C1&H0&J0&R1&K0&M0&B1E0V0Q0M0<450=0'. The 'Phone line type' is 'Tone'. The 'Number of rings before answer' is 1, and the 'Number of retries' is 4. The 'Answer on first ring schedule' is empty. The window has 'Close', 'Cancel', and 'Help' buttons at the bottom.



**NOTE:** The Remote Baud rate should not be changed. If you are uncertain about modem setup parameters, consult your network administrator for the settings which apply to your particular hardware configuration.

- Enter the Code to access an outside line (if applicable).
- Enter the Remote phone number.




**NOTE:** For reliability and configuration consistency, Kantech Systems currently supports the US Robotics Sportster external modem only.

**NOTE:** The Modem init settings can not be changed.

- Select the Phone line type: Tone or Pulse.
- Set the Number of rings before answer that will define the number of rings before the modem picks up the call. This option is valid whenever ring schedules are not in effect.
- Set the Number of retries. This will set the number of calls the modem will attempt to make before giving up.
- Set the Answer on first ring schedule option to configure the time interval during which site modem will be allowed to answer on one ring.

- 2 Move to the Modem Schedule parameters tab to set time intervals during which the gateway or site connects to remote sites or gateways (through modem calls) in order to perform specific tasks.



- Click on the Retrieve site events browse button to bring up the schedule selection window. Select the schedule that best corresponds to the time requirements set out for this task. For more information on defining schedules, see *"Schedules Definition" on page 194*
- Repeat this step for If data is modified since last, Report events under priority call type and Report events automatically.
- Define the delay before the system will Fail to report after (mm:ss).



**NOTE:** To schedule the reporting of events under priority call types, first define *Priority call types* for items such as doors, inputs and controllers.

- 3 Click the Miscellaneous tab to configure how modems handle site incoming and outgoing calls.

The screenshot shows the 'Site / Loop' configuration window with the 'Miscellaneous' tab selected. The window has a title bar 'Site / Loop' and a toolbar with icons for file operations. Below the toolbar, there are dropdown menus for 'Gateway' (set to 'Corporate Gateway') and 'Site / Loop' (set to 'Corp Site #1 TCP/IP KT-300 Elevator'). To the right, there are text boxes for 'French' and 'English' languages, both containing 'Corp Site #1 TCP/IP KT-300 Elevator'. The 'Miscellaneous' tab is active, showing several checkboxes and time fields. The 'Use a callback connection' checkbox is checked, with a 'Fail to callback delay (m:ss)' field set to '1:30'. The 'After reception stay online for' checkbox is also checked, with a 'Disconnect line after (hh:mm:ss)' field set to '00:03:00'. Under a 'Miscellaneous' section, two checkboxes are checked: 'Call immediately when slave controller communication failure' and 'Call immediately when buffer 70% full'. A button labeled 'Remote modem delays' is visible at the bottom of the tab. At the very bottom of the window are 'Close', 'Cancel', and 'Help' buttons.

- Check the **Use a callback connection** box to force the gateway modem to hang up after initial connection to the remote site modem and to stand by for an acknowledgement call from the remote modem. You may also want to customize the **Fail to callback delay**. Default is set to 1:30 (1min 30 sec.).
- Select the **Primary host modem** in the drop down list. If available, select a backup modem in the **Secondary host modem**. This setting is useful when the primary modem is busy or fails to take the call.
- Check **After reception stay online for** if you wish to limit in-call time to a predetermined amount of time which can be set to anywhere between 00.03.00 and 23.59.59.
- Check the **Call immediately when slave controller communication failure** to be alerted in the event that a slave controller fails to send data to the master controller (the one carrying the modem).
- Check the **Call immediately when buffer 70% full** to force download of a site controller's event buffer as soon as it reaches 70% capacity.



**NOTE:** Do not click the *Remote modem delays* button. All values are factory-set for optimum performances with the supported US Robotics modems. Settings SHOULD NOT be edited unless recommended by Kantech.

## Controllers Configuration

Controllers provide audiovisual feedback on the access decision. Typically, a red/green light (LED) indicator on the reader informs the cardholder that the door is unlocked or that access has been denied. A local door alarm can be installed to provide an audible warning if the door is forced open or remains open after an access.

The controller definition tells the system how a controller is being used and what devices are associated with it: (doors, input zones, relays and output devices). Controllers may be defined during a gateway or site configuration; or in the controller definition menu, by selecting either the controller icon (Devices > Controller) or by using Express Setup utility.

EntraPass supports three types of controllers: KT-100, KT-200 and KT-300. These provide the ability to activate local functions associated with a controller.

The number of devices associated with a controller varies according to the controller type. The following table summarizes the basic components associated with each type of Kantech controller:

Type	Doors	Relays	Input Zones	Auxiliary Outputs
KT-100	1	4	4	2
KT-200	2	2	16	4
KT-300	2	2	8	4




**NOTE:** NCC 8000 Gateways support only KT-200. Corporate and Global Gateways support all Kantech products (KT-100, KT-200, KT-300). Under a NCC 8000 Gateway, the system allows a maximum of 16 controllers per site and up to 8 sites per NCC 8000. Only KT-200 with EP-8002 EPROM can communicate with a NCC 8000 Gateway. Under Global, KT-200 must be used with EP-Entra3 EPROMs.

### To Configure General Parameters for KT Controllers

- 1 From the Controller definition window, select the gateway associated with the controller site.
- 2 From the Site drop-down list, select the site where the controller is located.
- 3 From the Controller drop-down list, select the controller you want to define. Once selected, the language section is enabled. You may rename the selected controller.

- 4 In the General tab drop-down list, select the KT Controller type.



- Assign a meaningful name to the controller in the language section (English and French in our example), then click the Save icon. Once you save, the Controller type drop-down list becomes disabled.



**NOTE:** If you selected KT-200, a number appears next to the drop-down list. If you move your cursor above that number, a hint will popup to indicate the jumper setup for that KT-200 controller.

- The system prompts you to use the Express Setup program. Click Yes to continue. If you select No you will have to manually configure these devices in their respective definition menus (doors, relays, inputs and auxiliary outputs).



**NOTE:** EntraPass offers you the ability to install two types of readers on the same controller (primary and secondary). The two readers must be of the same technology (Wiegand or ABA). This feature is only available with KT-100, KT-300 and KT-NCC, under Global and Corporate Gateways.

- After configuring components associated with the controller, select the reader and keypad installed on your controller from the Reader and Keypad type drop-down lists.




**NOTE:** The New reader driver icon allows you to install a custom driver for a specific controller. Moreover, using this button allows you to add the driver in the Read Driver table, making it available the next time you want to configure a new controller.

- Use the Disable Controller when you need to put the controller in disable mode. In disable mode, the controller will never be polled and all status requests from this specific controller will send a message that this controller is disabled.



**NOTE:** This option can be used when a controller is removed temporarily but must not be deleted (when under repair, for example). It also allows Operators to easily setup the software before the physical installation is completed.

- Select a Graphic and Video view to which the gateway is assigned, if applicable. The video view will only be activated if the video feature is enabled in EntraPass.
- 5 To define the schedules applicable to the new controller, you must move to the Schedules tab.




- Select the applicable Schedules for the new controller:
    - When a KT-100 or KT-300 is selected: only the Power supervision schedule list is displayed.
    - For KT-200, the Power supervision schedule and the Tamper switch supervision schedule lists are available.
- 6 Click the Save icon.

## To Configure a KT-100 Controller (Corporate Gateway, Global and KT-NCC Gateways)

Once the general parameters are defined, the Controller type tab is displayed.

- 1 Select the KT-100 tab from the Controller window.



- 2 Enter the controller serial number in the Serial number field. Usually, the number is found on the controller label. The field is defined to accept only numeric characters, except for the first character which may be an a or A. If a lower case character is entered, the system converts it to a capital letter.
- 3 Enter the Wait for second access card delay. The maximum time allowed is 2 minutes 07 seconds. This feature is useful for secured areas where two cards are required to access a secured door. If the value entered is greater than the maximum allowed, the system will use the existing value.
- 4 In the Keypad escape key drop-down list, choose a keypad escape key if applicable. This feature is associated with PIN numbers. When a user enters a wrong number, he/she may press the escape key and re-enter the PIN, without incrementing the number of attempts.
- 5 In the Input resistor type drop-down list, select the resistor type used with your system. By default, this choice is set to Single resistor. This feature is used as a supervision device for all inputs. In fact, if this feature is enabled and if an input is disconnected, an alarm message is generated and sent to the Alarm message desktop (or other desktop configured to receive such events).



**NOTE:** For details on defining options for KT-100 controllers, see "To Define Controller Options for Corporate/Global Gateways" on page 122.

## To Configure a KT- 200 Controller

Each KT-200 can monitor, in real-time, the state of 16 input points such as magnetic contacts, motion detectors, temperature sensors, etc. The door contact (supervising door state) and the REX (warning the system that a user is exiting) are connected to such inputs.

The KT-200 is equipped with two relays. These relays can be activated according to schedules, reported events or a combination of different logical conditions. The system is expandable to 16

relays using REB-8 relay expansion board modules. REB-8 may be used as relays or as elevator controllers. KT-2252 are only used as elevator controllers.




**NOTE:** Please note that KT-2252 are no longer available.

## Defining KT-200 Expansion Devices

KT-2252 elevators offer a low voltage interface for up to 32 floors. Up to 4 KT-2252 can be connected to one KT-200 controller for a maximum of 64 floors per cab. One KT-2252 can be shared between 2 cabs, serving a maximum of 16 floors each (one common service switch for both cabs). When users present their cards to the elevator cab reader, the KT-200 verifies which floors can be accessed by this cardholder and sends a list of floors to be enabled to the KT-2252 interface. The KT-2252 closes the electronic interrupters corresponding to the related floors.

## Defining KT-200 auxiliary devices

- 1 From the Controller definition window, select the KT-200 tab.



- 2 In the Auxiliary devices section, select the type of devices used with KT-200 controller.
  - Check the REB-8 relay option if REB-8 expansion boards are used as relays. Only 16 relays can be defined. If two REB-8 are added, the last two relays (the 17th and 18th relays) can be used to perform different actions. You have to specify the additional actions for the two relays in the Extra relay drop-down list.
  - Check the KT-2252 elevator controller and REB-8 relay option if KT-2252 are used as elevator controllers and REB-8 are used as relays on the same door controller. A maximum of four KT-2252 can be connected to the controller.
  - Check the REB-8 Elevator Controller option if REB-8 are used for elevator control. Up to four REB-8 can be used for elevator control.



**NOTE:** When an elevator controller option is checked, an Elevator tab appears beside the KT-200 tab.




The following section explains how to program elevator controls using REB-8 and KT-2252 elevator controllers.

### To Program KT-2252 Elevator Controllers


The Elevator tab allows you to specify which auxiliary devices are used with the KT-200 for elevator control and how they are used. Depending on the expansion board installed and on the option checked, the Elevator window displays the REB-8 Installed or KT-2252 Installed section.

- 1 From the Controller definition window, select the KT-200 tab.



- 2 In the Auxiliary devices section, select KT-2252 elevator controller, or KT-2252 elevator controller and REB-8 relay. The Elevator tab appears beside the KT-200 tab.

- 3 To configure elevator controllers, select the **Elevator** tab. When KT-2252 elevator controllers are used, the **Elevator mode** section is enabled.



- 4 In the **Elevator mode** section, check the appropriate number of floors. This indicates how the floors are controlled with the KT-2252.
  - Select 16 Floors if there is one KT-2252 for two cabs sharing the same floors.
  - Select 32 Floors if there is one KT-2252 per cab.



**NOTE:** The *Inputs* column refers to the KT-2252 terminals. When floors have been defined (in the *Floor* menu), the *Floors* column contains the floors that are associated with the inputs.

- 5 In the **KT-2252 installed** section, specify the number of KT-2252 installed. The options are cumulative. If for example the KT-2252 #3 option is checked, KT-2252 #1 & 2 have to be checked as well. The following table summarizes how KT-2252 elevator controllers are used:

Number of Cabs	Number of Floors	Number of KT-2252
1	8	1
1	16	1
1	32	1
1	64	2
2	8	1
2	16	1
2	32	2
2	64	4

- 6 In the Floors column, select the floors associated with KT-2252 controller terminals.




*NOTE: The Inputs column refers to the KT-2252 terminals. When floors have been defined (in the Floor menu), the Floors column contains the floors associated with the inputs.*


### To Program REB-8 Elevator Controllers

REB-8 relay expansion boards may be used as a cost-efficient alternative for elevator control. With a REB-8 expansion board added to a KT-200, the software may control up to two elevator cabs per controller.

- 1 In the KT-200 definition window, select the REB-8 elevator controller option. When the option is selected, an Elevator tab appears beside the KT-200 tab. The REB-8 definition section is only active when REB-8 are used as relays.



- Select the Elevator tab to configure the REB-8 elevator controllers. Up to four REB-8 elevator controllers are supported.



- Specify the number of REB-8 that are installed on the controller. The selection is cumulative. For example, if four REB-8 are installed, the first three checkboxes have to be checked also. The following table summarizes how REB-8 are assigned to floors and to elevator cabs.

Number of REB-8	Number of Floors	Number of Cabs
1	1 to 8	Cab 1
2	9 to 16	Cab 1
3	1 to 8	Cab 2
4	9 to 16	Cab 2



**NOTE:** The Inputs column refers to the REB-8 terminals. When floors have been defined (in the Floor menu), the Floors column contains the floors that are associated with the inputs.

- In the Floors column, select the floors associated with REB-8 controller terminals. For details on floor definition and door group definition, see "Doors Configuration" on page 126.




**NOTE:** There is no floor confirmation when an REB-8 is used as an elevator controller.

## Defining REB-8 Relays

When REB-8 are used as relays, you need to specify how many relays are installed on the KT-200. The controller can handle a maximum of 16 accessible relays and already provides 2 on-board relays.

- 1 Under the KT-200 tab, select the REB-8 relay option if REB-8 are used as relays.



- 2 If they are used with the KT-2252 elevator controller, select the KT-2252 elevator controller and REB8 relay option. In either case, the REB-8 definition section is enabled.
- 3 In the REB-8 Definition section, select the appropriate option: No REB-8, One REB-8 or Two REB-8.
- 4 If two REB-8 are added (for a total of 18 relays), the last two relays can be used to perform different actions: select the use for the extra relays from the Extra relay drop-down list.



**NOTE:** For details on how to configure other options for KT-200 controllers, see "To Define Controller Options for Corporate/Global Gateways" on page 122.


- 5 Select the Status relay tab to program a relay or group of relays that will be activated when an event occurs.

## To Configure a KT-300 Controller (Corporate, Global and KT-NCC Gateways )

The KT-300 constantly supervises battery condition and reports "Low battery / No battery condition" status to the system. It also supervises locking devices for short and open circuits to detect lock failures.

KT-300 controllers support Combus modules. The Combus is a 4-conductor cable bus to which several expansion modules are connected in parallel to add inputs, outputs, relays and an LCD time and date display.

- 1 From the Site menu, click the Controller icon, then select the KT-300 tab.




- 2 Enter the controller serial number in the **Serial number** field. Usually, the number is found on the controller label. The field is defined to accept only numeric characters, except for the first character. It may be an a or A. If a lower case character is entered, the system converts it to upper case.
- 3 Enter the **Wait for second access card delay**. The maximum time allowed is two minutes and seven seconds. If the value entered is greater than the maximum allowed, the system will use the existing value. This feature is useful when access to a place is controlled by two cards.
- 4 In the **Keypad escape key** drop down list, choose a keypad escape key if applicable. This feature is associated with PINs. When a user enters a wrong number, he/she may press the escape key and re-enter the PIN, without incrementing the number of attempts.
- 5 In the **Resistor type** drop-down list, select the resistor type. By default, the **Single resistor** option is selected. If you hear a long buzz, verify the number of resistors installed on your system.

## To Configure the KT-300 Combus module

Four expansion modules can be connected to KT-300:

- KT-PC4108 (8-zone input expansion module). This module has a tamper contact input.
- KT-PC4204 (4-relay/power supply expansion module). It has a tamper contact input and also includes a built-in 12VDC, 1A power supply for field devices.
- KT-PC4216 (16-zone output expansion module). It can be used for elevator control, although additional hardware may be required.
- KT3-LCD (Kantech 32-character liquid crystal display). The LCD is *green* (normal status), *red* (power failure) and yellow (trouble).

- 1 If a Combus module is installed to the KT-300 controller, click the Combus module configuration button. Undefined Combus terminals are identified by red flags/bullets. Once a module has been defined, it is identified by a green flag.



- 2 To define a module, select one, then click the Define button (lower part of the window). The Enter Combus module serial number message box appears.
- 3 Enter the module's serial number, then click OK.



*NOTE: To obtain this number, you have to activate the Tamper switch or to press any key on the keyboard. The Combus serial number is displayed in the Desktop Message.*

- 4 Assign names to the modules in the language fields.
- 5 Check the options related to the module you want to configure (if these are displayed in the window).




*NOTE: Usage options of a module vary according to the selected Combus module. For example, installing the KT3-LCD and checking the options **Combus low power** and **Display date and time** will allow the KT-300 to report Combus low power conditions and to display the date and time.*

The following table summarizes the options associated with each module:

Combus type	Options	Additional options
KT3-LCD	Combus low power, display date and time	No additional options
KT-PC4108	Tamper alarm, Combus low power	8 input module May be used as inputs

Combus type	Options	Additional options
KT-PC4204	Tamper alarm, Combus low power, Low battery, Power failure, lower auxiliary power	Used as relays (1-4)
KT-PC4216	Tamper alarm, Combus low power	Used as outputs

- 6 Check the Combus low power option so that the KT-300 will report any Combus low power condition
- 7 Check Display date and time option so that LCD can display the date and time; then click the Close button to go back to the KT-300 configuration window.
- 8 When you have finished configuring the Combus module, click the Close button to go back to the KT-300 configuration window.



- 9 Associate a Local activation relay for Power failure, Combus failure and Combus low power (Corporate Gateway only). If you want to assign a specific relay, you may click the three-dot button and select a specific relay or group of relays.



**NOTE:** To configure local activation relay, you must configure relays (*Devices > Relays*), and then select specific relays for local activation.

- 10 Under Priority call type, assign the call type option that best suits failure event reporting (Corporate Gateway only). To access the Priority call type feature, the site connection type must be set to Modem.



**NOTE:** For more information, see "Sites/Loops Configuration" on page 101.

## To Define Controller Options for Corporate/Global Gateways

The Options tab enables operators to configure such features as:




- Anti-passback (for synchronizing entry/exit readers)
- Duress function (for defining a panic button)
- Card count options (for specifying cards in an area), etc.



**NOTE:** The anti-passback option works with entry/exit readers. It allows security administrators to keep track of the number of monitored cardholders in an area. It is local to each controller defined by corresponding entry/exit readers. A relay can be activated when the counter reaches the number of cards defined to be inside the area; the relay is disabled when the number of cards in the area goes below the specified number.

- 1 In the Controller window, click the Options tab to define anti-passback options, duress options and card count options.



- 2 Determine the Duress options. When a duress option is selected, you have to assign a duress key, that is a silent panic key.
  - Duress on access granted: this option enables the duress key when access is granted.
  - Duress on access denied: this option enables the duress key, even when access is denied.
- 3 Select a duress key from the Keypad duress key drop-down list.




**NOTE:** For added security, you may select the two options. The duress option is available on both Corporate and Global Gateways. The anti-passback is available on a Corporate Gateway configuration only.

- 4 From the Anti-passback options section, select anti-passback option from the Type drop-down list: when an anti-passback option is enabled, a card cannot be used on an exit door unless it has been used on a corresponding entry door.
  - None: the anti-passback option is disabled.
  - Soft passback: this option allows a cardholder to use an entry (or exit) reader more than once without using the corresponding exit (or entry) reader. Only an “Invalid passback” event is sent to the Message desktop.

- **Hard passback:** a card used at an entry reader will not be able to access the same entry reader again until it has used the corresponding exit reader.
- 5 In the **Forgive** schedule section, click the three-dot button to set a schedule for resetting the anti-passback option on all other cards.
  - 6 In the **Miscellaneous** section, indicate options for **Fail-soft delays** (10-255 second). During a fail-soft mode, the controller operates in stand-alone mode, following a communication failure.
  - 7 Enter the **32-bit card family code**. You can locate this hexadecimal code on the access card.
  - 8 In the **Card count** option, use the up or down controls to set the maximum card count. The maximum allowed is 65,535. The system keeps track of the number of monitored cards that are in the monitored area and activates a relay when the count is reached. When users exit the area, the counter decrements and the relay will eventually reset when the count is smaller than the value defined.
  - 9 You may configure the system to **Activate a relay** when the maximum count is reached. Click the three-dot button to select the relay or relay group that will be activated when the number is reached.

## Controller Event Buffer Overflow Message

When a controller is disconnected from the server, the controller buffer starts collecting the controller's events. When the buffer is full, it transfers the oldest events in a secondary buffer (50 to 100 bytes) that can contain approximately 5 to 10 events. When this secondary buffer is full, the system then starts sending messages to the Desktop Message List (shown below) to indicate that the buffer is full and that events are being deleted from the buffer.



Sequence	Date and time	Event message	Details
	12/13/2005 3:55:40 PM	Loop communication trouble	NCC Site #3 VC KT-200 Jigs
	12/13/2005 3:55:41 PM	Controller communication restored	VC KT-200 #1 Manual Operation
	12/13/2005 3:55:42 PM	Controller successfully reloaded	VC KT-200 #1 Manual Operation
	12/13/2005 2:19:16 PM	Fail-soft mode on	VC KT-200 #1 Manual Operation
	12/13/2005 2:19:16 PM	Door unlocked by a schedule	NCC Site #3 - VC KT-200 #1 entry, Always valid **
	12/13/2005 2:19:16 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:00119,
	12/13/2005 2:19:20 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:00120,
	12/13/2005 2:19:20 PM	Event buffer overflow	VC KT-200 #1 Manual Operation
	12/13/2005 3:19:20 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03674,
	12/13/2005 3:19:28 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03675,
	12/13/2005 3:19:28 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03676,
	12/13/2005 3:19:28 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03677,
	12/13/2005 3:19:32 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03678,
	12/13/2005 3:19:32 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03679,
	12/13/2005 3:19:32 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03680,
	12/13/2005 3:19:32 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03681,
	12/13/2005 3:19:36 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03682,
	12/13/2005 3:19:36 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03683,
	12/13/2005 3:19:36 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03684,
	12/13/2005 3:19:36 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03685,
	12/13/2005 3:19:40 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03686,
	12/13/2005 3:19:40 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03687,
	12/13/2005 3:19:40 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03688,
	12/13/2005 3:19:40 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03689,
	12/13/2005 3:19:44 PM	Access denied - card unknown	NCC Site #3 - VC KT-200 #1 exit, 00:03690,

- The controller will delete messages in FIFO order (First In, First Out). The oldest message will therefore be deleted first.
- When the controller is reconnected to the server, the controller events will be sent to the Message list all at once, in the following order: events in the controller's secondary event buffer; events displayed in the controller Event Buffer Overflow, followed by the list of events generated while the controller was disconnected from the server.
- In the Message List above, the highlighted error message "*Event buffer overflow*" is the first controller event sent to the Message List.

## Doors Configuration


This menu is used to define the door parameters on which readers and/or keypads are installed. A door can be considered as an elevator door, a Time & Attendance door, an entry door for anti-passback, an exit door for anti-passback or an access door. All this depends on how the settings are programmed.

The controlled door may be secured at all times or only during defined schedules. The common locking devices used are electric door strikes and electromagnetic locks.

A door may be equipped with one or two readers, with one reader at each side. For doors equipped with two readers, the outer reader has to be defined as an entry reader and the inner reader as an exit reader.

### To Define General Parameters for a Door

- 1 In the Devices toolbar, select the Doors icon.



- 2 In the Doors window, select the appropriate Gateway to view the controller sites for a specific gateway, then select a site (from the Site drop-down list) and the controller associated with the door you want to define.
- 3 From the Doors drop-down list, select the door you want to modify or to define. New items are identified with a red button. The button turns green once the item has been defined and saved.
- 4 Specify the Door lock mode: Depending on the lock device used, the locked state will be energized or de-energized to lock.
  - Fail-secure: The strike is locked when power is removed (door locks, door strikes).
  - Fail-safe: The lock output is energized to lock the door (electro magnetic locks).
- 5 Specify the Door type:
  - Access: The reader is considered as an access reader. Time and Attendance or Anti-Passback options are not used with access doors. An access reader generates only "Access granted/Access denied" events.

- **Entry:** An entry door is an entry point for time and attendance or anti-passback. In order for the system to record an entry, the door must be opened after a valid access (if a door contact is installed).
  - **Exit:** An exit door is an exit point for time and attendance or anti-passback. In order for the system to record an exit, the door must be opened after a valid access (if a door contact is installed).
- 6 Specify the Door access delay:
    - **Unlock time:** The time during which the door is unlocked on a valid card read or a valid request to exit event (when the REX is defined to unlock the door). If this is an elevator door and a push button (input) is used to enable floor selection, this is the time during which a floor selection will be allowed. Usually, a longer period should be defined to allow the user to select floors. For more information, see *"To Define an Input for an Elevator Door"* on page 146.
    - **Open time:** The time during which a door can remain opened following a permitted access or a valid request to exit request. This applies only to a door defined with a door contact input. This time can be from 1 to 255 seconds (4 minutes 15 seconds). After this delay has expired, the system will generate the event "door open too long" and the door piezo will sound to warn the cardholder. You can use the Pre-alarm on door open too long (Doors window, Contact tab) to sound the door piezo when half of this delay has expired. It will continue to sound until the door is closed.
  - 7 In the Miscellaneous section:
    - If the door is to be used for time and attendance purposes check the Time and attendance option. With this option the door must be set as either an entry or an exit door.
    - Check the Elevator cab option if the door is to be used for elevator control. When this option is checked, the Elevator tab is displayed to define the unlocking schedules.
  - 8 If you are using the Extended door access delay feature, specify these delays in the Unlock time and Open time fields. This feature may be useful for cardholders with disabilities.
  - 9 When applicable, select an Unlock Schedule.
  - 10 Select a Graphic and Video view to which the gateway is assigned, if applicable. The video view will only be activated if the video feature is enabled in EntraPass.



**NOTE:** Under a Corporate and a Global Gateway, EntraPass offers the ability to program an extended door access delay and to specify specific unlock and open time delays reserved for people with disabilities. In addition to setting this special access delay, the user's access card must be programmed with this feature. Only available with KT-100 and KT-300.


## To Define Door Keypad Options

Doors can be defined with relay activation when the \* or # keys are pressed on the keypad. This option is available only for KT-100 (with firmware version 1.04 and up) and KT-300 (with firmware version 1.16 and up) controllers.



**NOTE:** The *Keypad* tab is enabled only if you have selected a keypad type while defining the controller associated with the door being defined.

- 1 From the Door window, select the Keypad tab.



- 2 Specify how access to the door is controlled:
  - **Reader only:** Select this option if access is granted using a reader. A reader only installation is the most common application.
  - **Keypad only:** Select this option if access is granted using a keypad only. This option can also be enabled on a reader with an integrated keypad. A keypad only installation is generally considered less secure than a reader only installation, because users may “lend” their codes to another person but cannot prevent further use (in comparison to getting a card back).




**NOTE:** This option can be enabled on a reader with an integrated keypad if you want, for instance, to use the keypad only.

- **Reader and keypad:** Select this option if both a reader and a keypad are used to permit access to this door. The keypad will only be used when the “keypad schedule” is valid. Adding a keypad to a reader significantly increases the level of security. PIN code requirement can be limited by a schedule for use only outside business hours, for example, rather than during high traffic hours.
- 3 From the Card and PIN schedule menu, select a schedule during which cardholders will have to enter their PIN after a valid card read. The time allowed between a valid card read and entering the PIN at the keypad is set in the Gateway definition menu (Time-out on keypad option).
  - 4 Check the Enable duress function on keypad option, if desired. (Corporate/Global/KT-NCC doors only)
  - 5 For doors defined with keypad or reader and keypad, you can program the star key (\*) or pound key (#) to activate a relay. When this feature is enabled, users can activate a relay simply by pressing the appropriate key. (This function is only available for KT-100 and KT-300.)

## To Define Door Contact Options

In most applications, the low cost door contact is the only supervisory element that protects the investment made to control access to the door. The door lock and card reader (or keypad) provide security and prevent unauthorized entry only when the door is closed and locked. A simple door contact allows the ability to monitor several door conditions such as: door forced open, door open too long, interlocks options, etc.

- 1 In the Doors window, select the Contact tab.



- 2 Select the door contact from the Door contact list.



**NOTE:** For KT-200 Controllers, Input 1 (door contact) and 2 (request to exit device) are ideally reserved for Door 1 of the controller whereas Input 9 (door contact) and 10 (request to exit device) are ideally reserved for Door 2 of the same controller. The input that is used for the door contact or REX contact **SHOULD NOT** have a “monitoring” schedule defined in the “Input Definition” menu.


- 3 Check the door reading options:
  - **Door open reading**—If selected, this option allows the system to read cards while the door is open. However the system will not unlock the door if it was locked. If selected, the event “Access granted” is generated. Otherwise, the event “Access granted - Door open” is generated.
  - **Door unlocked reading**—If selected, this option allows the system to read cards while the door is unlocked manually by the operator or by a valid unlock schedule. If selected, the event “Access granted - Door unlocked” will be generated on access. To ignore all access events while the door is unlocked, leave this option unselected.
  - **Pre-alarm door opened too long**—If selected, this option allows the system to generate the event “pre-alarm door open too long” and sound the door piezo when half of the delay defined in the Open time field is expired. It will continue to sound until the door is closed.

- 4 Select the appropriate Relock on access option. You may choose to relock an access On door opening or On door closing.

## To Define REX (Request to Exit) Options

A signal from the REX indicates that someone wants to exit through a controlled door. Devices such as motion detectors, push buttons can provide the REX signal. EntraPass enables users to configure doors with unlock time reset each time the primary or secondary REX is triggered. This option is available only for KT-100 (with firmware version 1.04) and KT-300 (with firmware version 1.16) controllers.

- 1 From the door window, select the REX tab, then check the appropriate Relock on Rex options:
  - Relock on door opening, if you want the door device to re-lock following a valid access
  - Relock on door closing, if you want the door device to re-lock when it closes.



- 2 For the primary and Secondary Rex options, make the appropriate choices:
  - Assign the REX contact: the input to which a “request to exit” detector can be connected. This input must be local; it has to be one of the inputs on the controller operating the door.
  - Select a Rex schedule: when this schedule becomes valid, the controller will detect request to exit signals originating for the exit contact. This option applies only to a door defined with a REX contact.
  - Unlock on REX: the door will be unlocked if a valid request to exit is permitted by the controller. This option may be useful on exit doors such as interior doors, shipping doors or other push doors through which people carrying packages may pass. The system will permit the exit and generates the “request to exit granted” event rather than “door forced open” event.
  - Resettable REX function: the unlock time is restarted on a valid request to exit. Open and unlock times are defined in the door definition (Devices > Doors > General). Select this option for high traffic area doors such as manufacturing doors where many users may need



to exit at short intervals (for example after a work shift) to prevent unwanted door open too long or door forced open events.



**NOTE:** It is recommended to choose either *Unlock on REX* or *Resettable Rex function*, not the two options at the same time. If you choose these two options, the door may remain unlocked for long periods of time. Moreover, these features should not be used if a door contact has not been defined.

## To Define Miscellaneous Options

You may define interlock options between two doors to synchronize the time when these two doors are open/closed. The interlock option is also called the mantrap option. This ensures that once the cardholder has accessed the first door, that door is closed and locked before the cardholder is granted access to the second door. The two doors have to be controlled by the same controller.

- 1 In the Doors window, select the Miscellaneous tab.

- 2 From the Doors drop-down list, select the first door for which you want to define interlock options.
- 3 From the Interlock contact list, select the first input for the interlock feature. The selected input has to be the *door contact of the second door*.
- 4 Return to the Doors drop-down list to select the second door for which the interlock options are being defined; then select the interlock input for this second door. It has to be the door contact of the first door.
- 5 Select the Interlock schedule: the two doors must have the same interlock schedule. This is the schedule according to which the interlock is checked by the controller before access is granted to users.



**NOTE:** The interlock feature is not available on doors controlled by a KT-100.


- 6 Check the No lock by input when lock by alarm system armed option when applicable.

- 7 Check the **Unlock door by schedule after first man in** option to unlock the door automatically when a first card is read.
- 8 In the **Shunt on door unlock** section, set the time during which selected inputs will not be monitored when the door unlocks. The **Shunt delay** indicates the time during which the selected inputs will not be monitored when the door unlocks. It is not possible to shunt a door contact since the system will automatically shunt it.
- 9 In the **Shunt inputs** scrolling pane, select inputs that will not be monitored when the door unlocks. Selected inputs will remain unmonitored for the delay defined in the **Shunt delay** field.

## To Define Elevator Doors

During a door definition, it is possible to specify whether it is a “regular door” or an Elevator cab (Door window, General tab, Miscellaneous section). When a door is defined as an Elevator cab, an Elevator tab is displayed in the Doors definition window. This tab is used to define the automatic unlock schedules for specific floor groups.

- 1 From the Doors definition window, select the Elevator tab.



- 2 From the **Unlock schedule #1** list, select the applicable unlock schedule. By default, you may select the **Always valid** schedule. You may also create a new schedule (Definition menu, Schedules).
- 3 From the **Floor group #1** list, select the appropriate floor group associated with the **Unlock schedule #1**. Only floors that have a valid schedule in the **Floor group** definition will be unlocked or available for selection when the **Unlock schedule #1** becomes valid.
- 4 From the **Unlock schedule #2** list, select the schedule applicable to the second group of floors.
- 5 From the **Floor group #2** list, select the appropriate floor group. Only floors that have a valid schedule in the **Floor group** definition will be “unlocked” or available for selection when the **Unlock schedule #2** becomes valid.

*Important Notes:*

- The *Unlock schedule* defined during a door definition (Door menu, General tab) will **OVERRIDE** these schedules even if they are valid.
- Only one *Unlock schedule* can be valid at a time. For example if the first schedule (Unlock schedule #1) is valid from 6h00 to 9h00 and the second schedule (Unlock Schedule #2) is valid from 7h00 to 9h00, then Unlock schedule #2 will **NEVER** be valid since Unlock schedule #1 is already valid.
- Do not overlap schedules. For example, if the first schedule is valid from 8h00 am to 17h00 and the second schedule is valid from 16h00 to 21h00, the gap (between 16h00 and 17h00) can result in erratic operation of the elevator control system.
- Only floors that have a valid schedule in the Floor Group definition will be “unlocked” or available for selection when the unlock schedules become valid.



**NOTE:** For more information on how to program elevator control using REB-8 relays, see "Defining KT-200 Expansion Devices" on page 114.

## To Define a Door Under a Global/KT-NCC Gateway

- 1 Use the Access and Area tab to define dual custody operation, area before/after, and restrictions for the door being defined.

- 2 Check the **Dual Custody** option to enable this feature. Dual custody is used to add extra security to a door by requesting that 2 cardholders must access the door together.
- 3 Define the proper access levels for both cardholders:
  - Select **Access Level #1**, the first access level needed to access the door.
  - Select **Access Level #2**, the second access level needed to access the door.

- Select Privileged Access. This is the access level selected to override dual custody on a door.



**NOTE:** With the Dual Custody feature, cards must be presented in proper order to grant access. Card with Access Level #1 must be presented first then card with Access Level #2 is presented second.

4 Define Area for Anti-Passback.

- Area before— Select the area which will be considered as “area before” when a cardholder presents a card at this door. To disregard anti-passback for this door, leave this field blank.
- Area after— Select the area which will be considered as “area after” access will be permitted to the cardholder. To disregard anti-passback for this door, leave this field blank.



**NOTE:** Usually, doors (or readers) are “shared” between areas, meaning that before accessing a door, a cardholder is considered to be in a certain area (which is called “area before”) and when this cardholder passes the door, he/she is in another area (which is called “area after”).

For example, a cardholder who is in an “Unknown” area and wants to access “Area A”:

- The card holder presents his card at the door reader and wants to access area “A”.
- The system verifies the current location of the cardholder (to verify the current location of cardholder within areas, see the Manual Operation on Areas menu).
- The system then looks in the door definition menu where the cardholder presented his card to see which area is defined as “area before” and “area after” for the selected door reader.
- If area “Unknown” is set as “area before” and “area A” is set as “area after” and the current position of the card holder is “Unknown”, access will be granted.
- If this cardholder's current position would have been in Area B, access would have been denied, since the area before of the reader (door) was set to “Unknown”.


5 Define Timed Anti-Passback by checking Restrict Access box and entering time (mm:ss) for Restrictive Access Delay.



**NOTE:** When cardholders present their cards at this door, they will not be able to present their cards at another reader/door also defined with “restrictive access” until the delay expires.

### To Configure Door Events (Corporate Gateway Only)

- 1 In the Doors window, select the Door events tab. This is to define the relays (or relay groups) that are to be activated on specified events.




- 2 Select the relay that will be activated locally, on such events as: Door forced open, Door open too long or Door alarm on relock.
- 3 Under Priority call type, assign the call type option that best suits event reporting.



**NOTE:** To access the Priority call type feature, the site connection type must be set to Modem. For more information, see "Sites/Loops Configuration" on page 101. The *Priority call type* feature is supported by Corporate Gateways only.

- 4 Once all door event features have been set, select the Access events tab to define relays (or relay groups) that are to be activated on miscellaneous events.



**NOTE:** *Entrapass offers you the ability to define a relay that will be activated if the **Extended delay** feature is used. The card used must be defined with this feature. Only KT-100 and KT-300 can be configured with the **Extended door access delay** feature. This feature is available with Corporate and Global Gateways.*

- 5 Select the relay that will be activated locally, on such events as: Invalid card status, Bad access level, Other access denied, Duress alarm, Access granted and Card traced.
- 6 Under Priority call type, assign the call type option that best suits event reporting.




**NOTE:** *To access the Priority call type feature, the site connection type must be set to Modem. For more information, see "To Configure a Dial-Up (RS-232) Modem Connection Type" on page 107.*

## To Define Options for a KT-100 and KT-300 (Corporate Gateway Only)

Please note that the following options are available with KT-100 or KT-300 controllers only.

- 1 Select the Options and alarm system tab.



- 2 **Motor lock delay:** Enter the time period (minutes:seconds) after which the door will be considered locked. This feature is used in specific applications such as bank vaults to compensate for the slow motor locks. Adding this delay avoids false door forced open alarms if a user is opening the door before it has been completely secured at the end of unlocking delay. The default value is 0:00 for inactive. For example, if this delay is set to 5 seconds and unlocking delay is 20 seconds after access granted; the lock output will deactivate after 15 seconds and no door forced open alarm will be generated if the door is opened during the last 5 seconds.
- 3 If a second card read is required, select a schedule from the Second card schedule required (two-man rule) list.



**NOTE:** When KT-100 and KT-300 are installed in a Corporate Gateway, the system offers the ability to interface an external alarm system.


## To Configure External Alarm System Interfaces (Corporate Gateway Only)

KT-100 and KT-300 offer the ability to interface with any external alarm system. When you add these Kantech controllers to an existing alarm system, cardholders can arm/disarm an existing system, simply by presenting a valid card on an entry/exit door. Adding a keypad will increase the system security since cardholders will be required to enter a PIN in addition to presenting a card. There are five options to arm/disarm or postpone an external alarm system:

- On a valid card read on an arming reader
- On a valid arming code entered on a keypad
- By pressing a button on a keypad
- By pressing a button connected to an input
- By an automatic arming/disarming schedule

There may be a combination of the three options. For example, an alarm system will be disarmed with a correct access code during a valid predefined schedule and after a valid card read.


- 1 Select the External alarm system options button (Door > Options and alarm system tab). The Options and alarm system tab appears when a KT-100 or KT-300 is selected.




- 2 In the Arming request window, select the **Arming request input**. This is the input that is activated on an external alarm arming request. Once you have selected an arming request input, you have to set the schedule during which the request will be valid.
- 3 If applicable, select an arming access level from the list. The **Group** option allows you to select all access levels. Choose **Single** if you want to select a specific level. If the level you want does not appear in the list, you may create a specific level to arm the external alarm system (Users > Access level definition).
- 4 Use the right-click menu to create a new access level.
- 5 To increase the security of your alarm system, check the **Wait for access granted to arm** option. This will oblige the user to present a valid access card before pressing the selected **Keypad button**. You may also check the **Lock door when system armed** option for increased security.
- 6 Specify the **Exit delay** and **Entry delay (h:mm:ss)**. The **Entry delay** is the time during which the alarm system is bypassed after an access granted event. The **Exit delay** is the period before which the system is armed. The maximum values are 9:06:07 for both the exit and entry delays. Usually the entry delay is shorter than the exit delay.
- 7 Select the input that will indicate the status of the external alarm panel. When the selected input status is "normal", this indicates that the external alarm panel is armed.



- 8 Select the **Input** tab to define input devices that will be supervised or shunted (no supervision) when the alarm system is armed. The input description column contains all the inputs that are defined in the system.




- 9 Check the **Supervised** column for inputs that you want to be supervised by the external alarm system; check the appropriate column for input for which you want to suspend supervision (on entry, on exit, or when the alarm system is disarmed).
- 10 Select the **Postpone arming** tab to select the input that will be enabled to postpone arming. Select also the applicable schedule from the **Enable postpone arming schedule**.



- 11 You may check the **Wait for access granted to postpone** option. If this option is checked, the alarm system will be postponed only after a valid card read and the cardholder will then press the selected keypad button to postpone the external alarm system.
- 12 Select the **Postpone or disarm access level** from the list.

- 13 Select the Relay tab to define a relay or a group of relays and input status for the external alarm relays.



**NOTE:** When you select an Alarm relay, you may specify its activation type. It may be activated permanently or temporarily.

- 14 Under Priority call type, assign the call type option that best suits relay activation reporting.



**NOTE:** To access the Priority call type feature, the site connection type must be set to **Modem**. For more information, see "To Configure a Dial-Up (RS-232) Modem Connection Type" on page 107.


## Relays Configuration

The output control relays provided on each KT-100, KT-200 and KT-300 can be used to activate alarms or other devices such as lighting control, ventilation, and air conditioning.

These relays can be activated according to schedules, events reported by the system. They can also be activated to indicate the status of an alarm system or a combination of different logic conditions.

### To Define Relays

- 1 From the Devices definition tab, select the Relay icon.



- 2 Select the Gateway, the Site and the Controller from the displayed drop-down lists, then select the relay for which you want to define settings.
- 3 Specify the Operating mode for the relay:
  - Normal: the relay is normally de-energized (deactivated) until it is energized (activated) by an operator, an event or any other system schedule.
  - Reverse: the relay is normally energized (activated or resting) until it is de-energized (deactivated) by an operator, an event or any other system function.
- 4 Specify the Automatic activation schedule: when this schedule is valid, the relay will be triggered (activated or deactivated) according to the specified activation mode.
- 5 Specify the Disable relay action: when this schedule is valid, the relay will be deactivated (or activated) according to the predefined operating mode. (Corporate/Global Gateway only)




**NOTE:** Under NCC 8000 and Global Gateways, EntraPass offers users the ability to force the Temporary activation timer. In EntraPass Global Edition, the *Force temporary activation* check box appears in the Relay window (*Devices > Relays*). Normally, a relay that is manually activated remains in this state until it is manually deactivated. When this option is checked, the relay will be deactivated by an alarm event, a system event or a schedule.

- 6 Set the Temporary activation timer to indicate the delay during which the relay will be temporarily triggered following a temporary activation.



**NOTE:** When the timer is set to zero, the default activation delay is set to five seconds. Maximum time allowed: 255 seconds (4 minutes 15 seconds).

- 7 Under a NCC 8000 Gateway, you have to set the action for the relay with Activation Mode.



- **Normal**—The relay will not be influenced by the “activation schedule”. The relay will be triggered when necessary (manual operation, event, alarm system, etc.).
  - **Activated**—The relay is permanently activated for as long as the “activation schedule” is valid. In this case, events or other system functions cannot influence the relay, it will remain activated. When the “activation schedule” becomes invalid, the “activated” relay will act in “normal” mode.
  - **Deactivated**—The relay is permanently deactivated for as long as the “activation schedule” is valid. In this case, events or other system functions cannot influence the relay, it will remain deactivated. When the “activation schedule” becomes invalid, the “deactivated” relay will act in “normal” mode.
- 8 Select a Graphic and Video view associated with the relay, if applicable.

## Inputs Configuration


Door controllers can monitor the state of input points such as: door contacts, interlocks, alarm points, motion detectors, temperature sensors, any REX and other devices with dry contacts. KT-100 monitors the state of 4 input points, KT-200 monitors the state of 16 input points, and KT-300 monitors the state of 8 on-board input points, with a maximum capacity of 16.

- For KT-200 only. Inputs are normally closed or normally open dry contacts connected in series with one resistor. If the dry contact is connected in series with the green resistor, the input number will be odd. If the dry contact is connected in series with the red resistor, the input number will be even.
- Input 1 (door contact) and 2 (request to exit device) are ideally reserved for Door 1 of the controller whereas Input 9 (door contact) and 10 (request to exit device) are ideally reserved for Door 2 of the same controller. The input that is used for the door contact or REX contact **SHOULD NOT** have a “monitoring” schedule defined in the “Input Definition” menu.
- For KT-100 Controllers. Input 1 is reserved for door contact while input 2 is reserved for a request to exit device.
- For KT-300 Controllers. Input 1 should be reserved for contact on door 1 while input 2 should be used for request to exit device for door 1 of the controller. Input 3 should be reserved for contact on door 2 while input 4 should be used for request to exit device for door 2 of the controller.

### To Define Inputs Under a Corporate Gateway

You may define Input devices from the Controller definition menu or from the Devices definition window.

- 1 From the Devices definition tab, select the Input icon.



- 2 Select a specific gateway (from the Gateway drop-down list), a site (from the Site drop-down list), a controller (from the Controller drop-down list).
- 3 From the Input drop-down list, select the input you want to define.

- 4 Assign a Monitoring schedule to the selected input: this is the schedule during which the system will supervise the condition of the input. When the schedule is valid, a change in input condition generates either an “Input in alarm” or “Input restore” event.



**NOTE:** The input that is used for the door contact, REX contact or interlock contact **SHOULD NOT** have a monitoring schedule.

- 5 Specify the Normal condition for the input: it may be Closed or Open.
- 6 Specify the Loop response time. This delay is expressed in minutes (mm:ss:cc). The maximum time is 10:55:35 for both the alarm response and alarm restore times.
  - **Response time**—The delay before the system generates the input and alarm event.
  - **Restore site response**—The delay before the system generates the input restore events (Corporate and Global Gateways only).



**NOTE:** Specifying the site response time reduces bouncing when the contact changes state, and helps to generate only one event for each transition if this time is longer than the bouncing time. For example, a 01:00:00 delay requires that a condition remains stable for at least one minute before it is reported.

## To Define Input Under a Global Gateway

- 1 From the Input drop-down list, select an input.

- 2 From the Monitoring schedule list, select one for the input you are defining. You can create a custom one by right-clicking the Monitoring schedule list and selecting new from the shortcut menu.
- 3 If you are configuring a Global Gateway, check **Move to Unknown Area** option to assign input to a push button which can be used by the system security department to move all cards of all sectors to the “Unknown area” if anti-passback is defined in the system. This button can be used when all the personnel have to leave the building due to a fire, for instance. This option

will reset all cards instead of using a manual operation, which can be a long task. (Global gateway only)



**NOTE:** The input's monitoring schedule must be valid.

- 4 Select a graphic in which the input has been assigned.

To Define Relays and Inputs

- 1 Select the Relay and input tab to define which relay(s) or input(s) will be activated or shunted when this input is enabled.



**NOTE:** For the system to process properly the reset delay on a temporary shunt, the *Temporary Shunt Timer* option must be set in the definition of the input that will reset the delay. For example, if *Input 1* will temporary shunt *Input 2*, the *Temporary Shunt Timer* must be specified also in the definition of *Input 2*.

- 2 From the Activate relay list, select a relay or a relay group that will be triggered when this input is enabled.
- 3 In the Resettable activation timer enter the time (hh:mm:ss) during which the relay will remain triggered when this input goes “in alarm”. When the input is restored or returns to normal condition, the relay will deactivate. The Resettable activation timer field appears under a Global Gateway.



**NOTE:** Setting the timer to 0:00:00 will instruct the relay to follow the input's state.

- 4 From the Shunt input list, select the input that will not be monitored when the input being defined is enabled.



**NOTE:** When the input is restored or returns to normal condition, the shunted input will also return to normal condition. The event “Input shunted by input” will be generated by the system. When the input returns to normal condition, the event “Input unshunted by input” will be generated.

- 5 In the Temporary Shunt Timer (h:mm:ss) field, specify the period during which an input is not monitored. Setting the timer to 0:00:00 will instruct the relay to follow the input state. The maximum value for the Shunt delay (h:mm:ss) is 9:06:07. (Corporate or Global Gateway only).



**NOTE:** Under a Global Gateway, users have the ability to define a delay before shunt.

## To Define an Input for an Elevator Door

When the input being defined or edited is used for elevator control, an Elevator tab is displayed in the Input definition window.

You may associate an input to a push button. It can then be used by a guard or by a receptionist to temporarily enable the floors defined in the Floor group activation section.

- 1 In the Input definition window, select the Elevator tab.



**NOTE:** Only the floors marked with an “X” in the State column in the Floor group menu will be available for selection. The system will temporarily enable floor selection according to the delay defined in the Unlock time of the Doors menu. A valid schedule has to be selected (Enable schedule list) for this feature to be activated. It may be necessary to define a door as an elevator cab to access this tab.

- 2 In the Select cab for floor group activation section, select the cab associated with the input.
- 3 Select the Floor group associated with the selected cab, that will be enabled when the input is triggered.



- 4 Select a schedule according to which the defined input will carry out this command.

## To Enable Remote Event Reporting (Corporate Gateway)

- 1 Select the Input event tab.

The screenshot shows the 'Input' configuration window with the 'Input event' tab selected. The configuration is as follows:

Field	Value
Gateway	01 - (2) Corporate Gateway
Site	Security Office Corporate Site
Controller	(01) 01 - Security Office Site K.T-300
Input	(01.01) 01 - 01 - Input Main Entrance

Language settings:

Language	Value
English	01 - 01 - Input Main Entrance
French	01 - 01 - Input Main Entrance

Input event configuration:

Field	Value
Input in alarm	[01.02] 02 - 01 - Main Entrance Relay
Priority call type	Call immediately

- 2 From the Local activation relay list, select a relay or a relay group that will be triggered when this input is in alarm (activated).
- 3 Under Priority call type, assign the call type option that best suits the reporting of the event which triggered the input.



**NOTE:** To access the *Priority call type* feature, the site connection type must be set to *Modem*. For more information, see "To Configure a Dial-Up (RS-232) Modem Connection Type" on page 107.

## To Define an Input for a Group of Doors


This feature allows operators to setup an input that will allow unlocking a group of doors upon an input alarm. This feature can only be setup for groups of doors.



**NOTE:** If you only have one door that you want to setup to unlock upon an input alarm, create a group that will only include that door. To create groups, see *Door Group Creation* on page 333.

When the input being defined/edited is used for a door contact, a Door tab is displayed in the Input definition window.

- 1 In the Input definition window, select the Door tab.



- 2 Select the group of doors that will be unlocked upon input alarm.
- 3 Select action to take once the doors are unlocked
  - Latch will keep the doors unlocked until an operator manually relocks them regardless of the input's state.
  - Follow will keep the doors unlock until someone physically resets the inputs' state. This option is the most appropriate for manual pull stations since they require special tools and/or user intervention to reset the alarm condition.



**NOTE:** This feature is not operational if communication links between the KT-300 door controllers and the Global Gateway are down.

## Output Devices Configuration


Outputs usually control the reader LED and buzzer. There are four outputs available per KT-200 and KT-300 controllers (2 per door). A KT-100 supervises the state of two outputs.

Electrical outputs are configured as open-collector. They provide an open circuit when deactivated (not connected to ground) and are switched to ground when activated.

You may configure Output devices from a controller definition menu or from a gateway window.

### To Define General Options for an Output

- 1 From the Devices configuration window, select the Output icon.



- 2 Select the physical components related to the output: gateway, site, controller for the output.
- 3 From the **Output** drop-down list, select the output you are modifying.
- 4 Specify the **Operating mode** for the output device:
  - **Normal**—The output is switched to ground when it is activated.
  - **Inverse**—The output is an open circuit (not grounded) when it is activated.
- 5 In the **Selected doors** section, select which door will affect the output you are configuring:
  - **Door #1**—Only the first reader port will follow the state programmed for these events.
  - **Door #2**—Only the second reader port will follow the state programmed for these events.
  - **Door #1 and Door #2**—Both reader ports will follow the state programmed for these events.



**NOTE:** This option is not available with KT-100.

- 6 Set the Activation period (m:ss) delay. It defines the activation time in seconds during which the output remains active when it is programmed for a temporary activation. An e will leave the output activated indefinitely, regardless of the activation type.



**NOTE:** If you are using the Video Integration feature, EntraPass enables you to assign all system components into a video view, the same way you assign them to a system interactive floor plan (graphic). To do this, you simply select the video view where you want the system component (Workstation, site, gateway, controller, etc.) to appear.

## To Associate Events with Auxiliary Outputs

System events can trigger auxiliary outputs. You can define how each event will trigger the output.

- 1 Select the Definition tab to associate a door event with an auxiliary output.

Event	Options
Access granted	Steady timed
Access denied	Steady timed
Time-out on access granted	Flash timed
Waiting for keypad	Steady
Time-out on keypad	Flash timed
Bad code on keypad	Flash timed
Valid floor selection	None

- 2 In the Options column, associate an event with an output state.
  - **Steady timed**—The output given this option will not flash, it will remain activated for the specified activation period and will return to normal state when the activation period is over.
  - **Flash timed**—The output will flash and remain activated for the specified activation period and will return to its normal state when the activation period is over.
  - **Steady**—The output given this option will not flash, it will remain activated until it returns to normal condition.
  - **Flash**—The output will flash and remain activated until its condition returns to normal.



**NOTE:** The on-off delays for the outputs are pre-defined during the gateway definition. For details, see "EntraPass Gateways Configuration" on page 85. Events for timer on/off vary depending on the type of the selected gateway. A NCC 8000 Gateway supports 16 events, a Corporate Gateway supports 30 events and an Global Gateway supports 28 events.

## Chapter 5 • Video Integration

EntraPass adds real-time monitoring capability to the Corporate and Global series as a response to the growing importance of video in access control systems. The Video feature allows operators to define Video parameters and use video features from EntraPass Corporate and Global Edition user interfaces.


EntraPass administrators have to define video configuration and viewing parameters including:

- Video servers for use in EntraPass (identifying the video source and specifying cameras connected to it)
- Video views for Video monitoring using EntraPass desktops
- Video recording triggers
- Recording parameters
- EntraPass Video Vault, etc.



**NOTE:** Installing and using the video feature may take a great amount of your company network bandwidth (LAN or WAN). The network administrator may control the use of the network bandwidth for video data transfer.

The following diagram shows how the video feature is integrated in EntraPass. The EntraPass Video Vault utility can be installed on the same computer as any other EntraPass application or on a dedicated computer.



## Video Server Configuration


A video server is connected to EntraPass through a specific IP address. The video server captures, stores and distributes video data to the EntraPass desktops for monitoring and surveillance purposes. Video data can then be accessed by any EntraPass workstation (with appropriate permission) through the network.

In order to use the video feature in EntraPass, the video server must be identified to EntraPass. To do this, you have to:

- Define the video server communication settings
- Specify video parameters including the number of cameras connected to the server
- Set communication delays
- Define parameters for use with EntraPass Video Vault, etc.

### To Define the Video Server Communication Settings

- 1 From the EntraPass main window, click the **Video** tab, then click the **Video server** icon in the Video window toolbar. The Video server window appears with the **General** tab enabled.



- 2 From the Video server drop-down list, select the Video server you want to configure (or click the **New** icon to create a new one), then assign it a descriptive name in the language section. It is recommended to supply a name in the two languages if you are running the application in two languages.

- 3 From the Video Server type drop-down list, select the Video brand for the Video server you are configuring.



***NOTE:** The current version of the software integrates Intellex only. Entrapass supports all version of Intellex, DVMS8000 and DVMS16000, Intellex IP (up to 16 network video streams), Intellex Ultra (16 channels) and Intellex LT. This later version limits the number of cameras to 4, 8 or 16 depending on the selected Intellex LT (LT-4, LT-8 or LT-16). Moreover, a number of features such as the event control are not available on systems running an Intellex LT.*

- 4 Check the On-line option to tell Entrapass that the video server is on-line.



***NOTE:** The **On-line** option must be unchecked when the server is off-line for long periods such as maintenance reasons, for example. Otherwise, Entrapass will continue polling the video server; this may cause the system to hang.*

- 5 In the IP address field, specify the static IP address of the Video server. Make sure that the Video server is set to a static IP address. For specific information about the video server IP address, contact your network administrator.
- 6 Specify the port information for Video, Communication and Events. Make sure that these are the same used by the DVR (Digital Video Recorder).



***NOTE:** The TCP port (Transmission Control Protocol) is used by the Video application to communicate with Entrapass. Options displayed in the TCP port section depend on the device you are configuring. For details about ports and their settings, contact your network administrator or the documentation provided by your Digital Video Recorder (DVR) vendor.*

- 7 Check the Bypass Ping for identification option if you want to save on Network utilization. In fact if this option is not checked, the workstation will continually poll for server identification.
- 8 Check the Specify video server login option if you want users to enter their credentials before accessing the Video server. If this option is checked the Login tab appears in the Video Server window.
- 9 Check the Bypass DVR Messages option if you want to cancel all the messages coming from Intellex.
- 10 In the Video server parameters section:
  - Enter the Number of cameras. The number of cameras connected to the video server (or use the up/down arrows) or click the Import camera details button to get this information from the video server. Using the Import camera details button offers a fast way to define cameras connected to the video server. In fact, when you click this button, Entrapass will connect to the Video server and get the number and default names for cameras connected to the DVR.
  - Specify the Polling frequency (mm:ss). The polling frequency refers to the delay between two polls from the Kantech Server to the Video Server. This operation is processed by the Kantech Video Server Interface.
  - Specify Polls before Communication failure. This refers to the number of unsuccessful polls before the Entrapass Server declares the Intellex server offline. For example, if you enter 4 in this field, Entrapass will attempt to connect four times to the video server before it declares that the Intellex server is down.

- Indicate the Timezone adjustment. Using the up/down arrows, specify the Timezone adjustment if the EntraPass server and the Intellex server are not in the same timezone. The timezone adjustment refers to the timezone difference between the Intellex server and the EntraPass server. Adjusting the timezone enables workstations to retrieve events generated by the Intellex server at the EntraPass Server's time.
- Check the Time for clock synchronization box. The Time synchronization refers to the time of the day when the video server will synchronize with the Kantech server for date and time. This operation is processed by the Kantech Video Server Interface.



**NOTE:** The EntraPass server serves as the reference time source. Intellex server will process the time according to the EntraPass Server's time. For example, if the EntraPass Server's time is 3:00 and that of the Intellex server is 2:00, the Timezone adjustment data will be -1 so that the Intellex server can display the correct information about an event that occurred at a specific time.

## To Enhance the Security of Video Servers

If your Intellex video server is secured by Policy Manager, EntraPass operators must use a specific login and user name to access the video server. In that case, you will check the Specify Video server login box in the General tab.

For details about the video server security parameters, contact the network administrator.

- 1 If the Specify video server login option is checked, select the Login tab that appears.

- 2 Enter the login data in the displayed fields:
  - Domain name: enter the domain name used by the Intellex Video server.
  - Login name: enter the login name used for accessing the Intellex server.
  - Password: enter the password specific to the domain controller.




- **Password confirmation:** the password for confirmation must be identical to the password entered in the previous field. If you get an error message, make sure that the Caps Lock key is activated.

## To Define the EntraPass Video Vault

The EntraPass Video Vault parameters tab allows you to specify settings such as archiving schedule or transfer frequency for EntraPass Video Vault if this application has been activated in EntraPass and has been configured for use within the EntraPass applications.

- For details about installing EntraPass Video Vault, see *"To Add Optional Components/Features" on page 11*.
  - For details about configuring the EntraPass Video Vault application, see *"To Configure the EntraPass Video Vault Application" on page 80*.
  - For details about using EntraPass Video Vault, see *"EntraPass Video Vault" on page 518*.
- 1 From the Video server window, select the Video Vault parameters tab.



- 2 Enter information for the EntraPass Video Vault application:
  - **Video Vault application:** the name of the EntraPass Video Vault application associated with the selected video server.
  - **Archive schedule:** the selected schedule indicates the period during which video segments will be saved. When this schedule is valid, all video segments from user-defined triggers, video server triggers or manual triggers will be saved for archiving purposes.
- 3 Define the Video segment transfer parameters:

- **Transfer interval (hh:mm):** the interval specified in this field indicates the period during which videos segments are retrieved from the video server. This feature restricts data retrieval and the availability of the video server during a specified period of time.



**NOTE:** Intellex allows one video retrieval at a time. If, for instance, the specified period is 02:00 --> 04:00, video segments will be retrieved for two hours per day. If the specified period is 18:00 --> 06:00, this indicates an interval of twelve hours starting from 6:00 PM to 6:00 AM.

- **Notify on transfer failure (days):** this number indicates the number of days allocated for the video retrieval. If a video segment was not retrieved after the number of days specified in this field, the video segment will be considered irredeemable for archiving and EntraPass Video Vault will notify the operator of the failure.
  - **File language:** This option is applicable to KVI and KVA formats only. Users can choose between English and French as the language that will be used to describe the archived data.
  - **Video file format:** select the format for the video file that will be retrieved:
    - **Video Vault default:** this is the format defined for the selected EntraPass Video Vault (Devices > EntraPass Applications > (Select Video Vault application) > Video Vault Process tab).
    - **KVI (Kantech Intellex Video) Format:** The KVI file contains thumbnail and video context information and places a watermark on embedded .img. It must be viewed with the Intellex Video Player that uses the American Dynamics API. You must make sure that the API has been installed on the client's computer.
    - **KVA (Kantech Video AVI) Format:** The KVA file contains thumbnail and video context information with no watermark on the embedded .avi. Video files can be viewed using Windows Media Player or any other AVI player on the market.
    - **AVI (Audio Video Interlaced) Format:** This is the standard AVI format, with no watermark. Video files can be viewed using Windows Media Player or any other AVI player on the market.
    - **American Dynamics IMG Intellex Format:** This format places a watermark on the video. It must be viewed with the Intellex Video Player using the American Dynamics API. You must make sure that the API has been installed on the client's computer.
- 4 For increased security, check the **Use a password for KVI and KVA file formats** option if you want to protect the KVI and KVA archived video segments by a password. Make sure to enter identical information in the **Password** and **Password confirmation** fields. Before viewing video segments archived on the EntraPass Video Vault being defined, operators will have to enter this password. Archived video files can be viewed from the **Browse Video Vault** window.

## Camera Definition

EntraPass offers you the ability to assign names to cameras, presets, and patterns for easy identification in the Video desktop and in all system video events.


The definition of a camera includes identifying its:

- Type (fixed or dome)
- Presets (for dome cameras)
- Patterns (for dome cameras)

The camera name is displayed when viewing live or recorded video events. The default names are *Camera 1* through *Camera n* (where n is the last camera number).

### To Define a Camera

- 1 From the Video window toolbar, click the Camera button. The Camera window appears.



- 2 Select the camera you want to define, then assign it a descriptive name in the enabled language fields. It is recommended to assign a name both in the primary and secondary languages if the system is running in two languages.
- 3 Select the Camera type from the drop-down list.
  - Fixed: no preset/pattern; operators cannot control a fixed camera.
  - Dome: preset and pattern available; selecting this option allows operators to control the camera. If you select this option, assign descriptive names to the camera presets.
- 4 Check the **Show camera** option for the camera to be accessible for selection and display in the Video view desktop. It is important to check this option if you want the camera to be enabled in EntraPass. Only operators with appropriate permission will be able to view a camera with the

Show camera option not checked (Hidden/covert cameras). To assign permission to an operator: System > Operator definition > Privileges.




**NOTE:** If you leave the *Show camera* box unchecked, the camera will not appear in the Video view component window (*Video view > Modify video view components*) and will not therefore be assigned in the Video desktop for view. This feature allows to hide a camera from all view. Operators who do not have appropriate permission will not be able to view, search, export or carry any other operation on a camera for which they do not have access permission. However, all links and references to this camera will be kept. This feature is different from deleting a camera since links to a deleted camera are deleted as well.

- 5 Check the Select specific events option if you want this camera to record specific events. By default all camera events are displayed in the Video Events List. However, you can decide which events will be recorded by a specific camera by checking this option. When you do this, the Event tab appears. You can then select it and select specific events will be recorded by the camera being defined. If this option is checked, you have to select events that will be recorded by this camera.
- 6 Using the Up/down controls, adjust the number of presets and patterns for the selected camera if the selected camera is a dome. When you do this, the Preset or Pattern tabs appear in the Camera window.
- 7 Select the view type you want to display when an alarm occurs.
  - Video View: The video view selected will be displayed when an alarm occurs on this camera.
  - Graphic View: The graphic view selected will be displayed when an alarm occurs on this camera.

## To Define Presets and Patterns

- 1 From the Video server window select the Preset (or Pattern) tab to assign custom names to your presets.



- 2 Select a table cell, then overtype the default name. If you are running the system in two languages, enter the name in both the primary and secondary language, then click Close to close the Preset (or Pattern) window.



**NOTE:** If you select a preset or pattern and click the Default button, the assigned name is replaced by the default name.


## To Define Events Recorded by a Camera

If the Select specific events option is checked, you have to:

- Select events that will be recorded by the camera being defined and that will be sent to the EntraPass Server. This option is disabled when a camera is connected to an Intellex LT DVR.
- Select or define a schedule that will be used by the video server to report selected events to the EntraPass Server. This schedule can be used as a filter to limit the message flow from the Video Server to the Entrapass Server. For instance, choosing an Always valid schedule will send all the selected events to the EntraPass server. Specifying a limited period of time will allow to send events that occurred during a targeted period of time.

## Selecting Camera Events and Schedules


- 1 From the Camera window, select the Event tab. Typical camera events are displayed in the window. These are specific to the selected DVR.



- 2 Select a schedule for camera event reporting. Only events that will be recorded during the specified period of time will be sent to the EntraPass server. Right clicking the Event report schedule field enables operators to create a new schedule or to select an existing one. To define a schedule see *"To Define a Schedule" on page 195*.
- 3 Select camera events that you want to send to the EntraPass server. Specifying events to be sent to the Intellex server is a way of saving on controlling the flow of the video data, and hence

of saving on the company bandwidth. The list of events is specific to the video server. The following list is available on Intellex servers:

- Camera advanced motion alarm: the camera will send any event related to a motion alarm.
  - Camera alarm: the camera will send any event related to a change that occurred in the target area.
  - Camera motion alarm: the camera will send to the EntraPass server all video segment events related to any movement that occurred in the target area.
  - Camera museum
  - Perimeter: the camera will send to the EntraPass server all video segment events related to an object that has crossed into or out of the target area.
- 4 Select the **Video Vault Comment** tab if you want to add information regarding the camera being defined. KVI and KVA file formats from this camera that will be saved in EntraPass Video Vault will be displayed with the comment entered in this window.




- 5 Enter the comment you want to associate with the camera being defined, then save and close the window.

## To Associate a Camera with an Icon

EntraPass offers you the ability to associate a specific icon with a camera for easy identification in the Video desktop and system Graphic.

- 1 From the Camera window, select the camera you want to associate with an icon, then click or double-click the button next to the camera type drop-down list. The Select an icon window opens.



- 2 Choose an appropriate icon to associate with the selected camera, then double-click it to close the window. When you do this, a camera is associated with an icon using the icon index.



**NOTE:** The Camera icon in the Camera window toolbar allows you to add custom icons to the list of available icons. The Add and Delete buttons allow operators to add other icons for selection or to remove icons from the displayed list. The list of icons is displayed when you click the Camera icon in the toolbar.

## Video Views Definition


Once the video server is defined and its cameras identified, operators can define video views that will be displayed in the Video desktop for viewing and monitoring purposes.

EntraPass operators will then call pre-programmed presets and patterns. There is no limit to the number of presets that can be defined in the system.

EntraPass Devices (workstations, gateways, sites, controllers, etc.) can be associated with video views. Later, the video view can be selected in the components definition in order to display the component in the video view.

### To Define General Parameters for a Video View

- 1 Select the Video view button from the Video toolbar. The Video View window appears with the General tab enabled.



- 2 From the Video view drop-down list, select a video view (or click the New icon to create one), then assign it a name in the language section. If the system is running in two languages, you have to give a name in each language.
- 3 From the Default size on video drop-down list, select an appropriate size for the image that will be displayed: you may choose to select a smaller size if you have to display the Video window with another window.
  - Large: 1024x768
  - Medium: 800x600
  - Small: 640x480
  - Tiny: 400x300
  - Last used: displays the size that was previously displayed in the Video desktop.
- 4 From the Default size on graphic drop-down list, select a size for the image that will be displayed on the system graphics (Large, Medium, Small, Tiny, Last used).



- 5 Specify the Refresh rate percentage using the Up/down arrows.



**NOTE:** The Refresh Rate Percentage is related to the image compression/quality. The image quality impacts the system performance: the higher the quality, the lower the compression and the lower the system performance will be. If you set the Refresh Rate to high (> 80), the compression will be low. As result, the application will use a larger network bandwidth. This may result in a slower process. The following table shows the recommended options:

Quality	Description	Result
80 and Over	Super quality	Images are recorded at the highest image quality, using the lowest level of compression. This setting requires the highest amount of storage space and network bandwidth.
60	Normal, Default	Images are recorder at normal image quality. This setting provides a balance between compression and storage space requirements. The smaller, more subtle changers between images are ignored.
40	Low quality	Images are recorded at low image quality, using the highest level of compression. This setting requires the lowest amount of storage space and network bandwidth.

- 6 Check the Re-initialize video view delay (mm:ss) if you want the system to refresh the displayed image. If you check this box, the displayed image will be automatically updated when the specified delay is elapsed. This feature is very useful if the defined camera view includes patterns or presets.
- 7 From the Video control section, make the appropriate choices:
- **Show metrics:** this option enables the system to display the number of frames per second (Fps) and the number of bits per seconds (Bps) for the selected camera. The information appears in the upper section of the Video window (and in the Video desktop).
  - **Show camera controls:** check this option for use with dome cameras. Selecting this option allows operators to control a dome camera. It is not available with fixed cameras.
  - **Show overlay:** check this option if you want the camera identification (camera name and server) to appear in the Video desktop.
  - **Auto-hide text:** if this option is checked, the system will not display the information related to a camera.
  - **Enable camera zoom:** check this option if you want to display the zoom value for the selected camera.



**NOTE:** The Enable video pattern section is enabled once components have been assigned to the video view.

- 8 Check the Enable video pattern box to alternate video images in the Video window. If you have defined a 2X2 view, then the video pattern will be composed of four images alternating in the video display according to the delay specified in the Camera display delay field. If you do not check this option, the video view will display a static image.

- 9 Check Delay before launching sequence (m:ss) box to specify the transition delay before the images start alternating in the Video window.
- 10 Specify the display delays for Cameras, Presets, Patterns and Graphics.




**NOTE:** These delays indicate the time interval during which a video or graphic appears in the Video display before it is replaced by another. Refer to the following table for the minimum/default delays. The maximum delay is 9:59 seconds.

Delay	Minimum (sec.)
Delay before launching sequence	2 seconds
Camera display delay	3 seconds
Preset display delay	5 seconds
Pattern display delay	10 seconds
Graphic display delay	5 seconds



**NOTE:** Select the **Details** tab to view data about the selected view: video servers, cameras, and when applicable, camera presets and patterns.



## Video Views Creation and Modification


Video presets and patterns enable users to perform automatic actions on domes. They are configured for view in the desktop dedicated to Video viewing. They enable to optimize the time dedicated to video viewing when displaying videos using pre-programmed views.

EntraPass enables users to define a wide variety of views, depending on their needs:

- Single camera
- Multiple cameras
- Multiple graphics and cameras
- Server-specific view: these are created by dragging a server into the display
- Multiple video servers: depending on their needs, EntraPass users can create views from multiple video servers.

### To Modify a Video View

- 1 From the Video view window, click the **Modify Video view components** button to edit or create content for the Video view desktop.



- 2 From the left-hand panes, select a camera, a camera preset, or a camera pattern, then drag it into a right-hand pane cell. A camera is identified by its name and corresponding icon. A preset is identified by the camera name and the preset name.



**NOTE:** A specific camera can appear in more than one cell; in this case, the **Enable video sequence option** must be enabled. A graphic can appear only in one cell. You can put cameras from different Video Server but the source must be from the same vendor.

- 3 Click one of buttons in the upper part of the right pane to specify the number of images you want to display:
  - Click 1 X 1 to display 1 image
  - Click 2 X 2 to display 4 images
  - Click 3 X 3 to display 9 images

- Click 4 X 4 to display 16 images.



**NOTE:** You can create a view by dragging a video server into the display. This view will contain all cameras from this specific server.

**NOTE:** The number of the images displayed influence the speed of the network bandwidth. For example, if you are displaying 4X4 images, the network bandwidth will be slower than when you are displaying a 1X1 image.

- 4 Click the Test button to view the result of the selection. The displayed Video view appears in the Video desktop for video monitoring and surveillance (Desktops > Desktop dedicated to video monitoring).



**NOTE:** To delete a camera from a cell, right-click it, then select *Delete* from the shortcut menu.

- 5 Click the Close button (bottom left or the "X" top right) to close the Video test window.

## Video Triggers

Video triggers are system events that start or stop recording. Any event related to the selected component type can trigger recording including exception events originating from a video server. A source component must be specified for each type of triggering event. For example, the “door” component must be specified for the “Door forced” event message. There is no limit to the number of definable video triggers.

### To Define Video Triggers

The following information can be defined:


- Name in two languages
- Component type: type of component to be programmed for the trigger. Events are related to system components: alarm systems, areas, guard tours, gateway, site, controller, etc.

Based on an event that occurred on the selected system component, the trigger will start or stop recording.



**NOTE:** The list of parameters depends on the video server type connected to EntraPass. It can vary depending on server feature availability and decisions on subsequent implementation. All EntraPass events can be associated with the video trigger function.

- 1 From the Video toolbar, select the Video trigger button. The Video trigger window appears.



- 2 Click the new icon (or select an existing trigger if you want to modify one). Assign a descriptive name to the trigger.



**NOTE:** An alert message appears when you attempt to save before selecting the component type as well as the component for the trigger being defined.

- 3 From the Component drop-down list, select the component that will trigger the recording event. It may be a door controller, for example.

- 
- 4 From the Trigger schedule select a schedule for the trigger to be valid. If necessary, you can define a specific schedule for this trigger (Definition > Schedule). If there is no schedule selected for a trigger, the trigger will be disabled.
  - 5 From the Related event list, select the event or events related to the video trigger.

## Recording Parameters

The Recording Parameters menu enables users to define parameters that control video recording and to associate recording parameters (such as video source, cameras, etc.) with a video trigger. For each recording event, you must specify parameters such as the video server source, the camera, etc.

A recording can be stopped by a timer (maximum recording time) or by a trigger when a stop recording trigger is used.

A source component must be specified for each type of triggering event. For example, the “door” component must be specified for the “Door forced” event message. The resulting action (whether to start or stop recording) must also be specified.

EntraPass offers you the ability to associate multiple recording parameters with one trigger. In this case, all recordings will be associated with the single event and it will be possible to save all record segments as a single event recording.


### To Set up Recording Parameters

The Video record window lets you configure how EntraPass Video records videos. You must possess the appropriate privileges to set up this feature.

There is no limit to the number of definable recording parameters. The following information can be defined:

- Name in two languages (for systems in two languages)
- Video source (server and camera)
- Preset and patterns
- Start recording trigger
- Pre-alarm time
- Maximum total recording time, etc.

- 1 From the Video toolbar, click the Recording parameters icon. The Recording parameters window appears, the General tab enabled.



- 2 Click the New icon to create new Recording parameters (or select one from the Recording parameters drop-down list) and assign a descriptive name to the Recording parameters.
- 3 From the Video server pop-up window, select the video server that will be used for the Recording parameters.
- 4 From the Camera drop-down list, select the camera for this Recording parameters.



*NOTE: If the selected camera is a dome, you can specify the preset and pattern name and number. Defining these options allows you to direct the camera to a specific position for recording. However, the pre-alarm time feature may not work well with the preset/pattern option. In fact, the pre-alarm may be triggered when the camera is directed to a location different from the one where the video recording event occurred.*

- 5 From the Start recording trigger pop-up window, select the Video trigger you want to associate with the Recording parameters being defined. The Video trigger pop-up window displays all video triggers defined in the system.
- 6 In the Timings section, specify:
  - Pre-alarm time (m:ss): This option enables users to retrieve from the Intellex server, segment that was recorded before recording was triggered. For example, if a recording was triggered at 2:00 PM and if the Pre-alarm time is 1min. 0 seconds, the record segment will start at 1h 59.
  - Maximum total recording time (m:ss): This options allows you to specify a maximum length for the recording. This includes the pre-alarm time but not the post-alarm recording delay. The maximum allowed is 5 minutes.
- 7 Check the Custom recording rate (fps) option if you want to enable the custom rate option so that EntraPass can override the Intellex image rate settings.



*NOTE: This parameter will have an effect on the DVR only if you previously selected the Use Auto Rate Mode parameter when setting up the Intellex Server parameters. Selecting Use Camera Selectable Rate instead will disable the Custom recording rate parameter in EntraPass.*

- 8 Using the up/down arrows, specify the recording rate for recording parameters. The value you set will be used by EntraPass exclusively for the selected recording parameters. By default, this value is set to 2.5 fps. The average value is 7.5 fps. Below this value, there is no motion. When the value is set to a value grater than 7.5 fps, for example 8.5, there is motion. Adversely, the computer's performance can be affected.




*NOTE: The record rate is defined in frames per second (fps). The frames per second relates to how many pictures it will record in a second. Real time recording is about 30 fps on each camera.*

## To Set Up Stop Recording Parameters

If you want to associate the defined recording parameters with a trigger for stopping recording, check the Stop recording trigger option. If you do this, the Stop recording trigger tab appears in the Recording parameters window.



- 1 From the Recording parameters window, select the Stop recording trigger tab.



- Post-alarm recording delay (m:ss): this delay enables the system to end recording when recording is stopped by an “end recording delay” condition. Moving the mouse pointer over the field shows the value allowed in the field.
- Trigger: select one (or more) trigger(s) that will stop recording.



**NOTE:** You can create new stop recording triggers by right-clicking the triggers display area.

## Video Event List

The Video Event List window displays all video segments recorded in the system and stored in the Video server database as well as video segments archived in EntraPass Video Vault. These video segments can originate from three sources:

- Video triggers
- Manual requests from operators
- Automatic recordings from video servers



**NOTE:** Operators must have access permission to the video server in order to perform operation on events displayed in the Video Event list. For example, if an operator has not been assigned permission to use a specific video server, he/she will not view events originating from this server. User permission are assigned while defining the security level: *System > Security level*.

### To Use the Video Event List


The Video Event List window displays all video events as well as their description. EntraPass operators can:

- Search for a specific event associated with a video segment based on the date and time when the video was recorded
- Play a video segment
- Export the video segment for future consultation
- Stream or copy video segments from EntraPass Video Vault
- Retry all aborted transfers: these are transfers of video segments that were tagged for archive but which were not transferred to EntraPass Video Vault.

### To Find Video Events

Use the Search button to locate and view video segments. The Events tab allows you to filter events. The Options tab allows you to determine the size of the video you are looking for. Appropriate user access rights are necessary for performing this task.

- 1 From the Video Events List, click the Search button. The Find video event window appears.




**NOTE:** If the Menu and Legend buttons are not activated, the window will not show the legend nor the buttons in the lower part.

- 2 From the Find a video events window, select the Start date and time and the End date and time for the video segments you are looking for.




**NOTE:** The Legends button allows you to display a status legend related to video events. The Play and Copy from Video Vault buttons are enabled when the selected video events have already been archived on EntraPass Video Vault.

- 3 Select the video server that you want to include in the search. You can select All video servers if you want to search through all video servers defined in the system.




**NOTE:** If an event was registered by more than one video server, at least one of the servers must be selected for the event to be included in the list.


- 4 Select the Events tab to filter events to be included in the report. You can select All events all check specific events.



- 5 Select the Options tab to filter video segments according to their duration.




- 6 Check the Size filter option, then enter the duration in the Greater than (mm:ss) and Smaller than (mm:ss) fields. The value entered is in minutes and seconds. This feature allows you to target video segments meeting specific duration criteria.
- 7 Select the Archive State tab to filter events according to the archive status.







- 8 Check the Archive state option if you want to specify which events will be included in the filter. If you want to include all events, leave these options unchecked.






9 Click OK to go back to the Video event list window.



*NOTE: The Play and Copy from Video Vault buttons are enabled when the selected video event has been archived on EntraPass Video Vault. Archived events are identified by a green flag.*

10 Do one of the following using the buttons described below:

Button	Use description
 Search	Use this <b>Search</b> button to search for events associated with a video segment. For details, see <i>"To Find Video Events" on page 172</i> .
 Play	Use the <b>Play</b> button to view a video event. When you click this button, the Video desktop displays the video event. If only one camera was used, which is most often the case, the system displays the duration of the video event. If the video event was recorded by more than one camera on a single server, the video server will use the most optimal display layout. If the video event was registered by more than one server, it is possible to select a specific video server. For example, 2x2 for a maximum of 4 camera, 3x3 for a maximum of 9 camera or less and 4x4 for a maximum of 16 cameras. For events with various length, events will be played based on the longer event. Note that this feature shows limitations when used in systems not configured for continuous recording as it will not display cameras involved outside the selected time frame.
 Copy from Vault	The <b>Copy from Vault</b> enables operators to retrieve a video segment that has been archived on EntraPass Video Vault.
 Play from Vault	The <b>Play from Vault</b> enables operators to view a video event that has been archived on EntraPass Video Vault

Button	Use description
	The <b>Retry all aborted transfers</b> button enables operators to trigger any archiving process that was suspended.
	Use the <b>Menu</b> button to display the buttons in the lower part of the window and the <b>Legend</b> button to display a legend about the status of the displayed video recording events.
	The KVI (Kantech Video Intellex), KVA (Kantech Video AVI), IMG and AVI formats are available for your <b>Export</b> needs. These formats allow users to store all the data relative to a video event such as the event icon or key frame, description, etc.
	The <b>Save</b> button is enabled when an operator enters data in the <b>Comment</b> field. It enables operators to save comments associated with a video event.
	The <b>Cancel</b> button is enabled when the <b>Comment</b> field is modified. It enables operators to discard the comment and to go back to the previous value.

## To Play Video Segments

The Video Event List window is divided in two panes: the left-hand pane displays all video events that were retrieved according to the search criteria. The lower pane of the window displays the legend explaining the status of each event. It also contains buttons that enable operators to perform operations on video recordings.

The right-hand pane contains three tabs:


- The **Details** tab displays the text description of the video event such as the video server that recorded the event, the operator who was logged on, etc.
- The **Camera** tab shows cameras that are associated with a selected event.
- The **Image** tab contains the key frame for the video sequence. The key frame serves as preview of the video sequence. It is from this pane that you can associate a video key frame and link it to the video segment.




**NOTE:** Video recordings can be streamed from the left-hand pane (**Play** button) or from the **Camera** tab. You can also view camera recordings from the Message desktop. To do so, you have to select a video recording event (identified by a camera icon in the Message desktop), right-click it and select **View video segment** from the shortcut menu.



- 1 From the Video event list, select an event, then click the Play button. The video clip appears in the Video Playback window.



- 2 You may select the Camera tab to view information about the camera that captured the selected event. To do this, select the Camera tab in the right hand pane to view camera information.



- Start/End dates and time when the recording event occurred.

- **Recording time (mm:ss):** duration of the video segment. This duration is specified when defining recording parameters (Video menu > Recording parameters).
- **Video trigger, if any:** the video trigger is defined in the Video trigger menu and then selected in the Recording parameters definition.



**NOTE:** The status indicator next to the video server name indicates the current connection status of the server.

3 You can:


- Click the **Play** button to view this video segment of the selected camera for the duration of the recording. The video appears also in the Video desktop (Desktop menu)
- Click the **Export** button to export it for future use. For details, see "To Export Video Files" on page 181.

## To Link Video Clips with Key Frames

EntraPass users have the ability to save a still image that best represents a video sequence linking this image to the whole video recording. This may be useful for example if one event was registered by more than one camera and you want to associate the recording with a more explicit image. Viewing the video event will enable users to identify the best image for this video event, to snap it, paste it and save it as the best sequence for the video clip.

It is also possible to retrieve a previously saved image and to link it to a video segment, or to paste a previously snapped image.

1 From the video event list, select an event, then click the Image tab (right pane).



2 From the image window, you can:

- **Import image:** click the Import button to retrieve a previously saved or exported image from a file.
- **Paste image:** click this button to paste a previously snapped image. The Paste image button is enabled only when you have snapped (copied) an image while viewing it. You can first play a video clip, snap it and then paste it.
- **Clear:** click the clear button to delete the displayed image from view.

To Export Video Files


EntraPass exports video segments in four formats: KVI and KVA.

- **KVI (Kantech Video Intellex format).** Video data are stored in Intellex format (.img). A simple double-click allows you to view the file using VideoPlayerIntellex.exe.
- **KVA (Kantech Video AVI format).** Video data are stored in AVI format (.avi). A double click opens the video file using VideoPlayerWindow.exe.
- **AVI format**
- **IMG format**

EntraPass users have two options when exporting videos:

- From the Video event list (without previewing the video)
- From the video playback window: in this case, the video is previewed before it is exported.

1 From the video event list, select the video event you want to export.



2 Click the Export button. The Enter a video filename window opens.

- 3 Enter a file name in the File name field. By default, the file is assigned the Kantech KVI format. The file will be saved among EntraPass program files: \Kantech\Server-GE\Video. Later you can call this file simply by double-clicking it.



**NOTE:** Video files can be viewed in the View exported videos window (*Video tab > View Exported video*). The video file is displayed with its name, date and time. Key frames (if any) associated with a video clip can also be previewed in this window.

- 4 Click Save to close the Enter filename window. When you do this, the Description and password window appear.


## To Protect a Video with a Password

You can protect exported videos using a password. Users must enter this password to view exported videos.




**NOTE:** The password protection is applicable to KVI and KVA video formats only.

- 1 Select the video you want to export, then click the Export button.



- 2
- Enter a description for the video segment, in the Enter Video filename window, then click Save. The Description and password window appears.



- 3
- Check the Use password box if you want to add more security to this video segment. Users will have to enter this password in order to view the saved video segment.
- 4
- Enter a password and confirm the password in the displayed field.
- 5
- Click OK to close the Description and password window. Click OK to close the system message confirming the export.


## Video Playback

The Video Playback feature offers the ability to view recorded video one camera at a time. To do so, you have to specify the period of time for the playback. A maximum of one hour is allowed. To do so:

- Select a camera in the left-hand pane
- Drag and drop it into the View playback area.

### To View a Video Playback

- 1 From the Video playback window, specify the Start date and time and End date and time for the video you want to view. The maximum allowed is 1 hour. Therefore you may stream video events that occurred on the same date and for a maximum of one hour.



- 2 From the left-hand pane, select a camera then drop it into the right pane. It plays for the time specified in the start and end time. Use the controls in the lower part of the Playback window (right pane) to play, fast forward, rewind or stop the video playback.



**NOTE:** If the requested video is not available, a message appears in the lower part of the window; the **Snap** and **Export** buttons remain disabled. If a video is available, the message **Requesting video is displayed**.

- **Snap:** copy the displayed image and save it in the \tmp\image folder and use it as a still image representing the video sequence. Later, the snapped image will automatically appear in the View exported video when browsing the exported videos. It is recommended to add a comment to the snapped image; the comment will appears next to the image.
- **Export:** export the video clip for future usage
- **Tag to archive:** mark the video sequence so that it is queued for archive.



**NOTE:** You can drag the slider at the bottom of the right-hand pane to increase or decrease the speed of the video clip your are playing.

- 3 To save a specific video image, click the Snap button.



- 4 Accept the default name or enter a specific name for the video recording. The video recording is saved in: Program files\Kantech\Server\_GE\Tmp\Image. The video image can then be viewed using a Windows® image viewer such as Paint. Simply, double-click the video image to view it.


## Current Recording

The Current recording feature allows users to view the list of all on-going recordings. The information displayed depends on the source of the recording request:

- Started by a video trigger
- Started by an operator
- Started by an alarm on the video server

### To View the Current Recordings

- 1 From the Video toolbar, click the Current recording button. The current recording window appears, it shows all on-going recordings.



The following table shows the information displayed in the Current recording window depending on the source of the recording.

Initiated by	Information
Video server alarm	<ul style="list-style-type: none"> <li>• Initiated by</li> <li>• Event name</li> <li>• Start date and time</li> </ul>
Video trigger	<ul style="list-style-type: none"> <li>• Initiated by</li> <li>• Video trigger</li> <li>• Recording parameter</li> <li>• Event</li> <li>• Start date and time</li> <li>• Remaining time for the recording</li> </ul>



Initiated by	Information
Operator	<ul style="list-style-type: none"><li>• Initiated by</li><li>• Workstation</li><li>• Operator name</li><li>• Start date and time</li><li>• Remaining time for the recording</li></ul>

## Video Desktop

The Video Desktop allows operators to display and monitor, in real-time, video cameras configured and connected to the network.

### To Display a Video View

- 1 From the EntraPass main window, select the Desktop tab, then select the desktop dedicated to Video. The Video View window appears in the desktop.








**NOTE:** When you open the Video desktop, it is empty, it only displays “No video view selected”. You must scroll down to the bottom of the window and then select a video view from the Select a video view list.



- 2 Select a Video view from the Select video view drop-down list (bottom of the window). You can edit the view (Video view > select a specific View > Modify Video view components button).

- 3 Click a button to resize the displayed images. Buttons in the lower part of the window allow you to perform various tasks:

Buttons	Description
	Use these buttons to select a size for the displayed video. <b>Note:</b> A bigger image requires more process power. Therefore, selecting a bigger image may result in lower process power.
	These buttons are configured in the Operator security level. They enable operators to perform pre programmed tasks such as viewing video playback with a fixed or variable delay, generating video events with fixed or custom parameters. For details on programing this buttons, <i>see "Security Level Definition" on page 356.</i>
	Use these buttons to <b>Create</b> and <b>Edit</b> video views.
	Use this <b>Show view selector</b> button to display a mosaic view of all the camera defined in the system.
	<b>Help</b> and <b>Close</b> buttons. These are EntraPass standard buttons.

- 4 Click the **Show view selector** button to display the View selector window. This small window allows you to so select a specific view or to monitor a specific camera pattern. For instance, if you select a cell in the View selector, the sequence is interrupted to display the selected cell.



***NOTE:** When you open the Video view selector while a camera is recording, the camera icon will blink until the end of the recording.*

- 5 From the displayed view, you can click a dome camera icon to display control buttons for this camera (movement, zoom, focus). Available options depend on the Digital Video Management system connected to your system. Please refer to your DVMS documentation for additional information.




***NOTE:** If your dome camera is set with pre programmed movement patterns, you can define a view displaying a pattern composed of one or many of these pattern. For more details, see "Video Views Definition" on page 162.*

## Exported Video Viewing

EntraPass enables users to view all exported videos. This feature makes it possible to browse the list of all exported videos and to preview a key frame of the exported videos sequence for all KVI and KVA formats.

Moreover, users can preview the exported video segment before viewing it.

- 1 From the Video toolbar, select the View exported video icon. The Video folder opens automatically, with the list of all exported video sequences that have been exported.



- 2 Select a video sequence. The video thumbnail appears in the lower left part of the window. The directory contains the Date and Time the video was taken, the video file format (Type) and the File Name. You can then click the Preview button for details about the exported video. When you preview the video sequence, the system displays information about the camera as well as the software version (Image tab, About button).


## Entrapass Video Vault Browsing

Entrapass Video Vault offers an easy way for preserving important video data for future reference. In fact, video recordings have a limited life span depending on the video server settings and capability. Moreover, since video recordings require a great amount of disk space, using an archive management tool such as Entrapass Video Vault enables organizations to better manage and easily retrieve video contents.

The archiving activity is monitored from the Entrapass Video Vault user interface. The Browse Entrapass Video Vault interface offers a Windows-like navigation pane that enables operators (with appropriate permission) to play video segments archived on Entrapass Video Vault.

### To View a Video Segments Archived in Entrapass Video Vault

- 1 From the Video main window, select the Browse Video Vault button.



- 2 To view a specific segment, select a video segment, then click the Play from Video Vault button.



---

## Chapter 6 • Definitions

Use the Definition toolbar to define the system logical components such as:

- Schedules
- Alarm systems
- Areas
- Guard tours
- Floors
- Event relays
- Graphics
- Holidays

## Schedules Definition

A schedule indicates when the system will execute certain operations such as automatically unlocking doors, permitting access to employees, running automatic reports, monitoring inputs, etc. It also determines when events are to be acknowledged or when to activate relays controlling different functions (lighting, heat, etc.).

You can use the same schedule in different menus, but it is recommended to create a different schedule for each application, because it is much easier to modify a particular schedule without affecting other applications.

Each schedule is composed of four intervals. Each interval has a starting and ending time. Each of these intervals can be individually selected for the seven days of the week, and for holidays.

You can program up to 100 schedules in the system. However, EntraPass gives you the possibility of programming 100 schedules per gateway, 100 schedules per site and an unlimited number of system schedules. To do so, you must activate the **Upgrade to advanced schedule capability** option in the Server parameters menu (Option > Server parameters).



**NOTE:** For more information, please see "Schedule" on page 476.

When this is done, three groups of schedules are available:


- **System schedules:** System schedules for global functions such as event parameters, operators login schedules and video triggers. These are not loaded in controllers.
- **Global schedules:** Global schedules are grouped by gateway. These are defined per Global Gateway. You can define 100 schedules per Global Gateway for such devices as event relays, secondary access levels, alarm systems, areas, guard tours and elevator controls.
- **Corporate site schedules:** These are defined per site. You can define 100 schedules per corporate site for such purposes as: power supervision (controllers), unlock schedule (doors), Rex schedule (doors), activation mode (relay), monitoring schedule (input).

If you are assigning or defining schedules, make sure that you are selecting the proper category for this schedule. For example, if you are assigning or defining a system schedule (for workstation, operators, event parameters, video triggers) this schedule will be available for selecting components of this category. If you are selecting a schedule for physical components such as controllers, doors, inputs, their schedules will be grouped by gateway if you are using a Global Gateway and by site if you are using a Corporate Gateway. If you have defined two sites in your system, there will be two separate groups of schedules for each site. You can define up to 100 schedules for each site.



### To Define a Schedule

- 1 From the EntraPass main window, click the Definition tab. Then click the Schedules icon from the Definition toolbar.



	Start time	End time	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Hol 1	Hol 2	Hol 3	Hol 4
1	00:00	00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	00:00	00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	00:00	00:00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	00:00	00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



**NOTE:** If you have checked the *Upgrade to advanced schedule capability* option (*System parameter > Server > Schedule* tab), the *Gateway/Site* drop-down list appears for selection. From the *Gateway/site* drop-down list, select a *Gateway* (Global site) or, select a *Site* (Corporate site) or a *System schedule*, (applicable to system components such as event parameters, video triggers, operator login).

- 2 From the Schedule drop down list, select the schedule you want to modify or select the schedule applicable to the category selected in previous step, or click the New icon to create a new one.
- 3 Assign a name (or modify an existing one) to the schedule. It is recommended to choose a meaningful name.
- 4 You can click the Holiday icon in the toolbar to view the list of holiday that are defined in the system.



**NOTE:** EntraPass supports four types of holidays.

- 5 Specify the Start time: this is the scheduled time when the interval becomes valid. It will become invalid when the end time has been reached.
- 6 Specify the End time: this is the scheduled time when the interval is no longer valid.



**NOTE:** Start and end times are in 24-hour time format; this gives a range from 00:00 to 24:00. For any interval, the end time must be greater than the start time.

- 7 Check the Days of the week during which this schedule interval will be valid. To do this, click in the check box below each day.
- 8 Check the holiday type (Hol1, Hol2, etc.) column checkbox if you have defined four holidays in the Holiday definition menu and you want this interval to be valid during a holiday.

## Creating a 2-day Continuous Interval

To create an interval from Monday 20:00 (8:00 PM) to Tuesday 08:00 AM, the schedule must be divided into two intervals:

- 1 First define an interval for Monday from 20:00 to 24:00;

	Start time	End time	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Hol 1	Hol 2	Hol 3	Hol 4
1	20:00	24:00	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	00:00	08:00	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	00:00	00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	00:00	00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

- 2 Define a second interval for Tuesday from 00:00 to 08:00. The system considers these two intervals as one continuous interval.

## Alarm Systems Definition (Global/KT-NCC/NCC 8000)

An alarm partition is a gathering of devices or equipment arranged to signal and detect the presence of an alarm condition requiring immediate attention or operator acknowledgement.

The system offers up to 100 virtual alarm partitions per gateway. A virtual alarm partition is an alarm partition that is entirely controlled by the gateway instead of using a hardware device designed to perform the same function.

Depending on how virtual alarm partitions are programmed, they can trigger various relays on alarms.

### Example of an alarm partition.

The system shall be able to partition the different areas of the building into up to 100 VASP (Virtual Alarm System Partition). Each VASP partition can be set up using any number of readers, door contacts, motion detectors, sirens and user access rights. Monitored points can be used in more than one partition.

### Operation.

Each area can be delimited by doors equipped with readers and monitored with door contacts. Single reader doors can also be equipped with a T.REX exit detector to provide hands-free door unlock. As required for the security of each area partitioned, the VASP will control a collection of the following devices: readers, door contacts, motion detectors, heating/air conditioning control, exit delay warning device and door locks.

### Arming, Postponing and Disarming.

Each VASP can be defined with an auto-arming schedule for each day of the week including holidays. At the programmed arming time, the exit delay warning will sound for a minimum of 4 minutes. Any employee in the area who is not allowed to stay later than the arming time will have to leave the area.

At the end of the exit delay, the area will arm and will be monitored for intrusion and, possibly, for turning off or changing the settings of the air conditioning or heating system.

During the exit delay, if an authorized employee wants to remain in the secured area later than the arming time, that employee can use his/her card at any of the readers of the area defined as a "postponement reader" in the system.

This operation will initiate the postponement of the arming. The postponement delay can be pre-programmed for each area, up to eighteen hours and twelve minutes (18h12'). After the postponement period, the system will attempt to arm again and sound the exit delay. The same scenario of postponement will be available to employees wanting to remain in the area unless a maximum number of postponements (if programmed) or a "no disarm" scheduled time has been reached. Each card of the system can be programmed to allow or limit the use of this feature.

When an area is armed, it can be disarmed by authorized cardholders (who share the right to disarm the alarm partition) by presenting their cards at a disarming reader (as defined in the system).

If the cardholder is authorized in that area during that specific time, the door will unlock and the partition will be disarmed as soon as the cardholder opens the door. If disarming happens at a time when the system would be normally armed by a schedule, the system will attempt to re-arm automatically after the postponement time described earlier. In addition to those tasks performed by cardholders, an authorized operator (such as a guard) can manually operate the partitions from any of the system's workstations (disarm, arm or modify the postpone delay time).

## Alarm System Capabilities

- Up to 100 different independent alarm partitions can be programmed per gateway.
- Each alarm partition can supervise any input or door of the system.
- When defining alarm partitions, elements such as: doors, readers, input zones and output relays can be defined as single or group.
- Each alarm partition can include inputs or doors supervised by one or more alarm partitions as shared elements (common).



**NOTE:** *If a same input is defined for 2 alarm partitions, and only one system is armed, if this input generates an “alarm”, it will not be reported. Both alarm partitions must be armed for the input to report the alarm condition.*

## Common Inputs

Input zones or doors, which are shared by multiple alarm partitions, are related according to the following rules:

- An alarm partition will only produce an alarm from an input / door common to other alarm partitions if all the alarm partitions containing that input / door are armed. Inputs or doors which are part of “Alarm Level 1 and 2” can be defined in a different way but have to be part of a group.
- Alarm level 1 and 2 (input groups) are processed together as one large group for the purpose of determining whether an input (zone) is also included in another alarm partition definition.
- Common doors which are defined as “Door to be locked on arming” or “Door disabled on arming” in both alarm partitions will revert to their normal state if one or more of these alarm partitions is disarmed.

## Perimeter and Volumetric Detection

The devices of an alarm system are grouped in two categories, perimeter and volumetric detection.

### **Perimeter (alarm level inputs).**

Perimeter detection refers to the detection of access to the outer limits of a detection area by means of physical barriers such as: door contacts, glass break detectors, door contacts on uncontrolled doors, etc.

Usually, inputs that are defined as “perimeter” (glass breaks, garage doors, fire doors, door with door contacts not controlled, etc.) are grouped and defined as “alarm level #1 inputs”. When one of these inputs are activated, it will activate the “alarm relay #1” relay which can be connected to an “alarm panel” that will send a warning to the central indicating a parametric intrusion. A perimeter detection is considered more important since it originates from the perimeter of the controlled area. For supervised doors (reader, T.REX, door contact), you can use the field Supervised door when armed to group the doors that will also activate the “alarm relay #1” when a “door forced open” or “door open too long” event is generated for these doors. For example, main entrance doors or back entrance doors can be included in this field.

### **Volumetric (alarm level # 2 inputs).**

Volumetric detection refers to detection of access of the volume, such as an entire room or part of a room by means of volume detectors such as: movement detectors or sensors, controlled doors

(readers, etc.). Inputs defined as “volumetric” (PIRs, sensors (heat), etc.) are grouped and defined as “alarm level # 2 inputs”.

When one of those inputs is activated, it will activate the “alarm relay #2” relay which can be connected to an “alarm panel” that will send a warning to the central indicating a volumetric intrusion.

## Arming Procedure

There are three (3) methods to arm an alarm system:

- 1 **Manual arming:** This is done at the Manual operation window at the workstation by an authorized operator. The alarm system will be armed once the exit delay is over.
- 2 **Automatic arming (arming schedule):** The alarm partition will initiate the exit delay when the arming schedule becomes valid. The alarm partition will be armed once the exit delay is over.
- 3 **Arming at a door reader (with or without an arming request button):** There are 3 possible choices:
  - **With a card**—The card is presented at the reader defined as “arming reader”. The exit delay is initiated, once over the alarm partition will be armed.
  - **With a card and an “arming request input”**—The card is presented at the reader defined as “arming reader”. The “arming” delay is initiated. The “arm request input (button)” must be pushed during this delay to confirm arming. Once the arming request input is pushed, the exit delay is initiated and the alarm partition will be armed once the exit delay is over.
  - **With only an “arming request input”**—The “arm request input (button)” must be pushed to confirm arming. Once the arming request input is pushed, the exit delay is initiated and the alarm partition will be armed once the exit delay is over. To only use an “arming request input”, no reader must be defined as “arming reader”.



**NOTE:** Arming is done by presenting a card at the door reader (or entering a number on the keypad) defined as “arming reader” in the alarm system definition menu. Arming at a door reader is only permitted by a card with the defined arming access level, which must include access to the arming reader in question.

## Disarming Procedure

This command disarms the alarm system. Depending on how the partition is programmed, results can be different.

- **Manual disarming:** This is done at the manual operation window at the workstation console by an authorized operator. The alarm partition will disarm right away, unless a “no disarm” schedule is valid, this command will initiate the “postpone” delay.
- **Disarming at a door reader using a card:** Disarming is done at the door reader (or keypad) defined as “disarming reader” in the system.

**General Rules:**

- Disarming is done by presenting a card at the door reader (or entering a number on the keypad) defined as “disarming reader” in the alarm system definition menu.
- Manual disarming is only permitted by a card with the defined disarming access level, which must include access to the disarming reader in question.

- If there is a door contact defined for the door, then the door must be opened for disarming to take effect. If there is no contact, you don't have to open the door.
- If a "no disarm" schedule is in effect and a user disarms the system, the system will be in the "postpone delay" mode, when this delay expires, the system will be in the "exit delay" mode, when this delay expires, the system will arm again automatically, if the schedule is still valid at that time. In this case the limit on the number of postponement delays is effective only after the initial delay.
- If the arming reader is also defined as "disarming reader", the door will have to be open to disarm the system. On the other hand, if a "no disarm" schedule is effective, a disarming request will postpone the arming of the system.

## Disarm When "No Disarm" Schedule is Valid Procedure

If a "no disarm" schedule is in effect and a user disarms the system, the system will be in the "postpone delay" mode, when this delay expires, the system will be in the "exit delay" mode, when this delay expires, the system will arm again automatically, if the schedule is still valid at that time. In this case the limit on the number of postponement delays is effective only after the initial delay. Arming an alarm partition can be postponed for a pre-set period (maximum 16.5 hours) after which the system will automatically arm only if the "no disarm" schedule is valid at that time.

## Postponed Arming Procedure

A postponement arming can be activated in two ways, depending on the circumstances:

- 1 During the exit delay (when the system is being armed, whether armed manually or by arming schedule).
- 2 While the system is armed, during any interval when the "no disarm" schedule is valid, the normal disarming of the system will automatically initiate a postponed arming, for a number of times not exceeding the maximum number defined in the postpone count field.



### Notes:

- In either cases, the system will automatically arm itself at the end of the postponement delay (when the postponement delay expires, the exit delay is initiated) only if the "no disarm" schedule is in effect at the time.
- A postponed arming can only be activated at door readers defined as "arming reader" or as "postponing reader".
- For a door reader defined as "postponing reader", you can only postpone during the "exit delay".
- For a door reader defined as "disarming reader", you can postpone during the "exit delay" or when the system is armed and a "no disarm" schedule is valid.
- A postponed arming can only be activated with a card with the "disarming access level", which has to include access to the door from which it is to be activated.
- A postponed arming can be activated during the "exit delay" when the system is being armed, during a postponement delay already in progress or when the system is armed and a "no disarm" schedule is valid.
- If a postponement-arming request is done when one is already in progress will reset the postponement delay and decrement the count of consecutive postponement allowed, if the limit


has not already been reached. A limit is defined (0-15) for the number of successive postponement delays permitted.

**Warning:**

- An entry of 0 in the “postpone count field” will cause an infinite number of successive postponements to be permitted.
- Should a reader be defined as BOTH the arming and disarming reader for a given alarm partition, its function with respect to postponement will be as the postponement reader, i.e. postponement will initiate immediately upon card access.


## Alarm Partition

- 1 From the Gateway drop-down list, select a gateway associated with the alarm partition.



- 2 From the Alarm System drop-down list, select an existing alarm system or click New to create a new alarm system
- 3 From the Arming Schedule field, select a schedule according to which the alarm partition will automatically arm at the time that this schedule becomes valid (the exit delay will be initiated before the system actually arms). This schedule is used only to arm the system, do not insert the “All valid” schedule. When this schedule becomes invalid, the system will not disarm, it will remain armed until presentation of a valid card at a disarming reader. You can right-click the selection field to create a custom arming schedule.
- 4 From the No Disarm Schedule field, select a schedule during which a disarming attempt will initiate postponing of the alarm partition. Once the postpone delay is over, the system will automatically initiate the exit delay and arm automatically once expired.

5 Select the Access and delays tab to define access level options:



- **Arming Access Level:** select the access level required to arm the alarm partition. Arming the system requires the arming access level and access to the arming reader(s).
  - **Disarming Access Level:** select the required access level to disarm the alarm partition. Disarming the system requires the disarming access level and access to the disarming reader(s).
- 6 In the Delays (hh:mm:ss) section, specify the entry and exit delays:
- **Entry delay:** specify the entry delay time during which a user will have access to a supervised area to disarm the system.
  - **Exit Delay**—Enter the exit delay. The exit delay is used to warn employees that the system will be armed once this delay is expired following an arming request. The system can be in the “exit delay” mode following:
    - An arming request,
    - or when the “postpone delay” is expired and the “no disarm” schedule is still valid.
  - **Arming Delay**—Enter the arming delay time. This is the delay allowed by the system between the moment that a card is presented at an arming reader and the moment that the “arming request button” is pushed to confirm arming.
  - **Postpone Delay**—Enter the postpone delay time. The postpone delay is a “period” during which the alarm partition is disarmed.
    - If the “no disarm” schedule is still valid, the system will enter in “exit delay” then arm again when the exit delay expires.
    - If a postpone or disarming operation is attempted during this “exit delay” the system will return to the postpone delay.
    - If the “no disarm” schedule is NOT valid, the system will automatically disarm at the end of the postpone delay.



- The postpone delay can be manually modified through the manual operations section of the system.



**NOTE:** It is possible to associate a relay that will be triggered when an arming, disarming or postpone delay is initiated. It could for example provide a visual feedback on a status panel to indicate that the system is waiting for a confirmation.

- Postpone Count—This option specifies the maximum number of times the alarm system can be postponed. When the maximum count is reached, the system will initiate the exit delay and arm automatically (if a “no disarm “schedule is still valid) or disarm if a normal arming schedule is valid.



**NOTE:** If set to “0”, the alarm partition can be postponed indefinitely.

7 Select the Door tab to define the arming and disarming, and postpone options:

Setting	Access Level	Security Code
Arming reader	[01.01.01] 01 - 01 - 01 - Security NCC Windows	***
Disarming reader	[01.01.01] 01 - 01 - 01 - Security NCC Windows	***
Arming reader no unlock	[01.02.01] 01 - 02 - 01 - Security NCC Windows	***
Postpone reader	[01.01.01] 01 - 01 - 01 - Security NCC Windows	***
Door disabled when armed	[01.03.02] 02 - 03 - 01 - Security NCC Windows	***
Door to be locked on arming	[01.01.01] 01 - 01 - 01 - Security NCC Windows	***
Supervised door when armed	[01.01.01] 01 - 01 - 01 - Security NCC Windows	***

- Arming reader—Select a door or door group that will be used to arm the alarm partition. Arming will only work at an arming reader. Arming the system requires the arming access level and access to the arming reader(s).



**NOTE:** Usually, arming readers are located near exit doors.

**NOTE:** If more than one alarm partition can be armed with the same arming reader, use an “arming request input” to confirm arming.

- Disarming reader—Select a door or door group that will be used to disarm the alarm partition. Disarming will only work at a disarming reader. Disarming the system requires the disarming access level and access to the disarming reader(s).



**NOTE:** Usually, disarming readers are located within the perimeter of the protected area. For example, a disarming reader could be located at the front door where a video surveillance camera is located for visual recording.

- **Arming reader no unlock**—Select a door or door group that will be used to arm the system without unlocking the door.
- **Postpone reader**—Select a door or door group that will be used to postpone the alarm partition from arming. Postponing arming requires the disarming access level and access to the postpone reader. A postpone reader can only be used during the “exit delay”.



**NOTE:** Usually, postpone readers are located within the protected area so as to allow employees to postpone the system from any reader located inside.

- **Door disabled when armed**—Select a door or door group for which the readers are disabled when the alarm partition is armed. No access is permitted, even for cards with the required disarming access level and at the disarming reader.



**NOTE:** For example, this field can be used to select a back door in order for users to use the front door to disarm the system.

- **Door to be lock on arming**—Select a door or door group that will be locked when the alarm partition is armed. It will override the unlocking schedule (even if valid) and will also override a manual unlocking operation.
- **Supervised door when armed**—Select a door or a group of doors that will generate an alarm level # 1 (perimeter) and trigger the relay selected in the Alarm # 1 Relay State field (Relay 2 of 2 tab) if the events “door forced open” or “door open too long” are produced by these doors while the system is armed.

8 Select the Input tab to define input for arming and disarming:

The screenshot shows the 'Alarm system' configuration window. The 'Input' tab is selected, displaying the following settings:

Field	Value
Alarm level #1	(01.01.01) 01 - 01 - 01 - Security NCC Windows
Alarm level #2	(01.02.01) Contact -> 01 - 02 - 01 - Security
Arming request	(01.01.01) 01 - 01 - 01 - Security NCC Windows
Prevent arming	(01.03.01) Contact -> 01 - 03 - 01 - Security
Input for entry delay	(01.01.01) 01 - 01 - 01 - Security NCC Windows
Shunted on disarming	(01.01.01) 01 - 01 - 01 - Security NCC Windows

The window also includes tabs for General, Access and delays, Door, Input, Relay 1 of 2, and Relay 2 of 2. The 'Relay 2 of 2' tab is currently active, showing the same settings as the 'Input' tab.

- **Alarm level #1 input**—Select a single input or a group of inputs that will automatically activate the relay selected in the Alarm # 1 Relay State field (Relay 2 of 2 tab) if the system is armed and an alarm is detected from one of the selected inputs.

- **Alarm level #2 input**—Select a single input or a group of inputs that will automatically activate the relay selected in the Alarm # 2 Relay State field (Relay 2 of 2 tab) if the system is armed and an alarm is detected from one of the selected inputs.
- **Arming request input**—Select a single input or a group of inputs that must be “in alarm” to confirm arming of the alarm partition. An arming request input should be used when more than one alarm partition can be armed with the same arming reader. Usually, a button is used as an arming request input. The card is presented at the reader, the “arming delay” is initiated, the button is pushed, the exit delay is initiated after which the alarm partition will arm.



*NOTE: It is possible to associate a relay that will be triggered when the arming delay is initiated. It could for example provide a visual feedback on a status panel to indicate that the system is waiting for a confirmation.*

- **Prevent arming input**—Select a single input or a group of inputs. If any of these inputs is “in alarm” when arming is attempted, arming will not succeed and will be aborted. Usually inputs from “Alarm Level 1 & 2” are grouped together as one group and selected. This will group all the inputs of the alarm partition. This is only true when an arming request is done at a door reader with an arming request input.




*NOTE: If the alarm partition is armed automatically with an “arming schedule”, the inputs will be ignored and arming will succeed.*

*NOTE: It is possible to associate a relay that will be triggered when the arming is aborted.*

- **Entry input**—Select a single input or a group of inputs used to initiate the entry delay. If any of these inputs is “in alarm” when the system is armed, the entry delay will be initiated and inputs selected in the “Shunted on Disarming” field will be shunted for the duration of the “entry delay”.
  - **Shunted on disarming**—Select a single input or a group of inputs that will be shunted (not monitored) when the “Entry Input” is triggered. These inputs will be shunted for the duration of the entry delay.
- 9 Select the Relay 1 of 2 tab to define the relays that will be used to indicate or display various status for the alarm system being defined. For each relay, it is possible to determine when the relay will return to its normal condition. There are 2 possible conditions:
- **Temporary:** The relay will remain temporarily activated for the activation time programmed in the relay definition menu. Be careful, if the relay activation time is set to zero in the relay definition menu, the relay will “follow” the condition or device condition even if it is programmed to be temporarily activated.


- Follow: The relay will remain activated until the condition that triggered the relay is over.



**NOTE:** When a relay is activated or deactivated from of an alarm system, *EVENTS WILL NOT* be generated.

- **System Armed—Relay**—This relay will be triggered when the alarm partition is armed.
- **System Disarmed—Relay**—This relay will be triggered when the alarm partition is disarmed.
- **System Status Relay**—This relay will reflect the status of the inputs of “Alarm Level #1 and #2” as well as doors of the “Door supervised when armed” field.
- **Prevent arming Relay State**—Select the relay that will be triggered when the arming sequence is aborted due to an input in alarm generated during arming. Select, from the pull-down menu, the relay activation

- 10 Select the Relay 2 of 2 tab to define the relays that will reflect the various conditions of the alarm system being defined.



**NOTE:** When a relay is activated or deactivated from an alarm system, **EVENTS WILL NOT** Postpone Relay—Select the relay that will be triggered when the alarm partition is in “postpone” mode.

- **Entry Relay**—Select the relay that will be triggered when the “entry delay” is initiated.
- **Exit Relay State**—Select the relay that will be triggered when the “exit delay” is initiated.
- **Arming Delay State**—Select the relay that will be triggered when the “arming delay” is initiated.
- **Alarm #1 Relay State**—Select a relay that will be triggered when the alarm partition detects a valid alarm condition (i.e. input in alarm) from one or more inputs defined in the “Alarm Level #1” field or from one or more doors (i.e. door forced open or door open too long) defined in the Supervised door when armed field.
- **Alarm #2 Relay State**—Select a relay that will be triggered when the alarm partition detects a valid alarm condition (i.e. input in alarm) from one or more inputs defined in the Alarm Level #2 field.
- **Bell-Relay state**—Select a relay that will be triggered when the alarm partition detects a valid alarm condition (i.e. input in alarm) from one or more inputs defined in the Alarm Level #1 field or from one or more doors (i.e. door forced open or door open too long) defined in the Supervised door when armed field. Usually an audible signal is initiated with this relay.

## Areas Definition (Global/KT-NCC/NCC 8000 Gateways Only)

Areas are the basic unit for using Anti-passback. They define how to control and monitor cardholder activities within an area of controlled doors. Under a Global, a KT-NCC and NCC 8000 Gateways, the anti-passback is entirely controlled by the gateway rather than the controllers.

- 1 Select the Gateway associated with the area you want to define, then select an Area (to modify one) or click the New icon to create a new area.



**NOTE:** When cards are created in the Card Definition dialog, they are automatically sent to the “unknown area”.

- 2 Define the type of passback applied to the area being defined:
  - **None**—No anti-passback is verified to access the area. If you want to disable the passback for a specific time, use the Disable passback schedule field under the Miscellaneous tab.
  - **Normal passback (hard anti-passback)**—The “normal” passback is considered a “Hard Anti-Passback” which means that access is verified and control is done. Usually, doors (or readers) are “shared” between areas, meaning that before accessing a door, a cardholder is considered to be in a certain area (which is called “area before”) and when this cardholder passes the door, he/she is in another area (which is called “area after”).
  - **Supervisor passback**—Supervisor passback is more like a “controlled passback”. There are various restrictions or controls that can be programmed to use this type of passback. For example, you can indicate that at least 2 supervisors must be inside an area before anybody without a supervisor level can access the area.



**NOTE:** The supervisor level of a cardholder is programmed in the Card Definition dialog.

- **Normal and supervisor**—both Normal and Supervisor passback types are in effect for the area.

- 3 From the Relay will be activated when area is open field, select a relay or group of relays that will be triggered when the area is opened (Area Open Event) and will remain activated until the area is closed (Area Closed Event).
- 4 Check the Card position already valid option if applicable. When selected, the “Card location in bad area” event will not be displayed if the user is no longer permitted in the area since his/her access level (schedule) is expired.
- 5 Specify the number of cards required to generate the Area open event in the Card(s) to open area field. This field will determine the number of valid cards required to consider this area “opened” (an area is considered “closed” or empty when all users have left the area and considered “open” when it is occupied by at least one cardholder). By default, if left to 0, as soon as one user accesses an area, if this area is empty, the system will generate an “Area Opened” event.



**NOTE:** If you specify more than 1 card (i.e.: 2 and up), each cardholder will have to pass their card at the reader one after the other (i.e.: the first user passes his/her card, then the second user passes his/her card).

- 6 If the video feature is enabled, the Video view field appears. If this is the case, select the video view in which you want the defined component to appear. For details on defining video views, see “Video Views Definition” on page 162.
- 7 From the Graphic list, you may select the graphic to which the EntraPass applications is assigned, if applicable. For details on defining graphics, see “Graphics Definition” on page 217.
- 8 Select the Miscellaneous tab to setup the transfer schedules for the area being defined.

- **Disable passback schedule**—This option sets the schedule during which the Anti-Passback verification (for all types of passback) is disabled. When this schedule is valid, passback will be disabled (not verified).
- **Supervisor:**
  - **Supervisor level**—Enter the supervisor level required to “open” the area. This field must be used with the “supervisor to open area” field.

- **Supervisor to open area**—Enter the number of supervisors required to “open” the area, meaning that “XX” number of supervisors (having the supervisor level defined in the supervisor level field) must be inside the area before anybody else (having a supervisor level lower than defined) can access the area (i.e. 2 supervisors having a supervisor level “9” must be inside before any other cardholder having supervisor levels lower than “9” can access the area). You must specify the supervisor level required in the “supervisor level” field.
- **Number of supervisor inside**—Enter the number of supervisors that must remain inside the area (having the defined supervisor level) at all time. This field is used when you need to have a supervisor inside the area at all times. When another supervisor comes in (having the defined supervisor level), then the previous supervisor can leave.



**NOTE:** You cannot use this field if you are using the Supervisor must be last on exit field. This function is disabled when set to zero.

- **Supervisor must be last on exit**—When selected, a supervisor (having the defined supervisor level) will not be authorized to leave the area if there are any cardholders present within the area without the defined supervisor level.



**NOTE:** You cannot use the Number of supervisors inside field if you are using the Supervisor must be last on exit field.

9 Define the Area transfer parameters:

- **Area transfer schedule**—This schedule is used to move the cardholders located in an area to another area so as to avoid generating “Access denied - Passback bad location” or “Card in bad location” events. When the transfer schedule becomes valid (or invalid), you can specify an area where cards will be transferred. You can also manually modify the card location using the Manual Operation on Areas menu.
- **Area on invalid schedule**—This area will receive all cardholders of the area being defined when the transfer schedule becomes invalid.
- **Area on valid schedule**—This area will receive all cardholders of the area being defined when the transfer schedule becomes valid.




## Guard Tour Definition (Global/KT-NCC/NCC 8000 Gateways Only)

A guard tour consists of a number of stations or doors that must be physically verified according to a predefined schedule. The stations can either be door readers or inputs. A delay between stations can be defined; the system will generate an alarm if a station is not visited at a specified time.




**NOTE:** Guard tours can only be initiated and ended by an operator's manual intervention (Operations > Guard tours).

- 1 From the Definition toolbar, select the Guard tour icon.



- If you want to create a new guard tour, click the New icon in the toolbar. The Select a gateway (Guard tour) window will open.



- Select the gateway you want to define, then click OK to close the window.
  - In the Guard tour window, enter a name for the new Guard tour and click the Save button.
  - If you want to modify an existing guard tour, select it in the Guard tour scrolling list.
- 2 Select a schedule from Notify schedule list by clicking the Select a component button. If this schedule becomes valid, the system generates the “Guard tour scheduled” event and notify the operator that the guard tour must be started. The operator will then have to start the guard tour physically. He will then present his card to readers related to this specific tour or open/check doors defined in this tour.
  - 3 Specify the Pre-alarm delay. After this delay, the system will generate the “Guard tour alarm” event.



**NOTE:** The first late event is issued when the station-to-station time expires; for example, if the guard has 1:00 minute to reach the next station and the 1:00 minute expires, the system will generate the “Guard tour station late” event. Then, the “pre-alarm delay” will be initiated. The “Guard tour alarm” event will be generated when the pre-alarm delay expires.

- 4 When applicable, enter the Time adjustment based on Gateway time zone. If, for example, the time difference is 1 hour and 30 minutes, you will enter 1,5.
- 5 Select a Video view (if applicable) and a Graphic view where the guard tour has been assigned.
- 6 Select the Station tab to define stations for the guard tour.

Seq.	Delay (hh:mm:ss)	Door or input	Unlock door	Description
1	00:00:00	Door	<input checked="" type="checkbox"/>	(01.01.01) Controller#1 Door#1
2	00:00:00	Input	<input type="checkbox"/>	(01.01.01) Controller#1 Input#1
3	00:00:00	Input	<input type="checkbox"/>	None
4	00:00:00	Input	<input type="checkbox"/>	None
5	00:00:00	Input	<input type="checkbox"/>	None
6	00:00:00	Input	<input type="checkbox"/>	None
7	00:00:00	Input	<input type="checkbox"/>	None


- **Sequence**—Indicates the guard tour steps. These must be defined in a way that it will be easy for the guard to go from a station to another. For example, the sequence should be programmed according to the order of stations to be visited.
- **Delay**—This delay specifies the period (hh:mm:ss) to reach the next station. If this delay expires before the guard reaches the next station, the system generates the “guard tour station late” event. If the guard does not reach the station within the next delay, the system generates the “Guard tour alarm” event.

- **Door/Input**—The station can either be defined as a door reader or an input. In the description column, select the door or input that will be used for the reporting station.
- **Unlock door** —When selecting a door as a station, it is possible to specify if the guard must “open” the door (unlock) to complete this tour.
- **Description**—Select the door or input (according to the “door or input” column that will be used as the station for the guard.

## Floors Definition

The Floor dialog is used to create or edit elevator floors. Once the floors are created, they are grouped and associated with a schedule that will define when access is permitted.

- 1 In the Definition toolbar, click the Floor icon.



- 2 In the Site drop-down list, select the gateway/site for which you are defining floors. This allows you to minimize the list of components defined in the system.
- 3 Select a floor or click the New icon to create a new floor group.
- 4 Assign a meaningful name to the floor, then click the Close button. The system prompts you to save.

## Event Relays Definition (Global/KT-NCC/NCC 8000 Gateways Only)


This menu is used to associate events that will trigger relays. You can also specify that the relay be triggered only during a specific schedule and if the relay will be activated, deactivated or temporarily activated. For instance, you can define a relay to be activated when an alarm system is armed. You can for example set the relay to turn off all the lights, etc.

Events are generated for various reasons. They can be generated to report such events as:

- Unauthorized access
- Intrusion
- Defective components
- Modified components
- Guard tour status (for example that a guard has not reached the next station), etc.

### To Define Event Relays

- 1 From the Definition toolbar, click the Event relay button.



- 2 From the Gateway list, select a gateway, then select an Event to which you want to associate a relay. System components associated with the selected event appear in the left-hand pane.
- 3 Select the component you want to associate with the event, then select the Relay you want to activate when the selected event occurs.
- 4 For the selected relay or group of relays, choose the Relay activation mode:
  - **Temporarily activated**—The relay will be temporarily activated for the delay defined in the Temporary activation timer field of the relay definition. If the Temporary activation timer delay is set to “0”, then the relay will follow the event.
  - **Activated**—The relay will activate permanently until requested otherwise by the system.
  - **Deactivated**—The relay will deactivate permanently until requested otherwise by the system.

- 5 Select the Activation schedule: The relay will ONLY be triggered when the schedule is VALID. In other words, when the event is generated and the schedule is valid, the event will trigger the relay, if the schedule is not valid, the event will not trigger the relay.




**NOTE:** When a relay group is selected, the relays included in this group are each triggered according to their definition (activation timer field). For example, one relay can be set to 10 seconds and another relay can be set to 0 (follow the event).

## To Print Event Relay

This menu is used to print the parameters for a specific event.

- 1 From the Event relay window, click the Printer icon.



- 2 From the Event Relay pane, select the Event for which you want to print the associated parameters.
- 3 From the Gateway drop down list, select the gateway for which you want to print event parameters.
- 4 Select components associated with the selected events.—Events are usually associated with a system component, such as a door, controller, alarm partition, workstation, etc. For example, if you select the event “Input in alarm”, the component selection will display all the inputs that are defined in your system. Select the input you want to print (you can select all components, use the “check mark” button).

## Graphics Definition

A graphic corresponds to the secured area of the system where components (EntraPass applications, controllers, inputs, relays, etc.) are located on a site.

With graphics, operators can easily view the exact location of a component installed on a site, or the status of components and devices such as doors, contacts, motion detectors, controllers, assigned to the graphic. Operators can perform manual operations directly from the displayed component (for example, locking/unlocking a door).


You can create as many graphics as you need. Each graphic can display up to 250 components including using live video as a background. You may also import graphics or maps from other programs in the following formats (BMP, EMF, WMF, JPEG, GIF, PCX, PNG, TIF or PCD).



**NOTE:** Entrapass offers users four sample floor plans. You can customize them to suit your system needs. The sample floor plans are located at: C:\Program Files\Kantech\Server-GE\Generaldata\Demobmp folder.

### To Define Components of a Graphic

- 1 In the Definition toolbar, click the Graphics icon.




- 2 From the Graphic drop-down list, select the graphic you want to modify, or click the New icon to create a new one.
- 3 Assign a name to the graphic (or modify the existing name).




**NOTE:** When you select an existing graphic, or when you create a new one, all the components that are assigned in your graphic are displayed in the left-hand pane. The right-hand part of the window displays the graphic itself.

- 4 From the Graphic Definition window, Click here to create, edit or modify a graphic to bring up the Assign Components window.



**NOTE:** If the video feature is enabled in your system, video components are added to the Graphics menu. These video components can be accessed from the graphic layout. The icon can be positioned on a graphic layout and its status can be retrieved by clicking on the video icon. In addition to standard options, the following status option will be available for the video component: Video Server Online / Offline, Video Server Parameters (Related to a specific vendor) and Camera status.

- 5 Click on the Options menu to display a pull down menu of drawing options. A check mark appears next to an option that is activated




- **Show hints** provides the component's name (component's address and name) when you point your mouse cursor over that graphic.
- **Draw transparently** will place a transparent icon on top of a background picture for a blended effect.
- **Draw frame** draws a frame around the component. Frame color indicates the current frame color and allows you to change the color.
- Select **Edit background picture** to edit the background of the selected graphic. From this window you can modify the graphic's frame and background color and add annotations.



- Select **Clear background picture** for the to clear the background picture of the graphic only leaving the assigned components. You can use this option when you want to insert a new graphic and leave the same components.

## To Design the Background for the Graphic Window


- 1 Double-click anywhere in the background of the Assign components window to bring up the **Design background picture** dialog.



- 2 Use this window to import a graphic that was created with another application or create your own background using the drawing toolbar buttons.
  - To import an existing graphic, click the diskette icon, then drag and drop the diskette in the work area. Once you have positioned the component, and released the mouse button, the Image properties dialog will pop up on the screen. The system displays the **Open** window. Locate the graphic you want to import and click **Open**. The graphic will be placed in the graphic area of the dialog.
  - To import a custom icon into the background graphic, click the **Custom images** button in the toolbar. The **Select an image** window pops up on the screen. Select an icon, then click **OK** to close the window and import the image in your design.
  - To insert shapes and text in the background image, select a rectangle, a circle, an ellipse, etc. in the toolbar, and drag and drop it in your background.




- To modify a shape you've just placed in the burgeoned window, right-click it to open the Properties dialog. and make the appropriate modifications (color, position, etc.).
- You can setup the system to display the Properties dialog as you drop the shape into the design window. To do so, select the Show properties on Drop from the Options menu.
- To retrieve shapes that were previously saved to a disk, select the Load annotations option in the Image menu. When you add shapes to a graphic, you have the option of saving them as annotation on a separate file in order to retrieve them later.
- To save annotations on a separate file from your graphic, select the Save annotations option in the Image menu. You will be able to retrieve them for later use.
- To clear the shapes, select Clear annotation in the Image menu. If you save the graphic with the shapes, the shape become permanent.
- Use the View menu to define how the graphic will be displayed.



**NOTE:** Sizing handles (square handles that are displayed along the sides of the object that surrounds the selected object) indicate the object is selected.

## To Assign System Components to Graphic Icons

- 1 From the Assign Components window toolbar, click and drag the selected component to the desired position. To drag an object across a window, select the object with your mouse and drag, while keeping the button pressed down, to the desired location in the graphic.



- 2 Once you have positioned the component, and released the mouse button, the Assign Form dialog will pop up on the screen
- 3 Select the system component you want to assign to the icon on the screen.
- 4 Click OK to go back to the previous window.



***NOTE:** If you do not assign the icon to a component, the icon will not be saved in the graphic. Only components that were not selected in the graphic will be available for selection.*

## Holidays Definition

A holiday is treated differently than other days. It is recommended to program holidays at the beginning of the year; this helps to modify floating holidays for the current year (Easter, Thanksgiving, etc.).

A holiday may be identified by a specific type (Hol 1, 2, 3, 4). The same day may be defined as a holiday at one site, but as a regular day in another site. Holidays may also be defined as global holidays or by Gateway.

- 1 From the Definition window, select the Holiday icon. The Holiday window appears.

- 2 To create a new holiday, select the New icon.
- 3 To create a global holiday, proceed with the holiday definition. If you want to define a holiday for a specific gateway/site, select the gateway/site from the drop-down list.
- 4 Assign a name to the holiday.
- 5 From the Date pull-down menu, select a the holiday date from the calender.
- 6 Check the Recurring option if this is the case for the holiday you are defining.



**NOTE:** If the holiday is not a recurring holiday, you will have to reprogram it for the following year. You can program holidays years in advance; but it is recommended to review holidays on a yearly basis.

- 7 In the Holiday type section, select the type of the holiday you are defining. This gives you flexibility when defining a holiday. For example, you may decide that a given day is a holiday for a certain group of users, but it is a regular day for another group.

---

## Chapter 7 • Operations

Under the Operations tab, operators will be able to perform manual operations on various system components (gateway, site, controller, etc.). Manual operations are used to override schedules or process special requests, when necessary. When you launch a manual operation on a component, it is possible to view the status of the selected components in real-time. You can also edit components by accessing the component directly from the operation window.

## The Operations Toolbar

The Operations toolbar, located at the top of the Workstation window will allow you to access all operation dialogs (gateway, site, controller, etc.), where you will be able to perform manual operations such as manually resetting or monitoring devices, disabling readers, etc.



## The Operation Dialogs Toolbar

All operation windows have a series of icons in the toolbar. Series of icons will only appear in specific operation windows. The five buttons described below appear in all operation windows.


Icon	Description
	<b>Select All</b> is used to select all the items or components displayed in the list.
	<b>Unselect All</b> is used to unselect all the items or components that were previously selected in the list.
	<b>Enable Graphic</b> displays the image related to the selected component (i.e.: door) and will also display the associated components (i.e.: reader). To display in real-time, this button must be used with the <b>Enable animation</b> button.
	<b>Enable Animation</b> will automatically enable the <b>Enable graphic</b> button. This will activate the current component (i.e.: door) and will display its status in real-time.
	<b>Help</b> will open the On line help corresponding to the window you are currently navigating.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

# The Operations Contextual Menu

You will be able to access a contextual menu by right clicking within the list in any operation window.




The items in the popup menu correspond to the icons in the operation window toolbar. Three options have been added to the popup menu, when you access it from the Gateway, the Site, the Guard Tour State or the area operation window.

- **State:** Opens a status window that contains the current information corresponding to the component you selected in the list. For more details, see *"The Component Status Window"* on page 226.
- **Edit:** Opens the window corresponding to the selected component to allow editing.
- **Extended selection box:** Opens the Extended selection box dialog that allows you to search for a specific component.

## The Component Status Window

A message window that contains the gateway, guard tour state, area status and site messages can be accessed by right-clicking within the corresponding operations window under the Operation tab, and selecting Status in the contextual menu.





In the example above, the information is listed for a Global gateway . We have listed some of the information that can appear in that window.




Parameter	Description
Gateway status	Indicates if the gateway is connected or not.
Number of sites/loops	Indicates the number of sites/loops for this gateway.
Number of cards	Indicates the number of cards processed by this controller
Number of processes	Indicates the number of processes
Total RAM memory	Indicates the total amount of RAM memory on the disk.
Free memory	Indicates the total amount of available disk space.
Total RAM disk space	Indicates the total amount of RAM.
Free RAM disk space	Indicates the total amount of available RAM.
Jumper J3	Indicates the J3 status. <b>Present:</b> Jumper J3 is active <b>Absent:</b> Jumper J3 is not active (may be missing from the board)
Jumper J2	Indicates the J2 status. <b>Present:</b> Jumper J2 is active <b>Absent:</b> Jumper J2 is not active (may be missing from the board)
Version	Indicates the software and hardware version number.
eBoot Version	Indicates the eBoot version number.
Local Time	Indicates the controller's current local time.
Last startup	Date the last system startup was performed.



***NOTE:** The information displayed in the status window corresponds to your configuration and will be different whether you access it from a gateway, a site, a guard tour or an area operations window.*

## Manual Operations on the Gateway

Three manual operations can be performed on the gateway: reload data, soft reset and hard reset.


Button	Definition
	<b>Soft reset:</b> will not affect the database. This command sends new information to a gateway to update its physical components (relays, inputs, doors and outputs).
	<b>Hard reset:</b> will erase the existing gateway database and reload it with new information. Reset commands should be executed with caution. Before you carry out a gateway reset operation, we recommend you contact our Technical Support. For more information, see "Technical Support" on page 4.
	<b>Reload data:</b> to refresh system parameter with new data from the system database.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

## To Select a Gateway

- 1 From the EntraPass workstation main window, select the Operations tab and click the Gateway button to open the Gateway dialog where all the gateways connected to your system will be listed.



**NOTE:** Please see Chapter 17 "Sites and Gateways" on page 579 for a definition of the icons in the Gateway window.

## To Perform a Soft Reset

- 1 Select the gateway for which you want to perform a soft reset.
- 2 Click the Soft reset button. This command will send new information to the gateway to update its physical components (relays, inputs, doors and outputs).

## To Perform a Hard Reset



**NOTE:** Reset commands should be executed with caution. Before you carry out a controller reset operation, we recommend you contact our Technical Support. For more information, see "Technical Support" on page 4.

- 1 Select the gateway for which you want to perform a hard reset.
- 2 Click the Hard reset button. This command will erase the existing gateway database and reload it with new information.

## To Reload Gateway Data

Entrapass allows operators to reload data in order to refresh system parameters with new data from the system database. When should you reload a gateway?

- After major changes in the system database such as new cards, new devices, modification of component definition, definition of new schedules;
- When one or more controller(s) is malfunctioning (when it does not receive data for instance).

After a reload operation, the gateway reorganizes the data received and communicates the new data to all the sites and controllers.



**NOTE:** *Communication with controllers is suspended during a reload operation.*


- 1 Select the gateway for which you want to reload the data.
- 2 Click the Reload data button. Gateway data will be updated.

# Manual Operations on Sites

The manual operations on site feature is used to poll unassigned controllers. For example, when a controller has been added in the system without a serial number, you can use this command to get the controller serial number. This feature applies to Corporate and Global Gateways only.

## To Perform Manual Operations on a Site

- 1 From the Operation window, click on the Site icon to open the Site window, then select the gateway to which the site is connected.










- 2 To poll a controller that is not assigned, click the Controller icon. A message is sent to an unassigned controller, asking it to identify itself. When the controller receives the call from the site, it sends an acknowledgement message in the Message desktop.
- 3 You may select the Message desktop to view the controller serial number.



**NOTE:** The % column shows the communication performance of a selected site. If the percentage is too low (below 75% for instance), it may indicate that the site is not communicating efficiently. Communication problems may stem from various reasons such as interferences, damaged cables, etc.

## Communication Options Available from the Toolbar

Icons	Description
	<b>Connect to remote site:</b> Click to connect to a remote site using a pre-configured dial-up connection.
	<b>Disconnect remote site:</b> Click to <b>close</b> the connection between this EntraPass workstation and the remote site.
	<b>Force disconnect site:</b> Force disconnect remote site immediately, even when the system is reloading.
	<b>Disable remaining time:</b> Click to stay connected until clicked again. This action disables preset connection remaining time. This action bypasses any idle time.
	<b>Update remote site:</b> After selecting site, click to connect and update parameters.
	<b>Update all remote sites:</b> Click to connect and update parameters on all sites starting with the first site on the list.
	<b>Remove site from connect and wait list:</b> Select a site then click to suspend connection after all sites had been set for update.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

## Communication Status Messages Available in the List

The messages in the list area of the dialog indicate the site/loop communication status. In the following example, you will see communication status messages for KT-NCC, Global and Corporate Gateways.

### KT-NCC and Global Gateways










Message	Description
Site/Loop Communication OK	All controllers on the loop communicate with the gateway.
Site/Loop Communication Trouble	At least one controller on the loop is not communicating with the gateway.
Site/Loop Communication Failure	None of the controllers on the loop can communicate with the gateway.
Site/Loop Communication Cannot be Opened	The gateway cannot open the communication port.

Corporate Gateways

Message	Description
Site Communication OK	All site controllers can communicate with the gateway.
Site Communication Trouble	At least one of the site controllers can't communicate with the gateway.
Site Communication Failure	Communication failed between the site controllers and the gateway.
Site Communication Cannot be Opened	The gateway cannot open the communication port.

## Manual Operations on Controllers

This dialog is used to reset or reload a controller: soft reset, hard reset, reload and reload controller firmware.

Button	Definition
	<b>Soft reset:</b> will not affect the controller database. This command sends new information to a controller to update its physical components (relays, inputs, doors and outputs)
	<b>Hard reset:</b> will erase the existing controller database and reload it with new information in the controller database Reset commands should be executed with caution. Before you carry out a controller reset operation, we recommend you contact our Technical Support. For more information, see <i>"Technical Support" on page 4.</i>
	<b>Reload:</b> will reload the controller database; if for example a controller database is not reloaded correctly due to an erratic operation
	<b>Reload controller firmware:</b> will reload the firmware of the controller (KT-NCC, KT-100, KT-300)
	<b>Unlock reader keypad:</b> will unlock the reader keypad for KT-100 and KT-300 controllers.
	<b>Reset reader power:</b> will reset the controller reader power. This operation can only be performed on KT-300.
	<b>Forgive:</b> will reset to zero the cards-in and cards-out counters
	<b>Cards-in:</b> displays the number of cards in per controllers
	<b>Cards-out:</b> displays the number of cards out per controllers.




**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.



## To Select a Controller

- 1 From the Operations window, select the Controller icon to open the Controller window where you will be able to reset the controller.



- 2 From the Gateway/Site pane, select a gateway or site. Controllers attached to this gateway/site appear in the right-hand pane.
- 3 From the Controller list, select the controller where the operations will take place. It has to be highlighted. To perform the operation on a group of controllers, select Controller Group (lower right-hand pane).



**NOTE:** If only one site or gateway is defined in the system, the Site Controller or Gateway list pane will not appear on the Controller window.

## To Perform a Controller Soft Reset

A soft reset will refresh the data in the controller.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Soft reset icon in the toolbar. This command will send new information to the controller to update its physical components (relays, inputs, doors and outputs, etc.)

## To Perform a Controller Hard Reset

A hard reset will delete the existing controller database and reload it with new information in the controller database.



**NOTE:** Reset commands should be executed with caution. Before you carry out a controller reset operation, we recommend you contact our Technical Support. For more information, see "Technical Support" on page 4.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Hard reset icon in the toolbar. This command will send new information to the controller to update its physical components (relays, inputs, doors and outputs, etc.)

### To Manually Reload a Controller

EntraPass allows you to reload a controller database when, for example, a controller database is not reloaded correctly due to an erratic operation.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Reload icon in the toolbar. The controller's database will be reloaded.

### To Manually Reload a Firmware Controller

EntraPass allows you to reload a controller firmware database for KT-100, KT-NCC and KT-300. You will perform a firmware reload after a system or firmware upgrade.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Reload controller firmware icon in the toolbar.

### To Manually Unlock a Reader Keypad

EntraPass allows you to unlock the reader keypad for KT-100 and KT-300 controllers from a workstation.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Unlock reader keypad icon in the toolbar.

### To Manually Reset a Reader Power

EntraPass Global Edition allows you to reset a KT-300 controller reader power.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Reset reader power icon in the toolbar.

### To Calculate the Number of Cards In and Cards Out

If you have one or more controllers configured with anti-passback, this function allows you to view a list of cards that are considered inside (Cards in) or outside (Cards out) an area. To do so, the passback option (either soft or hard synchronization) has to be enabled on the reader and the door has to be defined as an entry or exit door.

- 1 In the Controller dialog, select desired controller or controller group.
- 2 Click the Cards in or Cards out icon in the toolbar. The system will display the number of cards in or cards out for the selected controller or controller group.

*NOTE: This operation is performed only on one controller at a time as it may be a lengthy operation. The option is only available on a Corporate Gateway.*







### To Reset the Cards In and Cards Out Counters

This option allows to reset to zero for the cards in and cards out counter.

- 
- 1 In the Controller dialog, select desired controller or controller group.
  - 2 Click the Forgive icon in the toolbar. Card holders will not be considered inside or outside until the next use of their card at an entry or exit reader.

## Manual Operations on Doors

This dialog allows an authorized operator to manually modify the state of a door or group of doors. Operators can manually lock/unlock a door, temporary lock/unlock a door or group of doors, and enable/disable readers on selected doors.

Button	Definition
	<b>Lock door or group of doors:</b> will manually lock the selected door or group of doors.
	<b>Unlock door or group of doors:</b> The selected door or group of doors will be manually unlocked and will remain unlock until the next valid change of the unlocking schedule or an operator manually locks the door or group of doors
	<b>Temporarily lock/unlock door or group of doors:</b> Temporarily unlocks a door or group of doors for a preset delay. Once the delay expires, the door or group of doors re-lock automatically.
	<b>Return to schedule:</b> Will re-apply a schedule after a manual operation was performed on a component.
	<b>Enable card reader:</b> will enable a previously disabled door reader.
	<b>Disable card reader:</b> will disable a door reader and user will not be able to access that door, even if they have access rights.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.


There are various reasons why you would want to perform one of these operations; for example you may need to “disable a reader” for a short period in order to deny access to the door, etc.

This operation allows an operator to lock a door that was previously unlocked by an operator or a schedule. When a door is manually locked through the Operation menu, it remains locked until:

- The presentation of a valid card (will re-lock after access), or
- The next valid change of the automatic unlocking schedule (for a door defined with an unlocking schedule), or
- An operator manually unlocks the door.

## To Select a Door or a Door Group

- 1 From the Operations window, select the Door icon. The Door window appears.



- 2 Click the **Enable animation** icon to view a real-time display of the door status.
  - The left-hand pane displays the list of all Sites/Gateways. You may select all or select one site/gateway.
  - The individual doors associated with the site/gateway selected on the left are displayed in the top right side of the pane. If you select **All** on the left, all doors in the system will be listed on the right. You can select one, several or all doors.



**NOTE:** If only one site or gateway is defined in the system, the site or gateway list window will not appear on the Controller window.

- Door groups associated to the site/gateway tselected on the left are displayed at the bottom right side of the pane. If you select **All** on the left, all door groups in the system will be listed at the bottom right. You can select one or several or all groups.

## To Lock a Door Manually

- 1 In the Door dialog, select desired door(s) or door group.
- 2 Click the **Lock-door** icon in the toolbar.

## To Unlock a Door Manually

- 1 In the Door dialog, select desired door(s) or door group.
- 2 Click the **Unlock-door** icon in the tool bar. The selected door(s) will be manually unlocked. The system will prompt for operator confirmation. A door defined with an automatic unlocking schedule will remain unlocked until:
  - The next valid change of the unlocking schedule, or
  - An operator manually locks the door.


## To Unlock a Door Temporarily

EntraPass allows you to temporarily unlock a door for a preset delay. Once the delay expires, the door re-locks automatically. You can use this option in cases where you need to grant access to a user who does not have a card or has forgotten his/her card.



**NOTE:** The maximum unlock time: 4:15 (255 seconds).

- 1 Click the **Temporarily unlock** icon. The **Change delay on action** dialog will popup.
- 2 Enter the **New time** delay (m:ss) and click **OK**. The selected door will be temporarily unlocked by an operator.



**NOTE:** If a door contact is installed, the door will re-lock as soon the system sees a “door open-door closed” transition. There is no “Animation” for this type of operation.

## To Reset a Door Schedule

EntraPass allows you to reset a door schedule after a manual operation has been performed on a component.

- 1 In the **Door** dialog, select desired door(s) or door group.
- 2 Click the **Return to Schedule** button. This option will reset the schedule for the selected components.

## To Enable a Door Reader

- 1 In the **Door** dialog, select desired door(s) or door group.
- 2 Click the **Reader-enable** button. This option enables a previously disabled door reader.

## To Disable a Door Reader









- 1 In the **Door** dialog, select desired door(s) or door group.
- 2 Click the **Reader-disabled** button. This option disables a previously enabled reader. Disabling a reader prohibits users from accessing the door, even if access rights have been granted.

# Manual Operation on Elevator Doors

This dialog allows an authorized operator to manually lock, unlock or temporarily unlock elevator floors. The window will also display, in real-time, the status of the selected elevator door(s).

## How Elevator Access Is authorized

- The cardholder pushes an “up/down” button, the elevator door opens,
- The cardholder presents its card at the reader (usually inside the cab),
- The system checks if the schedule assigned to this door is valid. If yes, the system checks which floor group is associated to this door,
- Then the system verifies each floor of the floor group (in the floor group menu) and checks if the schedule associated to each floor of the group is valid or not valid.
- Only floors that have a valid schedule will be available for selection by the user (the elevator panel will enable the buttons corresponding to the floors).


Button	Definition
	<b>Lock elevator floor or group of elevator floors:</b> will manually lock the selected elevator floor or group of elevator floors.
	<b>Unlock elevator floor or group of elevator floors:</b> The selected elevator floor or group of elevator floors will be manually unlocked and will remain unlock until the next valid change of the unlocking schedule or an operator manually locks the elevator floor or group of elevator floors.
	<b>Temporarily lock/unlock elevator floor or group of elevator floors:</b> Temporarily unlocks an elevator floor or group of elevator floors for a preset delay. Once the delay expires, the elevator floor or group of elevator floors re-lock automatically.
	<b>Return to schedule:</b> Will re-apply a schedule after a manual operation was performed on a component.
	<b>Enable card reader:</b> will enable a previously disabled reader.
	<b>Disable card reader:</b> will disable a reader and users will not be able to access any elevator floor, even if they have access rights.
	<b>Enable elevator floor:</b> will enable a previously disabled elevator floor or floor group.
	<b>Disable elevator floor:</b> will disable an elevator floor or floor group and users will not be able to access that elevator floor or floor group, even if they have access rights.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

## To Select an Elevator Door

- 1 From the Operations menu, select the Elevator door icon.



- 2 Click the Enable animation icon to view a real-time display of the elevator door status.
  - The left-hand pane displays the list of all Sites/Gateways. You may select all or select one site/gateway.
  - The individual elevator doors associated with the site/gateway selected on the left are displayed in the top right side of the pane. If you select **All** on the left, all elevator doors in the system will be listed on the right. You can select one, several or all elevator doors.
  - Elevator door groups associated to the site/gateway selected on the left are displayed at the bottom right of the pane. If you select **All** on the left, all elevator door groups in the system will be listed at the bottom right. You can select one or several or all elevator door groups.

## To Lock Floors from Elevator Doors

- 1 Select an elevator door or a group of elevator doors.
- 2 Click the Lock icon in the toolbar. This command will manually lock the floor group that was previously unlocked by an operator or a schedule.



**NOTE:** A door defined without an unlocking schedule will only be locked by a manual command. To lock all floors that were previously unlocked, use the Unlock option in the Manual operation on doors menu.

## To Unlock Floors from Elevator Doors

- 1 Select an elevator door or a group of elevator doors.
- 2 Click the Unlock elevator floors icon in the toolbar to unlock a previously locked floor. This command will only enable the elevator floors that are defined with an "X" in the "State" column



of the Floor group Definition menu. If you do this, the system will prompt the you to select a floor group that should be unlocked (available). Once the group is selected, the system will prompt the operator to confirm the operation.



**NOTE:** For a door defined with an “automatic unlocking schedule”, floors will remain available until:

- The next valid change of the unlocking schedule, or
- An operator manually locks the door.



**NOTE:** A door defined without an unlocking schedule will only be locked by a manual command. To lock all floors that were previously unlocked, use the Unlock option in the Manual operation on doors menu.

**NOTE:** When a manual unlocking operation is completed, only floors that are defined with an “X” in the “state” field of the Floor Group Definition menu will be available for selection. Also, when communication is lost and the controllers are working in stand-alone mode, only the floors marked with an “X” will be available for selection and the access schedule will be ignored.


## To Temporarily Unlock Floors from Elevator Doors

EntraPass allows you to temporarily unlock a floor from an elevator door for a preset delay. Once the delay expires, the elevator door re-locks automatically.



**NOTE:** The maximum unlock time: 4:15 (255 seconds).

- 1 Click the Temporarily unlock icon. The Change delay on action dialog will popup.
- 2 Enter the New time delay (m:ss) and click OK. The selected elevator floor will be temporarily unlocked by an operator.



**NOTE:** This command will only temporarily enable the elevator floors that are defined with an “X” in the “State” column of the “Floor group Definition menu” (available for selection).

**NOTE:** There is no “Animation” for this type of operation. To temporarily unlock all floors, use the “temporarily unlock door” option in the “manual operation on doors” menu.

## To Reset an Elevator Door Schedule

EntraPass allows you to reset an elevator door schedule after a manual operation has been performed on a component.

- 1 In the Elevator door dialog, select desired elevator door(s) or door group.
- 2 Click the Return to Schedule button. This option will reset the schedule for the selected components.

---

### To Enable an Elevator Floor

- 1 In the Elevator floor dialog, select desired floor(s) or floor group.
- 2 Click the **Enable elevator floor** button. This option enables previously disabled elevator floors or floor group.





### To Disable an Elevator Floor

- 1 In the Elevator door dialog, select desired floor(s) or floor group.
- 2 Click the **Disabled elevator floor** button. This option disables a previously enabled elevator floor. Disabling a floor prohibits users from accessing the floor, even if access rights have been granted.

## Manual Operations on Relays

Use this menu to manually change the state of a relay or group of relays. You can activate/deactivate and temporarily activate relays or group of relays manually. The window will also display, in real-time, the status of the selected relay(s).

This feature allows to manually turn off a relay; for example, when an input programmed to activate a relay goes in alarm in unknown conditions.


Button	Definition
	<b>Deactivate relay:</b> allows an operator to deactivate a relay which was previously activated by an operator, event, schedule or input in alarm.
	<b>Activate relay:</b> activate a relay which was previously deactivated by an operator, event, schedule or input in alarm.
	<b>Temporarily activated relay:</b> Temporarily activate a relay or group of relays for a preset delay.
	<b>Return to schedule:</b> Will re-apply a schedule after a manual operation was performed on a component.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

### To Select Relays

- 1 From the Operation window, select the Relay icon.



- 2 Click the Enable animation icon to view a real-time display of the relay status.
  - The left-hand pane displays the list of all Sites/Gateways. You may select All or select one site/gateway.

- The individual relays associated with the site/gateway selected on the left are displayed in the top right side of the pane. If you select **All** on the left, all relays in the system will be listed on the right. You can select one, several or all relays.
- Relay groups associated to the site/gateway selected on the left are displayed at the bottom right side of the pane. If you select **All** on the left, all relay groups in the system will be listed at the bottom right. You can select one or several or all groups.

## To Manually Deactivate a Relay

- 1 Select a relay or a group of relays.
- 2 Click the Deactivate Relay icon.




**NOTE:** If you manually deactivate a relay that is usually activated according to a schedule, it will remain deactivated until its reactivation schedule becomes valid. This means that if a relay needs to be activated according to a schedule and you deactivate it, remember to reactivate it again for the remaining scheduled time, because one relay can be defined for various components of the system; its activation or deactivation will relate to its configuration within these components.

## To Manually Activate a Relay

- 1 Select a relay or a group of relays.
- 2 Click the Activate Relay icon. The selected relay(s) will be activated. This operation allows an operator to activate a relay which was previously deactivated by an operator, event, schedule or input in alarm.


## To Activate a Relay Temporarily

- 1 From the Operation window, select the Relay icon.



- 2 In the left-hand pane, you may select a site or gateway, or you may select **All Relays** to display all the relays.

- 3 In the right-hand pane, you may select a relay in the upper part of the window, All Relays in the lower part of the window.
- 4 Click the Activate relay temporarily icon. The Change delay on action window will popup on screen.
- 5 Enter the New time delay (m:ss) and click OK. The selected relay will be temporarily activated by an operator.



**NOTE:** The selected relay(s) will be temporarily activated. This is useful for an operator who would like to activate temporarily a relay which was previously deactivated by an operator, event, schedule or input in alarm. The system displays a message box requesting that a temporary activation delay, is entered. When this delay is over, the relay will be deactivated automatically.





## To Reset a Relay Schedule

Entrapass allows you to reset a relay schedule after a manual operation has been performed on a component.

- 1 In the Relay door dialog, select desired relay(s) or relay group.
- 2 Click the Return to Schedule button. This option will reset the schedule for the selected components.

## Manual Operations on Inputs

This dialog allows you to bring an input back to its normal state, or to stop monitoring an input, or monitor a specific input at all times, or to perform a temporary shunt on a selected input, if it had been previously modified from its original state as setup in the Device menu.


Button	Definition
	<b>Input normal:</b> returns an input to its normal state as setup in the Device menu.
	<b>Input continuous supervision:</b> will monitor the selected input at all times.
	<b>Input with no supervision</b> will terminate the input monitoring, regardless of its schedule, and will start monitoring with the next pre-defined schedule.
	<b>Input no supervision temporarily (Shunt):</b> will stop input monitoring for a pre-set period of time.



**NOTE:** A hint is displayed when you move your cursor over a button. It gives details about the operation to be performed.

### To Perform Manual Operations on Inputs

- 1 From the Operation window, select the Input icon.



- 2 Click the Enable animation icon to view a real-time display of the relay status.
  - The left-hand pane displays the list of all Sites/Gateways. You may select All or select one site/gateway.

- The individual input associated with the site/gateway selected on the left are displayed in the top right side of the pane. If you select All on the left, all inputs in the system will be listed on the right. You can select one, several or all inputs.
- **Input groups** associated to the site/gateway selected on the left are displayed at the bottom right side of the pane. If you select All on the left, all input groups in the system will be listed at the bottom right. You can select one or several or all input groups.

## To Manually Return an Input to its Normal State

This option is used in cases where an input status has been modified by an operator and you want to return the input to its normal state. For example, if an input is assigned a monitoring schedule in its definition and an operator has reversed the state of the input making it “not supervised”, it can be returned to its normal state using this button.

- 1 Select an input or a group of inputs.
- 2 Click the **Input normal** icon. The selected input returns to its normal state as defined in the Device menu.

## To Setup Continuous Input Supervision

You will use this feature to monitor an input at all times. This option can only be setup manually.

- 1 Select an input or a group of inputs.
- 2 Click the **Input continuous supervision** icon.

## To Stop Monitoring an Input


You will use this option to terminate the input supervision, regardless of its schedule (if defined).

- 1 Select an input or a group of inputs.
- 2 Click the **Input no supervision**. The selected input will not be monitored.

## To Temporarily Stop Input Supervision (Shunt)




You will use this option when you want the system to bypass a specific input, for a specific period of time.

- 1 To temporarily shunt an input, select the input, then click the **Temporarily shunt** icon. The input will not be monitored temporarily.
- 2 Click the **Input no supervision temporarily**. The Change delay on action dialog will popup.
- 3 Enter the **New time delay** (m:ss) and click OK. An icon next to the input will indicate that it is temporarily shunt. If an alarm occurs, or if the input is disconnected, no message will be sent to the desktop Message list.



## Manual Operations on Alarm Systems

This menu allows you to manually change the state of an alarm system. You can arm, disarm or modify the postponement delay time of an alarm partition. The Alarm systems menu is only used under Global and NCC8000 Gateways.

Button	Definition
	<b>Arm alarm:</b> will automatically arm an alarm system when the arming delay is over.
	<b>Disarm alarm:</b> will automatically disarm the selected alarm system.
	<b>Alarm postpone:</b> will automatically postpone the delay time of an alarm system while the alarm system is in "postpone mode".


You can also visualize the remaining time for the entry, exit, arm request or arm postponement delays, under way for any of the alarm partitions.



**NOTE:** It is not possible to "postpone" an alarm partition from this window, it can only be done at a reader using a card.

### To Perform Manual Operations on an Alarm System

- 1 From the Operation window, select the Alarm system icon.



- 2 Click the Enable animation icon to view a real-time display of the relay status.
  - The left-hand pane displays the list of all system gateways. You may select All or select an individual gateway.



- The individual alarm system associated with the gateway selected on the left are displayed in the right pane. If you select All on the left, all alarm systems will be listed on the right. You can select one, several or all alarm system.

## To Manually Arm an Alarm System

This option is used to automatically arm the alarm system when the arming delay is over. For more information on arming alarm systems, see *Chapter 6 "Definitions" on page 193*

- 1 Select a gateway or an alarm system.
- 2 Click the **Arm alarm** icon. The selected alarm system will automatically be armed.

## To Manually Disarm an Alarm System

This option is used to disarm the selected alarm system. The system will disarm automatically. For more information on disarming alarm systems, see *Chapter 6 "Definitions" on page 193*.

- 1 Select a gateway or an alarm system.
- 2 Click the **Disarm alarm** icon. The selected alarm system will automatically be disarmed.




**NOTE:** If a “no disarm” schedule is effective and an operator disarms the system, the alarm system's exit delay will activate before the partition arms automatically. After the exit delay, the alarm system will arm again if there is no postpone and if the “no disarm” schedule is still valid.

## To Manually Modify the Alarm System Postponement Delay

This option is used to modify the postponement delay time of an alarm system while the alarm system is in “postpone mode”.



- 1 Select gateway or an alarm system.
- 1 Click the **Alarm postpone**. The Change delay on action dialog will popup.
- 2 Enter the New time delay (m:ss) and click OK. The selected alarm system postponement delay will be modified. Maximum allowed: 16 hours.



**NOTE:** This operation will not “decrement” the postpone count allowed.

## Guard Tour State

This dialog allows the operator to initiate, modify the delay allowed between stations, modify the next station and end a guard tour. The Guard tour dialog can only be used with Global Gateways.

Button	Definition
	<b>Start guard tour:</b> must be clicked to start the guard tour.
	<b>End guard tour</b> must be clicked after the last station of the tour has been visited by the guard.

Guard tours are used to allow guards to perform tours while being monitored by the system. Events will be generated at each visited stations.

These tours consist of different stations that must be triggered within a certain time, otherwise the system will give an alarm event. These stations can either be readers or inputs.



**NOTE:** Guard Tours can only be initiated and ended from the manual operations of the system.

### To Start a Guard Tour

- 1 From the Gateway List drop-down menu, select the gateway where the guard tour is defined.
- 2 Select the guard tour you want to start from the Guard tours list. Once you have selected the guard tour, click on the “Start Guard Tour” button. The system will display a card-selection window:
- 3 Select the cardholder who will be responsible for the guard tour. A card has to be chosen in order to initiate the guard tour. If doors are defined in the guard tour definition, then a card will have to be presented at the defined reader(s) and this cardholder must also have access to the doors. Once you have selected a cardholder and clicked OK, the system will display the Guard tour window.



**NOTE:** Please, remember the following:

- During a tour, using the “modify” button will reset the time allowed between two stations.
  - Only one (1) guard tour can be run at a time per gateway.
  - A tour must always be completed with the command “End guard tour” entered by the operator after the system displays the “Last station in guard tour” message.
  - During a tour, if the delay is almost expired, using the “modify” button will reset the time allowed between two stations.
- 4 Click More to display extended information on the selected guard tour. The system will display the stations to be visited as well as the delays from stations to stations. This button can be used only when a guard tour has been started.

- 5 Click the **Start guard tour** icon to start the guard tour sequence. Guard tours can only be initiated from this window. You can also assign a schedule that will generate the event “Guard Tour Scheduled” to warn operators or remind them that the guard tour must be started.
- 6 Click the **End guard tour** icon to end the guard tour sequence. When the last station has been visited, the system will generate the event “Last station in guard tour”, then the “end guard tour” button must be used. Once you end a guard tour, the system generates the event “Ending of a guard tour”.
- 7 Click the **End guard tour** button will also cancel a guard tour that has started.

The following icons are displayed in the right-hand. They provide additional information on the guard tour:




- **Previous station**—Provides information (text and picture) concerning the previous station (door or input) that the guard triggered.
- **Next station**—Provides information (text and picture) concerning the next station (door or input) to be triggered.
- **Delay to next station**—Indicates the time remaining for the guard to reach the next station. If this time expires, a warning will be displayed.
- **State**—Displays the guard tour state. The possible states are:
  - **Normal**—when the guard tour is normal.
  - **Pre-alarm**—For example, if the delay programmed for a specific station is set to 2:00 minutes, and this delay expires, the system will generate the event “Guard tour station late”, then the system will initiate the pre-alarm delay. After this delay expires, the system will then generate the “Guard tour alarm” event and the status will change to alarm.
  - **Alarm**: When the pre-alarm delay is over and the guard tour is in alarm.
- **Modify next station**—This option allows the operator to modify the next station, for the guard tour currently in progress.
- When you modify the next station, the system will generate the event “Guard tour sequence modified”.
- **Modify delay to next station**—This option allows the operator to modify the time remaining for the guard in order to reach the next station. This modification only affects the guard tour currently in progress.



**NOTE:** When you modify the next station, the system will generate the “Guard tour late time delay modified” event.


## Manual Operation on Areas

This feature is used to empty cards that are in an area to the unknown area and/or move selected cards to a specific area. The Area dialog can only be used with Global Gateways.

Button	Definition
	<b>Get card list:</b> will list all the cards in the selected area, after the filter and sorting criteria have been defined.
	<b>Empty area:</b> Will move the cards in the selected area into the unknown area.
	<b>Move only selected card:</b> will move the selected cards to a specific area.

You can also display supervisor cards, invalid cards or all the cards located in a specific area.

- From the Gateway list, select a gateway to view an area.



- Select an area from the left-hand pane (for example, Cards in area), the system will automatically display:
  - the number of cards that are currently located in the selected area (all cards, supervisors and invalid).
  - the number of supervisor cards that are currently located in the selected area (assigned with a supervisor level).
  - the number of invalid cards that are currently located in the selected area. A card is invalid because the schedule assigned to the cardholder's access level does not authorize the cardholder to remain inside the selected area.
- From the Filter drop down list select an item, then click the Refresh button to display detailed information on the selected item.

- **Cards in Area**—If selected, the system will display all the cards located in the selected area. The card total will be displayed under the “gateway list” field.
- **Supervisor Cards in Areas**—If selected, the system will display all the supervisor cards (assigned with a supervisor level) located in the selected area. The card total will be displayed under the “gateway list” field.
- **Invalid Cards in Area**—If selected, the system will display all the cards located in the selected area. The card total will be displayed on the top left-hand of the window (all cards, supervisors and invalid). When a card is invalid, it means that the card access level is no longer good. If for example, a user remains in an area longer than the period of time he is allowed, his card will become invalid and he will no longer be able to exit the area.



---

## Chapter 8 • Users

The Users menu allows you to easily manage the EntraPass cardholder database.

The Users toolbar icons start the following tasks:

- Define and issue cards as well as to perform card-related tasks (find, modify or delete existing cards),
- Design and print badges,
- Define and manage card access groups,
- Define access levels,
- Define and issue visitor cards,
- Define card types,
- Define and issue day passes,
- Modify groups of cards,
- Import or export CSV files.

The Integrated Badging feature was added to EntraPass to allow users to design and print badges. Pictures and signatures can be imported or, with the necessary devices, captured and incorporated into cards for printing badges.

## Cards Definition

Cards are defined by the following properties: card number, cardholder name, access level and status (valid, invalid, pending, lost/stolen). Cards records can be searched, sorted and deleted.

The Users menu is used to:

- Create and issue new cards
- Modify or delete existing cards
- Define multiple cards (by creating a group of cards)
- Assign access levels and pictures, etc.

### To Issue a New Card

- 1 From the Users menu, select the Card icon. The displayed Card window is used to enter/verify general information on the cardholder.

- 2 Click the New icon (first icon) in the toolbar. The Card number field is enabled.
- 3 Enter the number printed on the card (Card number field), then press Enter. If it is a new card, the Card user name field is initialized with "New user". If the card already exists, the system displays information about the card.
- 4 Enter the cardholder's name in the Card user name field. You can enter up to 50 characters.
- 5 Check the Copy to visitor card checkbox. When this option is checked, card information fields are copied to the Visitor database (the card number is not copied). This feature enables you to archive profiles that are retrieved should you issue a temporary card.
- 6 Click on the Card type box to access the Card type menu. Select the card type for the new card. The card type is used to group cardholders; it is useful for modifying an existing card group and



creating reports, etc. For more information on how to create/modify card types, see "Card Types Definition" on page 316.



**NOTE:** From the Card type window, you can right-click the Card type field and choose New to create a new card type, choose Select to pick an existing card type or you can choose Edit to edit an existing card type.

**NOTE:** The system automatically displays the Creation date, the Modification date and the Modification count information.

- 7 Fill out the Information #1 to #10 fields. These are user definable fields. They are used to store additional information regarding the cardholder. For example, you could use Information #1 to store the employee number; Information #2, department; Information #3, the address, etc. Later, card information fields are used to index reports, customize the cardholder lists, etc.




**NOTE:** These information fields are editable labels. To rename an information field label, double-click it, then enter the appropriate name in the displayed fields. You can enter up to 50 characters.

- 8 Click the Save icon.

## To Create New Cards Using the "Save as" Feature

The Save as feature allows you to create a new card based on an existing card, only making changes to specific information. For example: changing only the user name and keeping all other card information.


- 1 Type required changes into specific fields in the Card window and click the Save as icon. This feature allows you to create a new card under a new card number.
- 2 Enter the new card number in the New card number field.
- 3 Select the Keep/Delete original card options to specify if the original card should be kept or deleted (usually kept), then click OK to save the new information. The Card window is displayed.



## To Issue Cards Using the Batch Load Feature

The Batch Load feature allows operators to issue cards by presenting cards to a door reader. The card number is displayed on an "unknown card" or "access denied" event messages. During a Batch Load operation, the operator can create new cards or modify existing ones.

- 1 From the Card window, click the Batch Load button.




- 2 From the Door drop-down list, select the Door that will be used to read the cards.
- 3 Check the following options:
  - Refresh an access granted: if this option is checked, each time an access is granted the information displayed will be refreshed with data relative to the card.
  - Save on new card: if this option is checked, new cards will be saved in the card database on an “unknown card” event message. If this box is not checked, the operator will have to save the card manually each time a card is read.



**NOTE:** The Find button allows operators to search for an existing card in order to create a new card based on the existing card data.

**NOTE:** If an operator clicks the Close button without saving (when the Save button is still enabled), a system prompt will ask to save the last information.

- 4    Right click the Door drop-down list to expand your search.




To View and Verify PINs

Entrapass enables you to view and verify cardholders' PINs in the Card and Visitor windows.

To View Cards Assigned the Same PIN

- 1    From the Card or Visitor window, click the List of PIN owners button.



- 2 Enter the PIN number in the Enter your PIN field.



***NOTE:** If the system is set to PIN duplication (*Options > Server Parameters*), and if the PIN is used by more than one cardholders, the system displays a list of cardholders who are using the PIN. This feature is useful when for example you want to display the list of cardholders who are using a given PIN or if you are issuing new cards and you want to verify which PINs are already being used.*

## Cards Handling

### To Edit a Card

- Enter the card number in the Card number field and press Enter. The system displays the card; you may then modify the card as required.
- Browse the Card number field using the Up/down arrows and then select the card to be modified.
- Browse the Card user name field, using the Up/down arrows.

### To Find a Card

You can perform two types of card searches:



Per card information



Per card user name.



**NOTE:** For more information on how to search information in EntraPass, see "To Find a Card" on page 52

### To Delete a Card

The Delete feature allows an operator to remove a card from the cardholder database. A card that has been deleted from the cardholder database must be re-issued again in order to use it again.

- 1 Locate the card you want to delete: to locate the card, you may enter the card number in the Card number field and press the Enter key or you may browse the Card number or Card user name fields using the up/down arrows.
- 2 Click the Delete icon, then click Yes in the Warning message box.




**NOTE:** Although a deleted card is removed from the card database, it remains in the card history; all events involving that card remain in the event messages database. An event report locating past events that involved any deleted card can be performed.

### To Customize Card Information Fields

You may rename Card information fields according to your organization requirements. These fields can contain any information. They can be used as edit boxes or drop-down lists.

- 1 In the Card definition menu, select any card, then double-click the Card information field. The system displays the Change labels window:



- 2 Select the field you want to modify and enter the name in the language section. For example, if you want to rename *Card Information #1* to *Employee number*, double-click the *Card Information #1* label; it appears in the language section, then enter the new name in the language section.
- 3 Select the *Edit field* option if the information appears as an *Edit field* (one-line information) or *Drop-down list* (as applicable); then click *OK* to save your modifications.
- 4 You need to repeat these steps for all the fields you want to modify.



**NOTE:** Check *Mandatory field* to ensure a field is not left empty.

**NOTE:** The changes you make are not immediately effective. They will take effect only when you exit and then re-enter the Card menu.

**NOTE:** An operator must have full access privileges to edit card information fields. An operator with read only access may only view information in these fields.

## Cardholder Access Levels Assignment

An access level must be assigned to each card. Access levels determine where and when the card will be valid. The access level allows the cardholder entry to selected locations during specified schedules.

For information on defining access levels, see *"Access Levels Definition"* on page 313.




**NOTE:** When you modify the access level assigned to a card, you also modify the user's access permission to the doors and schedules associated to that access level.

In order to assign an access level to a card, you have to:

- Create schedules that will correspond to the time the user has access to the desired doors,
- Assign the created schedule to the desired doors (in the Access level definition menu),
- Assign the access level to cards.

### To Assign an Access Level to a Cardholder

- 1 From the Card definition window, select the Access level tab. The Access level window appears, it displays the Gateway/Site column and Access level drop down list.



- 2 Click the Card access group button (displayed on the left of the Site or Gateway list). It is used to copy information from a Card access group to a card. The Gateway/Site column displays the sites and gateways to which an access level will be associated.
- 3 From the Access level drop-down list, select the access level that will determine the cardholder's access to the doors of the selected site. If you do not want this cardholder to have access to the door of this site, leave this field to None.



**NOTE:** You have to create Access levels (*Users > Access Level*) to have them displayed in the Access Level drop-down list.

---

## To Assign Additional Access Levels (Global/KT-NCC/NCC 8000 Only)

You can also assign up to six more additional access levels and use an expiration date for each additional access level so as to restrict access to certain doors after the date is reached (button displayed on the right).



**NOTE:** When the controller is operating in “stand-alone” mode, these access levels are no longer valid, only the main access level will be valid. The button will display a “green” indicator when additional access levels are assigned.



## Card Use Options Definition

Use the Miscellaneous tab to specify and view card additional information.

- 1 Select a card number using the Up/down arrows. The Start date field indicates the card creation date. You can change this information by selecting another date in the displayed calendar. The start date must be the same day or earlier than the current date; else, the Card state field (Miscellaneous section) will be set to "Pending".

The screenshot shows the 'Card' window with the 'Miscellaneous' tab selected. The window has a title bar 'Card' and a standard Windows toolbar. Below the toolbar, there are fields for 'Card number' (4252812), 'Card user name', and 'Card type'. To the right, there are fields for 'Creation date' (2003-09-11), 'Modification date' (2003-09-11), and 'Modification count' (0). Below these fields are tabs: 'General', 'Access level', 'Miscellaneous' (selected), 'Comment', 'Usage', and 'Picture'. The 'Miscellaneous' tab contains several sections: 'Card validation date' with 'Start date' (2003/09/11) and a calendar icon, and a checkbox for 'Use end date'; 'PIN parameters' with a checkbox for 'Wait for keypad', 'Editable pin number' (00000), and 'PIN' (262144); 'Miscellaneous' with a 'Card state' dropdown (Valid), checkboxes for 'Card trace', 'Disable passback', and 'Extended door access delay' (checked); and 'Supervisor parameters' with a checkbox for 'Privileged operation' and a 'Supervisor level' dropdown (0). At the bottom are 'Close', 'Cancel', and 'Help' buttons.

- 2 Check the Use end date box if applicable. When this box is checked, the system displays a calendar allowing you to select the end date. When the end date is reached, the Card state field is set to "Expired".



**NOTE:** When creating a card with a limited access time of 24 hours or less, for example a *Day Pass*, the card will expire at midnight. This expiration may take up to one minute to register in the system.

- 3 Check the Delete when expired option (if applicable). This option can only be used with the Use end date option. When selected, the card information will automatically be deleted on the expiry date (using the end date specified), otherwise the Card state field will be modified to "Expired".



**NOTE:** A deleted card is a card that is not active in the system database. Even if a card was deleted, previous events generated by this card are still stored in the archive file.

- 4 Check the Wait for keypad option to force users to enter a PIN on keypad to access all doors, then in the Editable PIN field enter the PIN that users will be required to enter.



**NOTE:** Selecting the *Wait for keypad* will delay access to a door for this card until the correct PIN has been entered on a keypad. This only affects doors defined with both reader and keypad in the Door Definition menu (*Devices > Doors*). The keypad schedule must also be valid for this door. For more information on defining a door, see "Doors Configuration" on page 126.

- 5 From the Card state drop-down list, assign a state to the selected card. By default, a card is valid. The following states are available:
  - Valid: the card is functional,
  - Invalid: the card is NOT functional,
  - Lost/Stolen: the card is NOT functional,
  - Expired: the card has reached its expiry date,
  - Pending: the card is not yet functional.



**NOTE:** You cannot force a card state to *Pending* by selecting this state from the *Card state* drop-down list. To do so, you have to change the *Start date*.

- 6 Check the Card trace option if you want to monitor the use of a particular card. Selecting this option will cause the “Card traced” event to be generated each time this card is presented to a card reader. For example, you can request and generate a report containing the “card traced” event in order to verify user actions.
- 7 Check the Disable passback option if you want the card to override the passback option when defined.



**NOTE:** If you are issuing a card for a cardholder with disabilities, check the *Extended door access delay* option. To enable this option in the system, you have to define appropriate delays in the *Door definition*. This option is also available when defining visitor cards.

- 8 Set Supervisor level according to user privileges.



**NOTE:** If required check the *Privileged operation* option to override any security measures regarding doors.

## To Add Comments to a Card

- 1 From the Card window, select the Comment tab.

- 2 Enter a comment (if necessary) relative to this cardholder. The displayed field can be used to store additional information in the database. Maximum allowed: up to 241 characters.
- 3 Click the **Save** button, then the **Close** button to exit.

## To Limit Card Usage

EntraPass offers the ability to set card use count options so that you may limit the number of times a card can be used.

- 1 From the Card window, select the **Usage** tab.

The screenshot shows the 'Card' window with the 'Usage' tab selected. The 'General' tab is also visible. The 'Card number' field contains '4252812'. The 'Card user name' field contains 'Martin Userman'. The 'Card type' field contains 'Operator'. The 'Creation date' is '2003-06-19', 'Modification date' is '2003-06-26', and 'Modification count' is '7'. The 'Usage' tab is selected, showing the 'Enable usage restriction' checkbox checked. The 'Card count value' is '0'. The 'Card count options' is '0', and the 'To be reset to zero' checkbox is checked. The 'Close', 'Cancel', and 'Help' buttons are at the bottom.

- 2 Check the **Enable usage restriction** option in order to enable the card use count feature.
- 3 From the **Card count value** scrolling list, set the maximum number you want this card to be used. You may enter the number in the field or use the **Up/down** arrows.



**NOTE:** Once you set the *Card count value*, the *Card count options* field is automatically incremented each time the cardholder uses the card. After a certain number of uses, you may check the *Reset to zero* field if you want the counter to be reset to zero when the maximum value is reached.


## To Assign Pictures and Signatures

EntraPass offers the ability to associate photos and signatures with cardholders and to associate badge templates with cards as well as to print badges.

Photos and signatures can be retrieved from files, pasted from the clipboard, or captured using an appropriate device. To capture video images, use any MCI and TWAIN compliant device. For capturing signatures, signature pads such as Topaz, Penware TTI500 and Penware TT3100 are recommended.

## Assigning a Picture from a File

- 1 From the Card window, select the Picture tab.



- 2 Right-click the picture area. A shortcut menu appears; choose the appropriate action:
  - Get picture from file: this option allows you to select a previously saved picture.
  - Paste picture: this option allows you to paste a picture from the clipboard. To use this option, you have to copy the picture, then paste it into the picture window.



**NOTE:** The Video capture option is enabled only when a video capturing device is installed.

- 3 From the Files of type drop-down list, select the file type you are looking for or leave this field to All to display all image files. Make sure that the Auto displayer option is selected to enable preview.



**NOTE:** Files with the following extensions are supported: BMP, EMF, WMF, JPG, GIF, PNG, PCD, and TIF.

- 4 Select the directory where the image is stored. Select the image you are looking for, then click Open to import it into the Card window.



**NOTE:** To delete the imported picture, right-click the picture, then choose *Clear picture* from the shortcut menu.


## Assigning a Picture Using a Video Camera

The Video capture option is enabled only when the option Enable video capture is checked: Options > Multimedia devices > Video tab.




**NOTE:** Before you can capture images using a video camera, all equipment needs to be properly configured. For more information, consult your manufacturer's device manual. If you have more than one video driver, you will need to specify the video driver to be used (Options > Multimedia devices > Video tab).

- 1 Right-click the picture area.



- 2 From the shortcut menu, select Video capture. This option is enabled only when the Video capture capability has been enabled in the Options menu (Options > Multimedia devices > Video).



**NOTE:** Options may vary depending on the video capture program. If you have more than one video driver, you will need to specify the video driver you are using. For more information on configuring your video drivers, see "Multimedia Devices Configuration" on page 470.

- 3 Click the Freeze button when you are satisfied with the displayed image, then click the Capture button to paste and save the displayed image.

- 4 To associate a badge layout with the defined card, select one from the Badge layout list. For information on how to define a badge layout, see "Badges Designing" on page 281.




**NOTE:** The *Print badge* and *Preview badge* buttons are enabled only when a badge printer and badge layout has been selected and the option *Use badge printer* checked: *Options > Printer > Badge printer*. If these buttons are enabled, you can preview and print the cardholder's badge.

## To Import a Signature from a File

You can import a signature, just as you import other images such as logos or pictures into the card.


1 From the Card window, right-click the signature area. A shortcut menu appears.



- 2 From the shortcut menu, make the appropriate choice:
- Get signature from file: allows you to select a previously saved signature,
  - Paste signature: allows you to paste a signature that was previously copied to the clipboard. The option is enabled when there is content in the clipboard.



**NOTE:** The *Signature pad* option is enabled only when the appropriate device is enabled in the Options menu (Options > Multimedia devices > Signature).



3 Select the signature file, then click Open.


### To Add a Signature from a Signature Capture Device

Use this option if a Signature Capture Device is installed and configured. The Signature pad option is enabled only when the appropriate device is enabled in the Options menu (Options > Multimedia devices > Signature).

- 1 From the Card window, right-click the signature area. A shortcut menu appears.



- 2 From the shortcut menu, select **Signature pad**. The Signature window appears, allowing you to preview the signature.
- 3 Click OK to paste the signature in the card window.



## To Work with Photos and Signatures


The Entrapass Integrated Badging feature allows users to extract part of an image or enhance images that are incorporated into cards.

### Extracting Part of an Image

If you have incorporated a large image but you need only part of it, you can select and extract the part that you want to assign to the card (picture, signature).




- 1 Right-click the image you have just imported.




**NOTE:** The *Extract* option is enabled after you have started the selection mode. Similarly, the *Undo* option is enabled only when an image has been pasted.

- 2 Select *Start selection mode* from the shortcut menu.



**NOTE:** You can increase the size of the selection rectangle by dragging its sides and corners to adjust to the part of the image you want to extract. You can also move it by dragging it to the desired area of the image.

- 3 Once you have selected the part you want to incorporate into the card, right-click the image again. A shortcut menu appears.




**NOTE:** To disable the current selection, right-click the picture, then select *Cancel selection mode*. Select *Undo* to discard the changes. The *Undo* option is enabled only when you have pasted an image.

- 4 From the shortcut menu, select Extract.


## Editing a Picture/Signature

- 1 Right click the image you want to edit.



**NOTE:** The Barcode area allows you to assign a barcode to a badge for identification purposes. Select any item from the drop-down list to be used as the value of the barcode. Select *Custom* to enable the Value field and type a specific barcode value. If you do not enter a custom barcode value, the Card number is used as the default value.

- 2 From the shortcut menu, select Edit (picture or signature).



- 3 Adjust the features of the image using the displayed options. The Reset all option enables you to go back to the original image:

- **Auto contrast:** this feature gives better contrast by intensifying lights and shadows: it makes the darks darker and the lights lighter. In general, this auto contrast feature gives a good result when a simple contrast adjustment is needed to improve an image's contrast.
  - **Sharpen:** this feature provides more definition to blurry images by applying sharpening only when an edge is found.
  - **Brightness:** this feature allows you to add light to the image by sliding towards the positive values.
  - **Reset all:** this feature allows you to undo all the changes and to restore the original image.
- 4 Click OK to close the Picture editing window.
  - 5 From the Badge layout pull-down menu, select a layout to associate with the card you have defined To define a badge layout, see *"Badges Designing"* on page 281.


## To Print Badges

You may print badges, visitor cards and daypasses from a Card or from all Badge preview windows. The software is set up to let you print one single or double-sided badges.

Before you print, you have to select a badge printer. It may be any network printer, or a specific badge printer.

## Selecting a Badge Printer

- 1 From the EntraPass Workstation window, select the Options tab, then click the Printer Option button.
- 2 From the Printer option window, select the Badge printer tab.



**NOTE:** You can print badges to any network printer. However, to print badges on appropriate cards, you have to select a badge printer.


- 3 Check the Badge printer option to indicate to the system that a badge printer is selected. If the Badge printer option is checked, the Print badge and Preview badge are displayed in windows where you can print badges (Card, Visitor, and Daypass windows).
- 4 From the Select badge printer drop-down list, select the printer dedicated to badging.

- 5 Adjust the margins:
- Origin offset, X axis: indicates the left margin.
  - Y axis indicates the upper margin.

Previewing and Printing Badges

The Badge - Preview and Print window allows you to preview a badge layout with card information (if the badge layout is associated with a card) or with default values (if the template is not yet associated with a particular card). The program permits you to print single or double sided badges.

- 1 From the Card, Visitor or Daypass window, click the Preview badge button.



**NOTE:** From the Badge design window, the preview option allows you to view a badge with default values since there is no card associated with it (*Badge design > Layout > Preview*).

- 2 From the Badge - Preview and Printing window, choose a printing option:



- **Print front side:** only the front side (preview in the left-hand pane) is printed.
- **Print back side:** only the back side (preview in the right-hand pane) is printed. This button is enabled only when the badge is defined with two sides.
- **Print both sides:** the front and back side are printed. This button is enabled only when the badge is defined with two sides.




**NOTE: Important! In Order** to print badges with barcodes, your printer has to be properly set. You have to select the “black resin” option, otherwise, barcode readers may not detect the barcode. If you have problems with barcode printing or reading, refer to your printer manufacturer’s manual.

# Badges Designing

Entrapass contains a badge layout editor which enables users to create, save, edit or delete badge templates that are later selected and associated with cards for badge printing. You can create and edit badge templates, add colored or graphic backgrounds, logos, text, barcodes, and place photo or signature holders.

## To Create a Badge Template

- 1 From the Users menu, select the Badge icon. The Badge window appears.




**NOTE:** The Badge window contains all the tools available in other Entrapass windows: new, save, copy, delete, print, links, search (the Hierarchy button is disabled). However, it contains an additional 1-2 button which allows to modify the number of sides assigned to a badge layout.

- 2 Click the New icon in the toolbar. The Badge properties window appears.

## Specifying Properties for a Badge Layout


- 1 In the Badge properties window, indicate the number of sides for the badge, then select the desired size for the badge layout, then click OK.



- 2 Indicate the number of sides for the badge, then select the desired size for the badge layout, then click OK.



**NOTE:** Measures are expressed either in inches or millimeters (a hundredth of an inch or a tenth of a millimeter). To change the unit of measure, check the appropriate radio button in the Units section.



- 3 Enter the name for the badge template in the language fields. You can enter up to 40 characters.



- 4 You may check Set as default card layout if you want this new design to be automatically used for all new badges.



**NOTE:** Only one default layout is available. When you select one layout and check the option *Select as default card layout*, the current default layout is replaced.

- 5 Click the Save icon to save the badge template.

### Editing a Badge Layout


The Badge design utility allows users to edit the badge layout, to add background color or graphics, to modify the font, etc.




**NOTE:** Once a card layout is created, you cannot modify its size; you have to create a new layout. However, you can modify the number of sides by clicking on the *Sides* icon in the *Badge* window toolbar.

### Modifying the Number of Sides

- 1 From the badge window, select the badge you want to edit.




- 2 From the Badge window toolbar, click the 1-2 button.



- 3 Click the Save icon to save the new badge information.


## Modifying the Background Color

- 1 From the Badge window, select the badge you want to modify.
- 2 Click the Click here to modify the card layout button (located in the lower part of the window) to open the Badge design window.




**NOTE:** When you move the cursor over the Badge design objects, a hint explaining each object appears.

- 3 To modify the template background color, right-click anywhere in the work area. The Properties shortcut menu appears.



- 4 Select Properties. The Background properties window appears.



- 5 Select the appropriate options for the template:
  - **No background** (default setting)
  - **Use color as background:** this option will allow you to apply a background color to all the designs.
  - **Use image as background.** This option allows you to incorporate an image that will be displayed as a watermark in all the badges.

- Orientation: allows you to select a landscape (horizontal) or portrait (vertical) display.

### Adding Objects to a Badge Layout

By a simple click and drop feature, the Badging utility permits you to incorporate objects into the badge template:


- Card fields information,
- Barcodes,
- Text boxes,
- Current date,
- Previously saved images and logos (BMP, JPG, GIF, etc.),
- Border,
- Rectangle (including rounded rectangle, ellipse),
- Line, pointer,



***NOTE:** Objects are incorporated with their default settings. To modify an object's properties, right-click the object, then select appropriate settings from the shortcut menu.*

### Incorporating Card Information Fields

- 1 To add card information fields to the badge template, click the Card fields icon. The Card fields submenu appears.




- 2 To modify an object property before you drop it, go to Options in the Badge design window, then choose Show properties on drop. If you do this, the Properties window will open every time you drop an item in the template work area.



**NOTE:** To enable last and first name selection in the Card fields menu of the Badge design window, go to the *Options* menu, then choose *Server parameters*, choose select the *User name format* tab, check *Parse user name* checkbox, then select the name (first or last name) that will be used for sorting cardholders' names. For more information see "EntraPass Options" on page 461.

- 3 From the shortcut menu, select the card information field you want to add to the template layout, then click in the template work area to incorporate that field you have selected.


Card number
Card user name
Card information 1
Card information 2
Card information 3
Employed number
Card information 5
Card information 6
Card information 7
Card information 8
Card information 9
Card information 10
Start date
End date
Card type
Picture
Signature
Last name
First name



**NOTE:** When you add a photo to a badge design template, the photo that appears is only a placeholder. It indicates where the cardholder's photo will be displayed. When a badge is assigned to a card, the appropriate cardholder's photo is displayed.

## Aligning Objects in the Template Layout

Grids assist you in aligning items in the badge layout template. It can be used as a visual aid to place items on gridlines.



Three options are available to help you align your objects in the badge template:

- **Show gridlines:** displays grid points to aid with object alignment.
- **Align to grid:** must be activated before you start building your template. As you “click and drop” design objects in the template work area, they will be “snapped” to the nearest grid mark.
- **Grid settings:** allows you to specify the horizontal (Height) and vertical (Width) grid spacing (in pixels).



**NOTE:** To disable the grid unselect Show gridline in the *Align* menu.

## Modifying Card Fields Properties

Objects are incorporated in the template with their default settings (font, color, etc.). You can modify the settings later. For example, you can modify the appearance of any text object, such as card field, static text, date, etc.

- 1 From the Badge design template, right-click the object you have inserted (in this example, Card information fields).






2 From the shortcut menu, select Card fields properties.



*NOTE: The Properties menu item depends on the selected item. For example, it will change to Image properties or Current date properties, depending on the selected object.*



3 From the Card fields properties window, you can modify all the text properties:

- Font (name, color, style (bold, italic, underline)),
- Background (transparent or solid with a color),
- Justification (horizontal, vertical),
- Orientation,
- Parameters (word wrap, for example).




*NOTE: The **Set as default** checkbox allows you to apply all the characteristic to all text objects that will be incorporated in the template.*

*NOTE: When Text Orientation is set to "Other" it is not possible to resize the field.*


## Modifying Picture Properties

This applies to any picture object such as photos, logos, and signatures.

- 1 From the Badge design work area, right-click the image (picture, logo) or signature that you want to modify.



- 2 From the shortcut menu, select Images properties.




- 3 You may select another image from file or modify the image properties:
  - Stretch ratio: select this option if you want the image to be centered in the image holder space, while keeping the proportion of the original image.
  - Transparent mode: if you choose this option, there is no background color,
  - Draw frame: select this option if you want a frame around the picture object,
  - Frame color (enabled when a Frame option is selected): select this option if you want to apply a specific color to the image frame. The Frame color drop-down list enables you to select a custom color from the frame.

- 4 You may check the Set as default option if you want these properties to apply to all image objects you add in the badge template.


Adding Static Text Objects

- To add text objects to a badge, first click and drop a text box, then enter the text in the Text properties window. It is also in the Text properties window that you modify the text appearance.
- 1 From the Badge design tool bar, click the text icon. To resize the text box, select it and use the two-headed arrow to drag the sizing handles to the desired position. This also allows you to change the height and width of the text box.



- 2 To align the text box, see *"Aligning Objects in the Template Layout"* on page 289.

- 3 To add text to the text box, right-click the text box, then select Static text properties from the shortcut menu.




- 4 Enter text in the Enter text field; then modify the text properties as desired. The Preview section shows the result of the changes you apply to the text.

## Adding Bar Codes

The Badging feature allows users to add bar codes to badges. By default, the barcode value is the card number, if no other value is specified.


- 1 From the Badge design window, click the Barcode icon, then click in the Badge design work area.



- 2 To align the barcode, see *"Aligning Objects in the Template Layout"* on page 289.

## Setting Up Barcode Properties

- 1 From the Badge design window, right click the barcode to open the Barcode Properties window.



Supported Encoding Options:  
Code 39 or Code 39-Modulo 43  
POSTNET  
Codabar  
EAN 8 & EAN 13  
UPC A  
UPC E  
Code 2 of 5  
Interleaved 2 of 5  
Code 128

- 2 From the Properties window, you can define settings for the barcode that you want to incorporate in the Badge design.




**NOTE:** If it is necessary to set *Barcode encoding option* to *Code 39-Modulo 43*, set *Field Checksum* to *true*.

## Adding The Current Date

You add the current date just as you add any other design item by selecting the item in the tool bar, then by clicking in the Badge design work area.


- 1 From the Badge Design template, select the Current date icon, then click in the Badge design work area.



- 2 Right-click the current date to display the shortcut menu.



- 3 To align the current date, see *"Aligning Objects in the Template Layout"* on page 289.
- 4 Select Current date properties from the shortcut menu.






- 5 From the Current date properties window, you can:
- Select the date format (top of the window)
  - Change the text properties: font, color, justification, orientation etc.

### Adding An Image


Background images can be imported from any directory. Scanned images, photos taken with a digital camera and artwork created in any illustration design program can be incorporated into the badge design.

- 1 From the Badge design window, select the Picture icon.




**NOTE:** The Badging feature supports most available image formats: BMP, JPG, EMF, WMF, GIF, PNG, PCD, and TIF.

- 2 Drop the Picture icon in the template work area. The Image properties window appears.




- 3 Click the **Select image from file** button. The Open window appears, allowing you to select an image.



Click the zoom button to increase the size of the image in the preview pane

- 4 Browse to the desired image, then click Open. The picture appears in the template area.




**NOTE:** When you import an image, you have to resize it to its original size as illustrated on the following image.

- 5 Using the sizing handles, adjust the image to the desired size, then move it to the right-hand position; you can use the grid to align it properly. For more information, see *"Aligning Objects in the Template Layout"* on page 289.
- 6 Right click the image to modify its properties. For details, see *"Modifying Picture Properties"* on page 291.

## Placing Other Design Objects

The Badging feature lets you add borders, rectangles (regular, rounded, ellipse), lines and pointers, just as you add any other design object, by a click in the toolbar, then a drop in the design work area.


- 1 From the Badge design window, select the object you want to add (next to the Diskette icon), then click in the Badge design work area” The Border properties window opens.



- 2 To modify the border properties, select the border color, the border style, and the border width. You may check the Set as default option, then click OK to exit.

## Placing a Rectangle

- 1 From the Badge design window, select the rectangle tool (next to the Border tool), then click in the work area.



**NOTE:** This applies also to rectangles, rounded rectangles and ellipses.

- 2 From the Rectangle properties window, you may define the rectangle properties before importing it:
  - Line color,
  - Line style,
  - Background (brush style and brush color).

## To Validate Card Access

The Validate card access feature lets you view access levels that are assigned to a particular cardholder.

- 1 From the Card window, select a card.

- 2 From the Card window toolbar, click the View and Validate Access button (the key icon in the toolbar).

- 3 From the Select specific value section, select the date, time and the door on which the validation is required. The system displays the access levels for the selected door as well as the schedules assigned to the displayed access levels. The Access Level column displays the access levels associated with the selected door. The Schedule column displays the schedule associated with the access level.
  - Red—Indicates that access to the selected door on the selected date and time is not allowed (not authorized).
  - Green—Indicates that access to the selected door on the selected date and time is allowed (authorized).

## Cards Printing

Use the Print feature to print a specific range of all the cards that are stored in the database. You can select various filters to customize the card list.

You can preview your list so that you can modify or verify the settings (fields) before printing.

You can also use the Font button to set a different font and font size for your report.



**NOTE:** Whatever your selections, the card user name and card number will always be displayed. By default, only fields containing information will be printed. If no fields are selected, only cards containing information will be printed. If you want to print empty fields, check the *Print empty fields* option. If you want to simply preview card reports there must be at least one printer installed on the computer.

### To Print Cards

- 1 From the Card window, click the Printer icon.



**NOTE:** By default, empty fields are not printed. To print empty fields, check the *Print empty fields* option.

- 2 Select a sorting criteria from the Card Index drop-down list. These are card information fields.
- 3 If you are printing a specific range, check the Specific range option. Select the field that will be used to sort the card list. For example, if you select Card number, the cards in the list will be sorted according to the card numbers in ascending order. This field can also be used to target a specific range of cards when using the Lower/Upper boundaries fields.

- If you want to print a specific range, you have to specify a starting number in the **Lower boundary** field. It has to be used with the **Upper boundary** field. You must use the “card index field”.
- If you have decided to print a specific range and if you have entered a **Lower boundary** value, enter the last number or letter in the **Upper boundary** field. This field is used with the **Lower boundary** and the **Card Index** field.




**NOTE:** Only cards that match ALL the selected filters will be printed. For example, if you specify six filters, all the six criteria must be met. Cards that do not match all the six criteria will not be included in the range.

- 4 Select the **Filter** option if you do not want the system to search through all the cards of the system. Filters will restrict the search and facilitate the production of the desired card list.
  - **Start date between**—The system will include cards with a “Start date” field which is within the specified range (Miscellaneous tab).
  - **End date between**—The system will include cards with a “Use end date” field which is within the specified range (Miscellaneous tab).
  - **Card state**—Check the option and then select the desired state. The system will include cards that have this card state selected in the Card window (Miscellaneous tab).
  - **Card type**—Check the option and then select the desired card type. The system will include cards that have this card type selected in the Card window.
  - Select the **Exist trace** for the system to include cards that have the “Card Trace” option in their definition (Card window, Miscellaneous tab).
  - Select the **Exist comment** option for the system to include cards that have information in the **Comment** field in their definition (Card window, Comment tab).
  - Select **Exist PIN**—The system will include cards that have a PIN.
  - Select **Exist delete when expired**—The system will include cards that have information in the **Delete when expired** field (Card window, Miscellaneous tab).
  - Select **Exist wait for keypad** for the system to include cards that have information in the **Wait for keypad** field (Card window, Miscellaneous tab).
- 5 You may also check the **Print selected fields** to include specific data. If you select this field, no other fields below, the system will print the cards that match the filters you specified above with the card number and user name only.




- 6 Click the Select door access filter button if you want to include cards associated to a door.



- 7 Select the Based on time option if you want to select cards according to the time or select Based on schedule if you want to select cards according to a defined schedule.



*NOTE: To extend the selection, right click within **Select door for access filter** window.*



- 8 Check the appropriate field you want to print. The system will include the field content as it appears in the card definition.

- 
- 9 You may save the list as a.QRP file (Quick Report) to view later using the Quick Viewer option.
  - 10 You can also use the “Font” button to use a different font and font size for your list. The changes will appear automatically in the sample box. Use the Preview button from the print window to preview your report.

## Last Transactions Display

The View last transactions feature lets you view the most recent transactions for the selected cardholder. For example, the window will display “Access denied” as the type of event, and will display the date and time as well as the event message that was displayed in the Message desktop. The system displays the 15 most recent transactions for each category:


- Access denied events (bad location, bad access level, bad card status, etc.),
- Access granted events,
- Database events (that have affected the database, such as: card definition modified, relay definition modified, etc.),
- Other/Miscellaneous events (these include events that were generated by cardholders),
- Time and Attendance events (entry, exit).



*NOTE: To view more transactions for a specific category, see the “Card use report” option in the menu Historical Report definition menu.*

### To View the Last Transaction

- 1 From the card definition window, select the View last transaction icon.



Type	Date and Time	Event message	Details
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-10-19 11:3...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-11-02 14:4...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-11-14 10:5...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Access denied	2000-11-14 11:0...	Access denied - Bad access level	(01.01.01) 01 - 01 - 01 - Administration Works
Database	2000-10-12 17:1...	Card definition modified	Administration Workstation KANTECH
Database	2000-10-12 17:1...	Card definition modified	Administration Workstation KANTECH
Database	2000-10-17 15:0...	Card definition modified	Administration Workstation KANTECH
Database	2000-10-17 15:0...	Card definition modified	Administration Workstation KANTECH
Database	2000-10-24 15:1...	Card position manually modified	Administration Workstation KANTECH

- Type—Displays the event category.
- Date and time—Displays the date and the time stamp of the event message.
- Event message—Displays the event message that was sent to the server (and to the authorized Entrapass workstation) when this event occurred. This is the same message as in the Message desktop (Desktop menu).
- Details—Displays additional details directly related to the type of transaction. For example, for a “card definition modified” event message, the Details column lists the Entrapass applications from which the card was modified as well as the operator name.

- **Refresh**—This button can be used to refresh the window with new transactions as they happen. As cardholders generate events, new information is available.
- **Parent**—To view the parent component of a selected component. For more information, see *"Basic Functions" on page 50*.
- **Print**—Use this button to print an exact copy of the window. For more information, see *"Basic Functions" on page 50*.

## Card Access Groups Definition


Pre-programmed card access groups allow quick selection of access levels for various sites of the system. This card access group can be recalled during card programming instead of re-entering the access levels for each site.

It is only the card access group information that is associated with the card. Therefore, you can modify the card access group information without modifying the card access information.



**NOTE:** When importing cards, the *Card access group* may be used to assign an access level to the cards.

- 1 From the card definition window, click the access group icon.



Gateway / Site	Access level
01 - (2) Security Office Global Gateway	None
01 - (3) Global Gateway	None
01 - NCC Windows Gateway	None
Accounting	None
Administration	None
Security Office Corporate Site	None

- 2 To modify an existing card access group, select it from the Card access group drop-down list. To create a new group, click on the New button and enter the group name in the language section. The Site column displays the site associated with a card access group.
- 3 From the Access level drop-down list, select the primary access level that will determine the access to the doors of the selected site.

- 4 To select a secondary access level for a gateway/site, click the square icon next to the Access level column, for the gateway/site you want to configure.



**NOTE:** When the controller is operating in “stand-alone” mode, the secondary access levels are no longer valid, only the primary access level will be valid.

Access level	Use date	Expiration date
Always valid, all doors ▼	<input checked="" type="checkbox"/>	2006-02-25
None ▼	<input type="checkbox"/>	2006-02-2
None ▼	<input type="checkbox"/>	2006-02-2
None ▼	<input type="checkbox"/>	2006-02-2
None ▼	<input type="checkbox"/>	2006-02-2
None ▼	<input type="checkbox"/>	2006-02-2

Calendar: 25 février 2006

di	lu	ma	me	je	ve	sa
			1	2	3	4
5	6	7	8	9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28				

- 5 Select the Access level type in the scroll list.
- 6 If you need to setup and expiration date for the secondary access level, click the Use date box and click the Expiration date field where a calendar will popup.



**NOTE:** The Access level button will display a “green” indicator when additional access levels are assigned.

## Access Levels Definition

Access levels determine where and when the card will be valid. Pre-programmed card access groups allow quick selection of access levels for various gateways. A total of 250 access levels can be programmed per site and per gateway (Global/NCC 8000 Gateways).


In order to assign an access level to a card, you have to:

- Create schedules that will correspond to the time the user has access to the desired doors
- Assign the created schedule to the desired doors (in the Access level definition menu)
- Assign the access level to a card.



**NOTE:** The default access level is *Always valid, all doors*: cardholders assigned this default access level have access to all doors at any time. To restrict access to certain doors and at a certain time, you have to create a specific access level.

- 1 From the Users menu, select the Access level icon. The Access level window appears.



Door	Schedule	Floor group
(01.01) Corp Site #1 TCP/IP KT-300 #1 entry	Always valid	None
(01.02) Corp Site #1 TCP/IP KT-300 #1 exit	Always valid	None
(02.01) 01 - Corp Site #1 TCP/IP KT-300 #2	Always valid	None
(02.02) 02 - Corp Site #1 TCP/IP KT-300 #2	Always valid	None
(03.01) 01 - Corp Site #1 TCP/IP KT-300 #3	Always valid	None
(03.02) 02 - Corp Site #1 TCP/IP KT-300 #3	Always valid	None
(04.01) 01 - Corp Site #1 TCP/IP KT-300 #4	Always valid	None
(04.02) 02 - Corp Site #1 TCP/IP KT-300 #4	Always valid	None



**NOTE:** You can click the *Hierarchy* button (next to the *Printer* icon) to display the gateway list.

- 2 From the Access level drop-down list, select New access level, then assign a meaningful name to the access level you are creating.

Door	Schedule	Floor group
(01.01.01) Front Door	None	None
(01.01.02) Back Door	None	None
(02.01.01) Controller#1 Door#1	None	None
(02.01.02) Controller#1 Door#2	None	None
(02.02.01) Controller#2 Door#1	None	None
(02.02.02) Controller#2 Door#2	None	None
(02.03.01) Controller#3 Door#1	None	None



**NOTE:** Components that are displayed in the Doors, Schedule or Floor group column have to be defined for selection in the Access level definition. To define Doors: *Devices > Sites > Doors*. To define Schedules: *Definition > Schedules*. To define Floors groups: *Groups > Doors*.

- 3 From the Doors list, select the doors to which the cardholder has access.
- 4 From the Schedule column, select the schedule during which the cardholder will have access.
- 5 Select the floor group, if applicable.




## Visitor Cards Definition

A visitor card is issued on a temporary basis. It serves as a template for entering user information. You can create visitor cards in two ways:

- Copying the card information field into the Visitor card database when a new card or a daypass is created in the system,
- Creating a new visitor card.

### To Create a Visitor Card when Creating a New Card

- 1 Select the Card icon from the Users window. The Card window appears.




The Card window is a software interface for creating or editing a card. It features a toolbar at the top with icons for file operations and user management. The main area contains several input fields: Card Number (1219924), Card User Name (Alice), and Card Type (Administrator). There is a checkbox labeled 'Copy to visitor card'. On the right side, there are fields for Creation Date (2000-09-07), Modification Date (2000-09-14), and Modification Count (3).

- 2 Check the Copy to visitor card option. The card information will be used later for creating new cards and issuing day passes.

### To Create a Visitor Card Using the Card Template

- 1 Select the Visitor card icon from the Card window toolbar.



The Visitor window is a software interface for creating or editing a visitor card. It features a toolbar at the top with icons for file operations and user management. The main area contains several input fields: Card user name (New user), Card type, Creation date (2002-08-09), Modification date (2002-08-09), and Modification count (0). Below these fields, there are tabs for General, Access level, Miscellaneous, Comment, and Picture. The General tab is selected, showing fields for Department, Card information 2 through 5, Card information 6 through 10, and Card information 10. At the bottom, there are buttons for Close, Cancel, and Help.

- 2 Enter the required information in the Visitor card fields.



**NOTE:** For more information on Day Passes and Visitor cards, see "Cards Definition" on page 258. The Picture tab allows you to display the cardholders picture and signature as well as to preview and print badges.

## Card Types Definition

A card type is used to group cardholders and can later be used to modify an existing card group or to create reports. It can also be used to restrict access to card information for a particular operator. For example, you can restrict an operator's ability to issue or view a specific card group. For instance, if a card type is defined as "Administrators", an operator who does not have the appropriate security level will not be able to issue, view, modify, delete, or print this type of card.



**NOTE:** The system is preset with five card types: administrator, employee, security, maintenance and visitor. A card type can be assigned to a card access group. This way, if a cardholder is issued a card type associated with a card access group, the access information of the card access group will automatically be transferred to the cardholder.

### To Create a New Card Type

- 1 From the Users menu, click the Card type icon. The Card type window appears.

- 2 In the Card type window, click the New button in the toolbar and enter the necessary information in the language section.
- 3 From the Card access group to assign list, select a card access group or create one. For details about card access groups, see "Card Access Groups Definition" on page 311.
- 4 To assign a card type to a cardholder, see "Users" on page 257.


## Day Passes Definition

A day pass is issued to visitors such as contractors, employees from different divisions, customers, etc. This menu option offers an easy way to allow access to “visitors” for a single day. Even if the day pass cardholder does not return the day pass card, the card will expire the same day at 24:00, and will no longer grant access.

You can use profiles that were copied to the “Visitor definition” menu to create day passes (use the “find visitor” button). You can also use an existing day pass to create a new one.

### To Create a Day Pass

- 1 From the Users menu, select the Day pass icon. The Day Pass window appears.



The screenshot shows the 'Day pass' window with the following fields and options:

- Card number: 23.00001
- Card user name: Bob Barker
- Start date: 16/08/2005
- End date: 17/08/2005
- Card type: Maintenance
- Gateway / Site: Card access group
- Card access group: Night Shift
- Card information 1: Assigned to floors 51 and up
- Card information 2: (empty)
- Card information 3: (empty)
- Card information 4: (empty)
- Card information 5: (empty)
- Card information 6: 8377
- Editable pin number: 00000
- Extended door access delay: (unchecked)
- Comment: (empty text area)
- Copy to visitor card: (unchecked)
- Delete when expired: (checked)
- Picture / Signature tab: (selected)
- Right-Click for signature menu: (text)
- Preview badge: (button)
- Print badge: (button)
- Badge layout: Front horizontal & back vertical
- Badge print issue: 0
- Barcode: Card number
- Value: (empty)
- Close: (button)
- Cancel: (button)
- Help: (button)

- 2 You can fill out the fields or browse the card databases to the desired card. For more information, see "Users" on page 257.
- 3 Check the Copy to visitor card option if you want to save this day pass in the visitor database.



**NOTE:** For more information of visitor cards, see "Cards Definition" on page 258. The Picture tab allows you to display the cardholders picture and signature as well as to preview and print badges.

## To Create a New Day Pass Using the “Save as” Feature

The Save as feature allows you to create a new day pass based on an existing one, only making changes to specific information and assigning it new card number. You may, for example, change only the user name and keep all other card information.

- 1 From the Users menu, select the Day pass icon. The Day Pass window appears.

The screenshot shows the 'Day pass' window with the following fields and controls:

- Card number:** 23:00001
- Card user name:** Bob Barker
- Start date:** 16/08/2005
- End date:** 17/08/2005
- Card type:** Maintenance
- Gateway / Site:** Card access group
- Card access group:** (empty)
- Card information 1:** Night Shift
- Card information 2:** Assigned to floors 51 and up
- Card information 3:** (empty)
- Card information 4:** (empty)
- Card information 5:** (empty)
- Card information 6:** 8377
- Editable pin number:** 00000
- Extended door access delay:** (unchecked)
- Comment:** (empty text area)
- Copy to visitor card:** (unchecked)
- Picture / Signature:** Tabs for Picture and Signature. The Signature tab is active, showing a large area with the text 'Right-Click for signature menu'.
- Preview badge / Print badge:** Buttons for previewing and printing the badge.
- Badge layout:** Front horizontal & back vertical
- Badge print issue:** 0
- Barcode:** Card number (dropdown menu)
- Value:** (empty text field)
- Buttons:** Close, Cancel, Help

- 2 To locate an existing card, click the binoculars and select the card you want to duplicate.
- 3 Type required changes into specific fields and click the Save as icon.
- 4 You will be prompted for a new card number.

## Batch Operations on Cards

This menu is used to modify a specific card type group. For example, you could modify the “end date” of all the cards assigned the “administrator” card type. Individual fields will appear only when the appropriate check box is checked.

### To Perform Operations on a Group of Cards

- 1 From the Users menu, click the Batch operations icon.

- 2 Select a user group from the Card type drop-down list. All cards having this card type will be modified.
- 3 Select the appropriate option from the Operation with drop-down list.
  - **No notification**—The system will not notify nor request confirmation from the operator.
  - **Notification**—The system will display a window displaying the process.
  - **Notification and confirmation**—The system will display a window displaying the process and will prompt operators to confirm the operation for each cardholder having the selected card type.
- 4 Check the option you want to modify for the selected type.
  - **Card state**—If a card state is selected, the system will assign this new card state to all the cardholders of the selected card type.
  - **Supervisor level**—If supervisor level is selected, the system will set levels according to according to the values defined in the system.
  - **Card count value**—If a card count value is selected, the system will assign this value to all the cardholders of the selected card type.
  - **Trace**—If trace is selected, the system will trace all cardholders of the selected card type.
  - **Start date**—If a start date is selected, the cards will be valid only from this start date. This new date will be assigned to all cardholders having the selected card type.

- **End date**—If an end date is selected, the cards will be invalid after this end date. This new date will be assigned to all cardholders having the selected card type.
  - **Delete when expired**—If selected, the cards will be deleted when the end date specified in the Card Definition menu is reached.
  - **Wait for keypad**—If selected, all the cardholders of the specified card type will have to enter their PIN at the keypad after a valid card read, in order to permit access to the door (if keypads are defined).
  - **Card access group**—If checked, four options are provided to modify card access groups.
    - Replace card access group.
    - Update card access group.
    - Add new access level.
    - Update add access level.
  - **Card layout**—If checked, the list of card layout templates will be listed.
- 5 Click the Execute button to start the process. The system will prompt you to accept the operation.
  - 6 Click Yes if you want to continue. As soon as the process is initiated, a red indicator is displayed at the bottom left of the dialog. The indicator will remain red until the end of the process

## CSV Files Import and Export

The CSV Import/Export feature allows the ability to import or export card files that are saved in a CSV (Comma Separated Value) format. Importing/exporting data between two applications allows the ability for the two application to share data.

CSV files can be edited in most applications (Excel, NotePad, etc.).

You will use the CSV Import/Export feature if:

- You are upgrading from Entrapass DOS or WinPass 64 and you want to retrieve the cards created in these previous versions.
- Your company desires to import the card database information into the payroll system. Using the Import/Export feature will save a considerable amount of time in setting up the card holder database.
- Your company has a new database: instead of having to reprogram all the information already available in the card database, the system administrator could export the data contained in the card database (names, departments, card numbers, etc.) into a CSV file that can be imported into the target database.




**NOTE:** The CSV Import/Export feature imposes a number of rules: each field contains a specific value format that has to be respected. For example, the card state field will only accept the following values (0=valid, 1=invalid, 2=stolen/lost).

To Import/Export card information, you may use Kantech pre-defined patterns or you may create your custom patterns. Two patterns are available: the Entrapass (1,2,3) and the WinPass 64 models. You may use the Kantech template “as is” or you may edit it.

### To Use a Predefined Pattern

Two patterns are available: the Entrapass (1,2,3) and the WinPass 64 model. You may use the template “as is” or you may edit it.

- 1 From the Users menu, select the Import/Export CSV button.




- 2 From the Select operation drop-down list, select either Import or Export.

- 3 In the Available Patterns pane, select the pattern you wish to use. This depends on the software you are upgrading from.
- 4 Use the Edit button if you want to edit the pattern.


## To Create a New Import/Export Pattern

This menu lets you create your own import/export mask that will be used to import or export CSV files.

- 1 From the Users menu, select Import/Export CSV File icon. The system displays the Import / Export CSV file window.



- 2 From the Import/Export CSV file window, click New Pattern. The New pattern window displays a list of all the fields that are available in the EntraPass card databases. They contain specific value formats that have to be respected. For example, the card state field will only accept the following values (0=valid, 1=invalid, 2=stolen/lost).






- 3 Using the **Hand** buttons, select the fields you wish to include in your pattern. The **Transaction** code and the **Card number** fields are displayed by default. Once the fields are selected, you can use the red **Up/down** red arrows to organize information (this will indicate how information will be arranged in the CSV file).
- 4 Specify the **Add** code and **Modification** code. These codes are used by the system to identify, when importing a file, which card has to be modified or added to the card database. Default add code is "+" and default modification code is "+".
- 5 Select the **Delete** code. This code is used by the system to identify, when importing a file, which card has to be removed from the card database. Default delete code is "-".
- 6 Select the **Field separator**. This code will be used to separate the selected fields when importing or exporting data. Usually a comma (,) is selected. Keep this in mind when adding users' last names and first names separated by a commas.
- 7 Select the **Date format**. The date will be exported or imported according to the specified format. The most commonly used format is YYYY/MM/DD.



***NOTE:** The **Use DLL** feature allows you to enable a program that will convert specific card numbers. You may use the **Remove DLL** when you do not wish to enable the program that converts card numbers.*

- 8 Click **OK** to exist the pattern window and to specify the new pattern name.




- 9 Enter the pattern name, then click **OK**. The system automatically returns to the **Export/Import CSV file** window. The pattern you have just created is displayed in the **Available patterns** list.
- 10 If you want to add or remove fields from your pattern, double-click the new pattern to edit and make the necessary modifications. Now you can import or export your information using the new pattern you have just created.

## To Export Cards

Your organization may need to export the card database data into another application. You may use a predefined template or create a custom template.


- 1 From the Users menu, select the Import/Export CSV File button. The system displays the Import / Export CSV file window.




- 2 From the Select operation drop-down list, select Export.
- 3 From the Available patterns list (left-hand pane), select the pattern you want to use when exporting cards. If necessary, you may edit the pattern so that it matches the target application pattern, else, you may create a new one. (For more information on how to create a pattern, see *"To Create a New Import/Export Pattern" on page 322*).
- 4 From the Transaction file, select the folder in which EntraPass will save the card database content. You can open the CSV file in Excel, Notepad, etc.



- 5 Once you have selected/created an export folder, click OK to return back to the Import / Export CSV file window.




- 6 Click the Export button; it is enabled once the transaction file is selected. The system displays a window allowing you to filter the cards you want to export.



**NOTE:** For cards to be included in your file, they must match all the selected filters, if one or more filters are not matched, the card will not be included.


- 7 In the Export Card's filter window, specify the cards you want to export. Once you have made all your selections, click the Export button. The Import / Export CSV file window appears.




**NOTE:** The *Transaction file* field shows the target file name and location. By default, the export file is saved in the specified folder (Exportdata, in this example). The status bar (lower part of the window), shows the number of imported cards (1, in this example). The default name is YYYYMMDD.csv. You can open the target file with Notepad for instance.

## To Import Cards


- 1 From the Users menu, select the Import/Export CSV File icon. Then select Import from the Select operation drop-down list.



- 2
- From the Available patterns list, select the pattern that will be used to import the cards information (for more information on how to create a pattern, see *"To Create a New Import/Export Pattern"* on page 322).
- 3
- From the Transaction file pull-down menu, browse your hard drive to the CSV file that contains the data to import into the card database, then click Open.



- 4
- Select the CSV file to import, then click Open. The Import / export CSV file window appears.



*NOTE: The system scans the file to be imported; then it displays the results using a color code. Each entry is identified by a color flag. A yellow or red flag identifies an entry in error. Errors are frequently caused by the patterns. You have to select another pattern or edit the pattern you are using so that the pattern entries have to match the source file entries. There may be errors also even if the transaction code is identified by a green flag.*


- 5 If no errors are present (or once you have corrected errors), click **Import** to complete the operation.

## To Correct Import/Export Errors

The CSV Import/Export feature imposes a number of rules: each field contains a specific value format that has to be respected. For example, the card state field will only accept the following values (0=valid, 1=invalid, 2=stolen/lost). The pattern used has to match the pattern used by the source file.


The present section will assist you in correcting import/export errors.

- 1 Click the **Import** or **Export** button to start the transaction (the following example illustrates a case of importing CSV data). The lower part of the window displays the number of cards in the list.




**NOTE:** Although entries in the *Transaction code* column are identified with a green flag, the *Card number* column is empty. This indicates problems in the pattern conversion.

2 Click the Import button.




**NOTE:** The *Error* button is enabled because the system encountered problems during the import transaction.

3 You may click the Error button to display information about the error. The Process error window shows that the pattern used is invalid.




4 Click the Close button to go back to the Import Export window.

- 5 In the Import/Export CSV window, double-click the pattern you have used for the Import transaction (Custom, in this example).



- 6 From the Field separator drop-down list, select Comma as the field separator, then click OK. The Card number field contains data. This indicates that the import transaction will be successful.





## Chapter 9 • Groups

It is useful to create groups so that operators can perform modifications on a group of components or other system functions.



**NOTE:** Each system component has to be defined before it can be included in a group.

You can create:

- Controller groups
- Door groups
- Relay groups
- Input groups,
- Access level groups
- Floor groups




**NOTE:** When a NCC 8000, a Global or a KT-NCC Gateway is selected, components (controllers, inputs, access levels, etc.) are grouped by gateway. When a Corporate Gateway is selected, they are grouped by site.

## Controller Group Creation

The Controller group menu is used to group a number of controllers of the same site. The controller group can later be used to perform manual operations on controllers, for instance (i.e.: reload).

- 1 From the Groups window, select the Controller icon.



- 2 Select the **View hierarchy** button to display all the sites defined in the system.
- 3 From the **Gateway/Site** drop-down list, select the site or gateway from which you want to group controllers.
- 4 To create a new group of controllers, click the **New** icon. To modify an existing group, select one from the **Controller group** drop-down list, then enter the necessary information in the language section.
- 5 From the list of controllers connected to the selected site, check the controllers that are to be assigned to the group.




**NOTE:** For more information on controllers, see "Controllers Configuration" on page 110

## Door Group Creation

The Door group menu is used to group doors of a specific site. The door group can later be used to carry out manual operations such as unlocking a group of doors.

- 1 From the Groups window, select the Door icon.



- 2 Select the View hierarchy button to display all the sites defined in the system.
- 3 From the Gateway/Site drop-down list, select the site or gateway from which you want to group doors.
- 4 From the Door Group drop-down list, select a door group you want to modify or click the New icon to create a new group, then enter the necessary information.
- 5 From the Door list, select the doors that must be assigned to the group.




**NOTE:** For more information on doors, see "Doors Configuration" on page 126.

## Relay Group Creation

The Relay group menu is used to group relays of a specific site. This relay group can later be used to carry out manual operations such as temporarily activating relays.

- 1 From the Groups window, select the Relay icon.



- 2 Select the **View hierarchy** button to display all the sites defined in the system.
- 3 From the **Gateway/Site** drop-down list, select the site or gateway from which you want to group relays.
- 4 From the **Relay group** drop-down list, select a relay group or click the **New** icon to create a new group; then enter the necessary information in the language section.
- 5 From the **Relay** list, select the relays that must be assigned to the group.




**NOTE:** For more information on relays, see "Relays Configuration" on page 141.

## Input Group Creation

The Input group menu is used to group inputs of a controller site.  
This input group can later be used to carry out manual operations such as shunt on inputs.

1 From the Groups window, select the Input icon.



- 2 Select the View hierarchy button to display all the sites defined in the system.
- 3 From the Gateway/Site drop-down list, select the site for which you want to group inputs.
- 4 From the Inputs group drop-down list, select an existing group to modify it, or click the New icon to create a new group; then enter the necessary information in the language section.
- 5 From the Inputs list, select the inputs that must be assigned to the group.




**NOTE:** For more information on inputs, see "Inputs Configuration" on page 143.

## Access Level Groups Grouping

The Access level group dialog is used to group access levels of the same site.

- 1 From the Group window, select the Access level group icon.



- 2 Select the View hierarchy button to display all the sites defined in the system.
- 3 From the Gateway/Site drop-down list, select the site or gateway from which you want to group access levels.
- 4 Click the New button to create a new group access level, and assign a name in the English field.
- 5 Check the boxes that correspond to the access level group.

## Floor Group Creation

This menu is used to group the floors that were created in the floor definition menu. Floor groups are also used for various operations in the system such as: manual operations (unlocking schedules), access levels, etc.

- 1 From the Groups window, select the Floor/Elevator door icon.

Floor	State	Schedule
Floor #01	<input checked="" type="checkbox"/>	24/7
Floor #02	<input type="checkbox"/>	None
Floor #03	<input checked="" type="checkbox"/>	24/7
Floor #04	<input type="checkbox"/>	None
Floor #05	<input checked="" type="checkbox"/>	24/7
Floor #06	<input type="checkbox"/>	None
Floor #07	<input checked="" type="checkbox"/>	24/7
Floor #08	<input type="checkbox"/>	None

- 2 Select the View hierarchy button to display all the sites defined in the system; then from the Gateway/Site drop-down list, select the site or gateway from which you want to group the floors.
- 3 From the Floor group drop-down list, select an existing group if you want to modify it; or click the New icon to create a new group. Then enter the name of the group in the language section.
- 4 From the list of defined floors that is displayed by the system, check the State column for the Floors you want to include in the group. Only floors that have the State field selected will be enabled when:
  - A manual unlock operation is done, or
  - An “input” is programmed, for example, as a push button to enable floors for visitors (Devices > Input definition menu > Elevator tab),
  - Cardholders present their card to the card reader to enable floor selection when the controller is operating in stand-alone mode (due to communication failure). Only the floors marked with an “X” are available for selection.
- 5 Only floors that have State selected will be enabled when:
  - A manual unlocking operation is done, or
  - An “input” is programmed, for example as a push button to enable floors for visitors (input definition menu - elevator tab),

- 
- Cardholders present their card at the card reader to enable floor selection and the controller is operating in “stand-alone” (due to communication failure). Only the floors marked with an “X” will be available for selection
  - A schedule for each floor is assigned in the Schedule column (NCC 8000 and Global gateways only).



---

## Chapter 10 • System Status

The **Status** menu allows system operators to view the status of various devices and components of the access system:

- The **Connection list** button provides information regarding applications connected to the server (operator name, local identification, etc.).
- The **Text** button allows operators to view, in text, the status of EntraPass applications, gateways, sites, controllers (KT-100, KT-200, or KT-300), doors, relays, inputs. The status displayed depends on the controller installed.
- The **Numerical** button allows operators to view the statistical status of all components, by gateway. For example, you can view the number of inputs in an alarm.
- The **Graphic** button allows operators to display the graphic status of a controller.
- The **Database** button provides information on the database structure. In addition, an operator can perform configuration operations or manual commands from the database window.
- The **Video Server** button allows operators to display the statuses related to the EntraPass Video Vault process.



## Connection List

The Connection list feature displays details about a selected application, such as: operator name, last query date, local identification number, etc. It is also used to verify if EntraPass applications are connected to the server.

### To View the System Connection List

- 1 In the Status window, select the Connection icon. The Connection list window appears.

A scrolling list contains all applications listed together or individually. You can select All connections, or a specific gateway and view the details of the connection for the selected application(s).



- 2 Click the "+" sign to see detailed information about an application.
  - A Red circle indicates that the EntraPass application is not connected to the server
  - A Green circle indicates that the EntraPass application is connected to the server.
- 3 **Protocol**—Identifies the protocol (language) used to communicate with the server. The protocol is used to inform the system on how the information is shared between computers. **Local identification**—Identifies the label of the application on the network. This name is used by the server to identify your application.
  - **Network identification**—Provides the IP address of the application on the network or NetBEUI name.
  - **Operator name**—Displays the name of the operator currently logged on this application. The operator name is used for many purposes, such as to identify who performed a modification to a card, who acknowledged an alarm, etc. For information on modifying the operator name, see *"Operators Definition" on page 352*.
  - **Last query date**—Displays the time the application last polled the server. The server and application exchange information on a regular basis.

- **Connected date**—Displays the date and time at which this application started its connection with the server. This date will be used to generate an event and kept in archives.
- **Transactions**—Displays the number of requests performed by the application (number of exchanges with the server), i.e. report queries, for example.
- **Errors**—Displays the amount of errors encountered by the application. This field will reset when the application is shutdown.
- **Messages/Alarms buffered (0/1)**
  - 0: the number of messages/alarms buffered for this application on the server when the application is off-line (not in communication). This number will reset to “0” when the application connects to the server and messages are sent.
  - 1: the number of messages/alarms that were sent to this application since the Server is operational. If the Server is shutdown, this number will reset.



**NOTE:** The server holds a maximum of 100,000 messages and 100,000 alarms per workstation (default: 5,000) in the buffer. You can modify these settings through the Workstation Definition menu. You can also specify if newer or older events should be buffered. Events will be buffered only when the workstation is off-line (not connected to the server); and when the fields “Apply operator parameters for messages” and “Apply operator parameters for alarms” are not selected (for more information, see “Entrapass Applications Configuration” on page 60).


## Text Status

The Text status allows an operator to display the status of a selected component (and sub-components) as well as all the characteristics associated with this component in a text form. This menu option applies to all the system devices: applications, gateways, sites, controllers, doors, relays and inputs. The text window contains additional buttons/icons that assist operators in their tasks:


- The first eight buttons represent system devices (Workstation, Gateway, Site, Controller, Door, Input, Output and gateway). When a button representing a system device is selected, all the components defined in the system are displayed for selection.
- **Summary / Detailed list**—The magnifying glass icon is used to display components that are not in normal condition. It displays a summary list or a detailed list.
  - Summary: shows the components that are not in normal condition
  - Detail: shows all the components in any condition.
- **Stop display**—This button is used to stop the display when the information is taking too much time. It cancels or interrupts the process.
- **Refresh**—Refreshes the status of the selected components.
- **Print**—Use this button to print the displayed status. You can preview your report before printing it.

### To Display a Component Status

- 1 From the Status window, select the Text Status button. The Text status window appears.



- 2 In the Text window, select the icon of the component for which you want to view the status. If you select the Workstation icon, the system displays the list of the EntraPass Applications defined in the system.



- 3 You can check the EntraPass application you want to display the status or enter a few characters of the component name (field at the top) for the system to searched in the database. For example, you can enter “Sec” for Security Office. The system will highlight the first name containing the entered characters. You may also click the Select all button to select all the EntraPass applications; or select specific components by clicking in the checkboxes next to each component name. The Clear all button removes the check marks from the selected components. Click Cancel to return to the previous window without any selections or changes.
- 4 You may check the View sub-components box (lower part of the window) to display detailed information on the sub-components linked to the selected component. For example, if you selected a controller, all its components (doors, relays, inputs) with appropriate status will be displayed on the window if this option was checked. For more focus in one window, filter doors, relays or inputs by site.
- 5 Click OK to return to the previous window and apply your selections.




**NOTE:** The *Magnifying glass* button is used to display components that are not in normal condition. When it is in a “summary” position, only components that are not in normal condition will be displayed; the “detailed” position, displays a full status of all components.

## Numerical Status

This menu allows an operator to view the number of components in a “not normal” state for a selected gateway.

### To View the Numeric Status of a Specific Gateway

- 1 In the Status window, select the Numerical status button. The Numerical window appears.



- 2 From the Gateway drop-down list, select the gateway for which you want to display the status. The system displays the number of cards for that gateway, the number of inputs in alarm, the number of relays manually activated, the number of doors forced open, etc. This can be very useful if you need to find out how many cards are defined.


## Graphic Status

This feature is used to display a graphical status of a door controller, including the status of all its components (outputs, inputs, power supply status, communication status, etc.) represented by colored shapes (circle, square, etc.).

- An ellipse shape represents the controller
- A circle represents a door
- A square represents a relay
- A rectangle represents an input. Rectangles may be horizontal (KT-200 and KT-300) or vertical (KT-100).

### To View a Controller Status

- 1 From the Gateway drop-down list, select the gateway on which the controller to display is located. You may select "All gateways" to display all the controllers in the list.
- 2 From the Controller drop-down list, select the controller for which you want to display the status.



**NOTE:** The displayed graphic depends on the type of the controller selected.

- 3 To find out which items are represented by a colored shape, move the mouse over a colored shape. The item highlighted on the right-hand (in the list) identifies the component.
- 4 Select a controller from the Controller list drop-down list (right side of the window), double-click the item on which status is required.
  - Red—The component is "Supervised" and "in a trouble state".
  - Green—The component is "Supervised" and "in normal condition".

- Yellow—The component is “Not Supervised” and “in a trouble state”.
- Gray—The component is “Not Supervised” and “in normal condition”.
- Blue—The relay is activated (by an event or an operator).



*NOTE: If there's more than one controller site per gateway, the numbers between parentheses (xx) indicates the controller number and the following numbers (xx) indicate the component number.*




## Video Server Status

This feature is used to monitor video servers' statuses related to the Entrapass Video Vault archiving process. The **Video Server** option can be accessed from the **Status** tab. The Video Server window lists all video servers and their statuses.

### To View Video Server Status

- 1 Click the **Video Server** icon under the **Status** tab. The Video Server window will open and display all video servers and their statuses.



- **State:** Enabled/Disabled video archiving
- **Video Vault:** Linked to the Entrapass Video Vault
- **Schedule:** Valid/Invalid archive schedule state
- **Date and Time:** of the last transaction for this video server with the Entrapass Video Vault
- **State:** Description of the las transaction for this video server with the Entrapass Video Vault.

### To Enable/Disable Video Archiving


- 1 Right-click the server for which you want to enable/disable the video archiving process.
  - In the contextual menu, select **Enable** to activate the archiving process.
  - In the contextual menu, select **Disable** to interrupt the archiving process.

## Database Status

This window displays the status of the components within the database while browsing the database structure. The system displays all applications (connected or not), the gateway, controller sites, etc. You can also perform manual operations directly from the window and edit components in order to modify their configuration.


### To View Information About the Database

- 1 From the Status window, select the Database icon. The Database window appears.



**NOTE:** The icon identifies the type of component.

- 2 In the Database window, select the application you want to view the database. The lower part of the window displays the actual status of the selected component as well as its full name.
- 3 Select a component to modify its definition directly from the Database window. For example, if you have selected a door, right-click the door to display a shortcut menu.
- 4 Select a command in the cascading sub-menu; select a menu option.



**NOTE:** The command list varies according to the selected component.

- 5 Make your modifications to return to the Database status window. The Right-click shortcut menu offers the following options:
  - **Full expand**—This feature allows you to fully expand the tree status and view all components. Only applications that are connected to the server will display a “+” sign.


- **Full collapse**—This feature allows you to fully collapse the tree status and hide all components of the root component.
- **Edit**—When you select an assigned component (i.e.: input) and click edit, the system will edit the definition window so you can modify its definition and when finished, return to the window you edited the component from.
- **Limited display / No limited display**—When you click on a physical component, the bottom part of the window displays its status.
- By selecting **Limited display**, the system will erase the previous status and display the status of the next selected component.



*NOTE: The icons on the left side components indicate the component type.*

## Server State

The Server state dialog allows users to view detailed information on the server such as system information, system global memory, system process memory and system disk space.



---

## Chapter 11 • System

Use the System menu to define parameters for systems operators, security levels, event parameters, instructions, and message filters. This menu allows you also to view the EntraPass database structure.

You will define system parameters as follows:

- **Operator:** user name, login name, password settings for EntraPass operators
- **Security level:** use this menu to grant or deny access permission on system logical and physical components
- **Event parameter:** use this menu to define priority, color, schedule (display, printing schedule, acknowledgement) for system events
- **Instruction:** use this menu to create instructions for alarm messages and SmartLink applications
- **Message filter:** Use this menu to direct event messages from a specific EntraPass application to another EntraPass application and to define sort criteria for messages that are sent to the Filtered Message desktop.
- **Database structure:** Use this menu to display EntraPass physical and logical components and to edit or sort system components.

## Operators Definition

Use the Operator menu to define system operators and to determine their security level and privileges. An operator is responsible for issuing cards, carrying out manual operations on system components, requesting reports, arming the system, etc.

For security reasons, each person using and accessing the system database should have his/her operator defined to ensure that each action performed in the system will be traceable. You need to create at least one operator account or modify the pre-created accounts in order for the operator to use and operate EntraPass and to receive event messages.

There are three default operators created in the system. These are associated with three levels of access rights:

- Installer (login name and password are kantech): Full access to view, modify, delete, print components.
- Administrator (the login Kantech1 and the password kantech): Medium access with limited access to system menus.
- Guard (login Kantech2 and password are kantech): Limited access to system menus.



**NOTE:** You can define operators using the default operators or you can create new operators. For details about operators' security levels, see "Security Level Definition" on page 356.

### To Create or Edit an Operator

- 1 From the System tab, select the Operator icon to open the Operator window.



**NOTE:** The upper right-hand corner shows the last EntraPass workstation where the operator logged on and the last login date for the operator who is logged on.

- 2 Enter the operator name in the Name field. The operator name is composed of a maximum of 40 alphanumeric characters (including spaces).

- 3 Enter the operator Login name. This is a descriptive name composed of 6 to 20 alphanumeric characters (including spaces).



***NOTE:** On login, operators must enter their login name followed by their password in order for the system to validate their access. The login name is displayed in the events' details when operator events are generated (i.e. manual operation, login, logout, etc.).*

- 4 In the Password field, enter the password that will be used to login with the login name. The password is alphanumeric and consists of a maximum of twenty characters (minimum seven characters). The password is not displayed nor printed, the system displays the password as asterisks.




***NOTE:** The password is **case-sensitive** - make sure that all operators are aware of this.*

- 5 In the Password Confirmation field, enter the operator password again for confirmation using the proper case. If this password is not identical to the one entered in the password field, an error message will appear.
- 6 In the Language section, check the appropriate option for the display language for this operator. If you change the display language, it will be effective only when the operator logs out and logs in again. When an operator logs out and exits an application, the next operator who logs on the application will see the startup window in the language of the last operator.
- 7 In the Privileges section:
  - Select the **Auto acknowledge** option. If this option is selected, the **Manual** button is added to the Alarms desktop (see "*Entrapass Desktops*" on page 391). The operator can decide to manually or automatically acknowledge events. This is an operator privilege.
  - Select the **Bypass workstation message filter** option, if applicable. When this field is selected, the basic workstation configuration will be ignored and the operator will receive events from all workstations and gateways.
  - Check the **Privileges** option if you want this operator to view hidden cameras. For camera definition: **Video > Camera > Show camera option**
  - **Automatic video display:** this option tells the system to automatically display video clips on an alarm event for the operator who is logged on. If the Alarm desktop is configured and open, the video is automatically displayed. If the alarm desktop is not open, the system checks the video display settings for this workstation (**Devices > Messages 2 of 2, Disable autodisplay of video views**, if this option is not checked, the system checks the video view settings for this operator: **Operator > Automatic video display checkbox**).



***NOTE:** The **Bypass workstation message filter** option is a privilege granted to operators. It allows them to receive all events regardless of which workstation they are logged into at the time. If this option is selected and the **Apply operator parameters for messages** and **Apply operator parameters for alarms** options of the Workstation definition are also selected, then the basic configuration will be ignored and events will be filtered according to the security level of the operator who is currently logged into the workstation.*

- 8 Click on the Security tab to set operator access parameters.



- 9 From the Login Schedule pull-down menu, select the schedule during which the operator will be allowed to login into the system. You may want to create a specific schedule for an operator (Definition > Schedule), and then assign the schedule to the operator.



**NOTE:** To allow an operator to logon to different EntraPass applications or to the EntraPass Server select the field Allow login on application and/or Allow login on server (**System > Security Level > Miscellaneous** tab).

- 10 From the Security Level pull-down menu, select a security level that will determine which components an operator has access to. A security level consists of menus through which an operator can modify the database, create components, view system components and events, etc.



**NOTE:** It is possible to define up to 250 custom security levels; the system offers 3 built-in security levels (Installer, Administrator and Guard) on configuration. The default configuration for Installer permits access to all system commands. The Installer must program other security levels to limit operator access to menu commands and/or options.

- 11 Access the Security section to edit the security features of the currently displayed operator profile:
  - **Operator disabled:** use this feature if you want to suspend or limit an operator access. If you select an operator and then check this box, the selected operator will not be able to run the application.
  - **Change password at next log on:** use this feature if you want an operator to change his/her password at next log on.
  - **Disable operator on bad password:** use this feature to limit the number of retries on bad password. For example, if you set this number to three (3), the operator will be disabled after three errors when entering his/her password.



- **Days before password is reset:** this feature allows to manage operators' passwords. At the end of the number of the days specified in this field, the operator will be prompted to change his/her password.
- **Use expiration date:** this feature allows you also to manage operators' password. When this feature is checked, you have to select an expiration date (Operator expiration date).
- **Operator expiration date:** used with the Use expiration date feature, the Operator expiration date allows you to disable an operator's access at a specified date.



**NOTE:** *Changes to the currently displayed profile will take effect at the next log on attempt.*

## Security Level Definition

Security levels refer to the permissions granted to an operator to modify the database, create items, view components, print lists or reports, etc. There are three default operators and security levels. It is possible to customize an operator security level; the system allows you to create up to 250 security levels.



**NOTE:** You have to program the appropriate security levels if you want to limit operator access to commands and/or options of the system menu.

Each default operator has a separate login name, password and a corresponding security level. The password is case-sensitive. These are: Installer, Administrator and Guard.

- **Installer:**
  - Login name and password: kantech
  - Security level: By default, a user defined as Installer has full access to all the system menus. He/she can read and edit system components and has unrestricted access to the system.
- **Administrator:**
  - Login name: kantech1; password: kantech
  - Security level: Administrator. By default, a user defined as Administrator has limited access to a number of the system menus.
- **Guard:**
  - Login name: kantech2; password: kantech
  - Security level: Guard. By default, a user defined as Guard has limited access to the system menu.

### To Create/Modify an Operator Security Level

Assigning security levels is critical to the system. In fact, if a Security level is given full access to a system menu, operators who are assigned this security level can modify system parameters. Make sure that each operator is given the security level corresponding to his/her tasks.


Items in the Security Level window are presented in a root tree with all components available for selection. This structure makes it possible to target specific components when granting security level for manual operations.

Each security level is identified by a color: full access (green), read-only (yellow) and no access (red). The security manager or an operator with appropriate permissions can easily change or assign a component to a lower level security level by double clicking an item until it changes to the desired color code.



**NOTE:** Operators will not be able to see items for which they have not been given access.

- 1 From the System main window, select the Security level icon. The Security level window appears with the Menu tab enabled.




- 2 To modify a security level, select one from the Security level drop-down list. To create a new security level, click the New button and enter the necessary information in the language section.
- 3 In the Menu window, double-click an item to make it No access (red), Read-only (yellow) or Full access (green). You can specific components when granting security level for manual operations

## To Define Login Options for an Operator

The Miscellaneous tab allows you to define operator login and system display options:

- Operator login options: you can allow or restrict an operator to log on an EntraPass workstation or server.
- Active windows that can be kept on the desktop: EntraPass allows operators to keep five active windows on the desktop.
- Component display options: components can be displayed with or without their physical address. The physical address can appear on the left or right of the component name.

- 1 Select the Miscellaneous tab to define other parameters for the Security level being defined. These include login restrictions and viewing parameters.



- 2 In the Login restrictions section, select the appropriate login options:
  - Select Allow login on server to allow the operator to log onto the an EntraPass server (Primary or Redundant).
  - Select Allow login on workstation to allow the operator to log onto any application in the system. To narrow down the list of authorized applications, use this option with the Use workstation list for login feature. This option is checked by default when a new operator is created.
  - Select the Use workstation list for login option to restrict the number of authorized applications for an operator. If selected, the operator will only be allowed to log onto the workstations that are selected in the EntraPass application tab. The Allow login on workstation option must also be selected.
- 3 The Keep on application desktop section allows users to increase the number of active windows on the desktop. In fact, operators can open five windows at the same time: one configuration window and four windows from the other categories. EntraPass windows are classified in five categories:
  - Configuration screen: this group includes all the menus that allow an operator to program the system. This group includes such menu items as: User menu (card, Badging, card access group, access level, visitor, card type; Definition menu; Group menu; Devices menu; Video menu; System menu; Historical and Time and attendance reports.
  - Operation screen: this group includes all the Operation menu items and the Video playback option.
  - Status screen: this group includes windows of the Status menu, Current recording menu and Report state menu.
  - Database screen: The following menus are included in this category: Option menu (card format, authentication password, select languages, Printers options, Changes date and

time, etc.); Items of the User menu (Daypass, batch operations and Import/Export CSV); View Report, Operation on T&A, and View exported videos

- **Report screen:** this group includes Quick Report, Historical and Time and attendance report requests and Video list windows.



**NOTE:** These options allow operators to keep active four operation windows on the desktop. They can bring to front or send to back the window they want to display, simply by pressing ALT-F6.

- 4 In the Components physical address section, specify how the component's physical address will be displayed for the security level being defined. This will also affect how components will be sorted.
  - **Display on left**—If selected, components will be sorted by their address (i.e. 01.01.01 Controller xyz).
  - **Display on right**—If selected, components will be sorted by their component name (i.e. Controller xyz 01.01.01).
  - **No display**—If selected, the address will not be displayed (i.e. Controller xyz) and components will be sorted by name.
- 5 If you are using the Video feature, EntraPass enables you to deny viewing permission to a specified security level by checking the **Hide camera from video views** for the security level being defined.



**NOTE:** Checking the *Hide camera from video view* option tells the system to verify access permission to cameras before loading a video view. For example, if the selected operator's security level has access to a video server but not to all cameras defined in the video server and has access to the selected video view, the system will hide the camera that has been unselected when assigning permission to the video server. For details, see "To Limit Access to a Specific Camera" on page 367.


## To Filter Applications Available to an Operator

This feature allows you to filter applications that will be available to Operators assigned the selected security level when viewing or modifying system components. For example, if you assigned the menu "EntraPass application", only workstation selected in for this security level will be displayed in the EntraPass Application list when the operator who is assigned this security level wants to modify an EntraPass application.

Operator assigned a given security level will not see nor view or modify a specific application if it is not selected in their security level definition.

In the following example, the selected security level (Guard) will not view messages sent by the EntraPass SmartLink application because it is not assigned to their security level.

- 1 From the Security level drop-down list, select the security level you want to define/edit. when viewing or modifying components.




**NOTE:** When an operator is allowed to use the “Network alarms message desktop (Desktops menu), only alarm events originating from the Entrapass applications and components of the applications that are selected in this window will be displayed. The security level definition acts as a filter for the “Network alarms message desktop”.

- 2 Check the All Entrapass applications option if you want the operators assigned this Security level to see all the Entrapass applications defined in the system.

## To Filter Gateways and Sites Available to an Operator

As for the Entrapass applications menu, operators assigned a given security level will not see nor view or modify a specific gateway or site if it is not selected in their security level definition.

- 1 Select the Gateway and Site tab to narrow down the list of gateways and sites that will be available to the operator who is assigned this security level for modifications or normal operations.




**NOTE:** When you select a gateway or site, you *also* select all the components defined “under” or attached to the gateway (i.e. sites, controllers, doors, relays, inputs, outputs, etc.).

- 2 Select All gateways and sites if you want all the displayed gateways and sites to be available to the operator assigned this security level when modifying doors, relays, inputs, etc. or performing modifications/operations related to controllers. You can also select specific gateways/sites from the displayed list.

## To Filter Controllers Available to an Operator

EntraPass allows you the ability to assign to a security level Controllers that will be available for view. To do so, you must select the Operator security level, then select the Controllers tab and check controllers that you to be available for the selected security level.

- 1 From the Security level drop down list, select the security level you want to define.



- 2 From the Security level window, select the Controllers tab to assign controllers to the selected security level. The selected controllers will be available for viewing or editing to the operator who is assigned this security level.




**NOTE:** When you select a controller, you also select all the components defined “under” or related to the controller (i.e. doors, relays, inputs, outputs). Make sure that you have also selected the gateway (*Gateway and Site* tab) for which the selected controller is defined. If the gateway is not selected, the controller will not be available even if it is selected in the list.

## To Filter Doors Available to an Operator

Entrapass allows you the ability to assign to a security level Doors that will be available for view. To do so, you must select the Operator security level, then select the Controllers tab and check controllers that you to be available for the selected security level.



- 1 From the Security level drop-down list, select the security level you want to define/modify, then select the Door tab.



- 2 Select All doors if you want all the displayed doors to be available to the operator assigned this security level when modifying doors, relays, inputs, etc. or performing modifications/operations related to controllers. You can also select only the doors you want from the displayed list.




**NOTE:** Make sure that you have also selected the controller for which the selected door is defined. If the controller is not selected, the door will not be available even if it is selected in the list.

## To Filter Access Levels

Associating specific access levels to a security level allows you to control the access levels that an operator can define or modify. For example, a security guard may have the right to issue cards that are valid for a given door or access level only.

- 1 From the Security level drop down list, select the security level you want to define/edit.



- 2 Select All access levels if you want all the displayed access levels to be available to the operator assigned this security level when creating cards or performing modifications related to access levels. You can also select only the access levels you want from the displayed list.




**NOTE:** Make sure that you have also selected the gateway for which the selected access level is defined. If the gateway is not selected, the access level will not be available even if it is selected in the list.

## To Filter Card Types Available to an Operator

This feature restricts the operator action. In fact, card types that are not selected in this menu will not be available to an operator when creating or editing cards. For example, you may decide that an operator with the Guard security level will not be able to issue a specific card type such as Security. To do this, select the Guard security level, then do not select Security when filtering card type for the Guard security level.

- 1 From the Security level drop-down list, select the security level you want to define/edit.




- 2 Select **All card types** if you want all the displayed card types to be available to the operator assigned this security level when creating cards or performing modifications related to card types. You can also select only the card types you want from the displayed list.

## To Filter Reports Available to an Operator

This feature gives operators access to specific reports according to their security level. For example, a System Administrator may have access to all the reports that can be generated whereas the Guards' Supervisor may only have access to all Guard Tour related reports. The reports will be generated from the **Archived Message** list on the workstation desktop. Once the reports have been assigned to security levels, operators will only have access to reports that correspond to their security level.

- 1 From the Security level drop-down list, select the security level you want to define/edit.




- 2 In the Report tab, select the reports you want to assign to the selected security level. Or, check the All reports check box if you want to give full access to all reports to the operator assigned this security level. You can also select only the card types you want from the displayed list.

## To Filter Video Servers

The security level menu allows you to assign or limit operator access to specific video servers and cameras. For example, even if a security level has access to a video server, you still have the ability to restrict access to a specific camera. This feature makes it easier to define or modify permission for accessing a video server, a video view or other video menu items by double-clicking the colored bullet next to an item: green: full access; yellow: read-only; and red: no access. The video server, video view and video trigger menus offer the three access options. For other video menu items such as Recording parameters, video event list, current recording, video desktop, etc., only the no access and full access options are available.

- 1 From the Security level drop-down list, select the security level you want to define/edit, then select the Video server tab.



- 2 Check a specific video server, or check the All video servers option if you want the selected security level to have access to all video servers defined in the system.



**NOTE:** To filter video views available to an operator, the operator's security level must have access permission to the video server associated with this specific video view. For example, if operators are granted access permission to a video view but if their security level does not have access to the video server where the video view is defined, the video view will not be available to operators with this security level.


## To Limit Access to a Specific Camera

EntraPass offers the ability to grant permission to a video server and still restrict access to its cameras.




**NOTE:** If you want the operator not to view the camera for which he/she does not have access, you must check the **Hide camera from view** option when defining the security level. Checking this option will hide the camera from the video view even when the operator has full access to the video view in which the camera has been defined.

- 1 From the Security level window, select the Video server tab.




- 2 Double-click the video server (for this, you have to un-select the All video servers option).
- 3 From the Select camera window, un-select cameras you want to hide for this security level then click OK to close the Select camera window.



- 4 Save your modifications. When a video server has been modified, it's color turns red.

## To Filter Video Views

- 1 From the Security level window, select the Video view tab.




- 2 From the list of displayed views, select the views available to this security level. You may check **All video views** if applicable. You may also deselect a view if you want to restrict access to a specific view.

## To Hide Card Information

Entrapass offers you the ability to hide card information fields from view. For example, you can decide that a certain security level (Guard for example) will not modify card information field. To do so, select the security level, then in the Card database fields (Security level), select fields you want to be hidden.

- 1 Select the Card database fields tab to limit the number of card fields which are visible to the operator who is assigned this security level.



- 2 Select the fields (either individually or in groups) that will be hidden to the selected security level. In the example above, operators who will be assigned the Guard security level will not see the selected fields.


## To Assign Video Custom Buttons

Entrapass offers you the ability to customize five buttons for use in the Video interface. System installers and administrators can customize buttons for use by operators in the Video desktop. For example, a button customized for Playback with fixed delay with specific pre-record and record delays and assigned to a specific Security level will enable operators to trigger the actions related to the specific button.

If you associate a custom button with a specific task (play back or generating video events, additional buttons are added to the Video desktop (Desktops > Desktop dedicated to video viewing)



- 1 From the Security level drop-down list, select the security level you want to define/edit.



- 2 Select the Video custom button tab to assign permission to this operator. The following permission can be granted:
- Playback with fixed delay
  - Playback with custom delay
  - Generate recording event with fixed parameters
  - Generate recording with custom parameters.
- 3 Select the option you want to assign to the operator being modified.



**NOTE:** Pressing the button associated with *Playback with fixed delay* will start a play back with the specified duration. This includes the pre-alarm recording time and the maximum recording time.

## Event Parameters Definition

Defining event parameters is one of the most powerful features of the system. For each event, you can determine how it will be processed by the system. For example, you can:

- Direct events to output devices (such as Messages desktop and log printer),
- Send instructions to a SmartLink application
- Define schedules that will allow, for example, to send alarms to an EntraPass application only at night
- Send a specific event to a specific EntraPass application, etc.

There are more than 400 system events including:

- Access granted
- Input in alarm
- Card modified by operator, etc.

Events are associated with system components, such as doors, controllers alarm systems, gateways, Entrapass applications, etc. Every event message is associated with a system component and output devices or group of devices. For example, an *Access granted event* can be defined for each individual door or by default it can be defined for all doors. This flexibility allows for different actions or responses on a door-by-door basis.

### To Define Events Parameters

The Event parameters dialog allows you to customize your system events. In fact, you can specify events that will be printed automatically or acknowledged during a specific schedule. You can also send instructions to inform an operator of an alarm or through other media (i.e. e-mail, pager, etc.) when alarms are generated.


By default, all events are defined to be displayed on all the Message desktops of all EntraPass applications defined in the system. You can customize your system events by manually associating events and components.

There are two types of associations: manual and default association. For details about associations, see *"To Create and View Associations"* on page 374.



**NOTE:** *Manual associations take priority over default associations. When you define a manual association between an event message and a component, the default association is ignored. It can be restored by deleting the manual association. Manual associations should be used with caution. The most common use for this feature is the SmartLink application.*

- 1 From the System main window, select the Event parameters icon.



- 2 From the Event drop-down list, select an event for which you want to define settings.



**NOTE:** By default, all events are defined to be sent to the Messages desktop of all EntraPass workstations defined in the system with an always valid schedule. It is recommended to keep default settings especially when these settings apply to all components/events. However, you may decide to create manual associations if you want a specific event to appear on a specific EntraPass workstation. The selected event will appear on all doors and will be displayed on all EntraPass workstations.

- 3 In the Display settings section, specify the display options: by default, all events are programmed to be displayed in the Messages desktop window of all the EntraPass workstations of the system. By default, they are assigned an Always valid schedule.



**NOTE:** If you are running EntraPass SmartLink application, this schedule must remain to *Always valid* or otherwise messages/commands will *not* be forwarded to the application.

- 4 From the Print pop up-down menu, select a schedule to determine when the event will be printed. When this schedule is valid, the selected event will be printed on the printer defined on the workstation to which it is being sent.



**NOTE:** You must also select a printer and specify if the printer should print messages or alarms, or both. For more information, see "Basic Functions" on page 50.

- 5 From the Color drop-down list, select the color that will be used to display the event in the Message desktop. The default colors are set according to the following convention:
  - Red for alarm events;
  - Green for elements returning to a normal condition;
  - Yellow for warnings and errors;

- Blue for other events.
- 6 In the **Alarm Settings** section, specify:
  - **Alarm (schedule)**—When this schedule is valid, the event will be sent to the Alarms Desktop of the selected workstations and will require an acknowledgement from the operator.
  - **Instructions**—Select the instruction that will be sent to the Instruction desktop with the event to be acknowledged. Instructions will only be sent when the alarm schedule is valid.



***NOTE:** For the SmartLink application, the instruction does not require that the alarm schedule be valid. You can leave the **Alarm schedule** field blank, and the instruction will be sent anyway.*

- 7 Assign the Priority level to the event. This determines the sequence in which alarms messages will be displayed to the operator in the alarm queue. The priorities are preset to the most common values (0 = higher, 9 = lower).

## To Create and View Associations

There are two types of associations:

- **Default.** The default associations are preset in the system. By default all events messages occur on all components associated with them and are displayed in all workstations. You may keep the default settings. However, EntraPass offers you the ability to create manual associations.
- **Manual associations.**

Default associations		Comments
Component	Workstation	
Default	Default	All events originating from all components are sent to all workstations
Default	(Specific) Workstation 2	All events originating from all components are sent to only Workstation 2
Specific (Door 1)	Default	Only events originating from Door 1 are sent to all workstations


The following table shows the three types of manual associations:

Manual association		Example
Component	Workstation	
Specific	Specific	Events generated by Door 1 are sent to only Workstation 1
Specific	Unspecified or default	Events generated by Door 1 are sent to all Workstations (default)

Manual association		Example
Component	Workstation	
Unspecified or default	Specific	Events generated by any of the Doors (Default) will be sent to only Workstation 1

Creating an Association

- 1
- In the Event parameters window, select an event from the Event drop-down list. From the component pane (on the left) select a component and then select an EntraPass application to which the event message will be sent.




- 2
- Click the Save icon to create the new association. In this case, *All access - Door opened* events that will occur on the selected door will be sent to the additional *workstation* computer (selected on the right-hand side).



**NOTE:** The *Save* icon is enabled only when the selected pair (component/event) is not yet part of an association.

## Viewing an Association

- 1 In the Event parameters window, select a component from the left-hand pane, then select a workstation in the Send to workstation pane.




- 2 Click the **View association** icon in the toolbar. The View default parameters message box shows the component and EntraPass application.
- 3 You can click the **Delete** icon in the toolbar if you want to modify the displayed association.


## Deleting and Restoring Associations

You may decide that events from Door 1 should no longer be sent to the Message Desktop of all workstations, but to a specific desktop. To do this, you have to delete the existing association and then create a manual association. It is recommended to use this feature with caution.

- 1 In the Event parameters window, select an event message from the Event drop-down list.



- 2 From a component, select a workstation in the Send to workstation pane then click the association icon. The View default parameters message box appears.
- 3 Click the Delete icon in the toolbar.



- 4 From the Delete event parameters window, make your choice:
- Restore default: this option will apply the default alarm and display settings.


- Delete association: if you select this option, the alarm and display settings fields will be left blank and ready for new information. Once you have deleted the settings, you must re-define them.
- Cancel: select this option if you want to cancel the delete operation.

## To Print Event Parameters

EntraPass allows you to print events parameters (alarm and display settings) for the selected events and the selected workstations.

You can also use the Font button to choose a different font (and font size) for your report.

- 1 From the Event parameters window, select the Printer icon.



- 2 In the Select events pane, select the events to be included in your printout or click on the Select all button to select all the events from the displayed list.
- 3 In the Select applications pane select the EntraPass workstation (or workstations) to be included in your printout or click on the Select all button to select all the EntraPass workstations from the displayed list.
- 4 You may check the Print empty fields option in the bottom of the window. If selected, the system will print the fields that do not contain any information. Only the field title will be printed.
- 5 You may check the Print with default values option. If selected, the system will print the default associations as well as manual associations.
- 6 You may check the Print components reference option. If selected, the system will print the component physical address next to the component identification.



**NOTE:** If you *do not* select this field, only manual associations (not involving defaults) will be displayed in the report. If you do not have manual associations (Component x with workstation y), the report will be empty.

- 7 Select the Preview button before printing, if desired.



## Instructions Definition

This menu is used to define instructions that must be assigned to events. When an alarm is generated, the instruction will display in the Instruction window (Desktop menu) for acknowledgement.




**NOTE:** This menu is also used to create instructions for the SmartLink application by using special macro-commands already built into the software.

Usually, each line will contain a single directive; the response instructions will be composed of several directives (lines). This allows for greater flexibility when modifications are required.

### To Define an Instruction

- 1 From the System main window, select the Instruction icon.



- 2 To create a new instruction, click the New icon. To modify an existing instruction, select one from the Instruction drop-down list.
- 3 Enter the instruction name/identification in the language section.
- 4 Select an appropriate language tab to enter the instruction. Instructions are entered in one selected language.



**NOTE:** You may enter up to 511 characters (including spaces) per instruction.

- 5 To assign instructions to events, see "Event Parameters Definition" on page 372.

## To Define a SmartLink Instruction

The Instruction definition menu allows you to create SmartLink instructions. If you have a SmartLink application installed, the Macro-insertion menu button is enabled. It allows operators to send built-in macro-commands to the SmartLink application.

- 1 In the Instruction window, select the Macro insertion menu for SmartLink button or right-click and a menu will be displayed.



**NOTE:** When creating SmartLink instructions, only commands that are written in the primary language are considered as valid commands. For more information on macro-commands, refer to your SmartLink Specifications Manual.

The following table describes the options you will find in the menu.

Date	▶
Time	▶
Event	▶
Location	▶
Information #1	▶
Information #2	▶
Information #3	▶
Information #4	▶
Card information	▶
Numerical value	
Character string	
Add delay	
Carriage return	
Trim right	
E-mail	
Modem	
Serial device for messages	
Serial device for commands	
File	▶
Execute	▶
Network	
Modify language	▶
Save SmartLink mode	
Restore previous SmartLink mode	

Parameter	Description
Date	Insert a date in the instruction. Options are: <b>Year, Month, Day, YYYY/MM/DD</b> or <b>MM/DD/YYYY</b>
Time	Insert a time in the instruction. Options are: <b>Hour, Minute, Second, HH:MM:SS</b> or <b>HH:MM</b> .
Event	Insert event description in the instruction. You can select to display event name ( <b>Text</b> ) or <b>Number</b> .
Location	Insert the location where the instruction must take place. Options are: <b>EntraPass Application, Gateway</b> or <b>Site</b> .
Information #1 to 4	Insert event information. Options in the database are: <b>Index Number, Index Text, Component ID</b> and <b>Component Text</b> .
Card Information	Insert card information in the instruction. Options are: <b>Card Number, Card User Name, Card Information #1 to #10</b> or <b>Comment</b> .
Numerical Value	Insert a number in the instruction.
Character String	Insert a string of characters (free text) in the instruction.
Add Delay	Insert a delay in 1/10 secs in the instruction.
Carriage Return	Insert a carriage return in the instruction.
Trim Right	Will delete the last character to the right of the instruction.
E-Mail	To insert and e-mail in the instruction that will be sent automatically when the event occurs.

Parameter	Description
<b>Modem</b>	To insert a message in the instruction that will be sent automatically through a pager when the event occurs.
<b>Serial Device for Messages</b>	Select the <b>Serial Com Port</b> and <b>Baud rate</b> to send the message.
<b>Serial Device for Commands</b>	Select the <b>Serial Com Port</b> and <b>Baud rate</b> to send the command.
<b>File</b>	<p><b>File</b> opens the Select a filename dialog that allows you to locate a file (or create a new one) where all event information entered in the instruction will be logged when an event occurs.</p> <p><b>Close</b> will close the file.</p> <p><b>Commit to disk</b> will save the file to disk. This command will not close the file.</p>
<b>Execute</b>	<p><b>File</b> opens the Select a filename dialog that allows you to locate the executable that will be used with the macro command.</p> <p><b>Parameter</b> opens the Enter Character Strings dialog allowing you to type a string of characters that will be added to the macro command.</p> <p><b>Action</b> allows you to define how you want to launch the macro (<b>Launch Hidden</b>, <b>Launch Normal</b>, <b>Launch Minimized</b>, <b>Launch Maximized</b> or <b>Terminate the process</b>).</p>
<b>Network</b>	Insert a <b>Network Tag</b> .
<b>Modify Language</b>	You can modify the command language to <b>English</b> or <b>French</b> .
<b>Save SmartLink Mode</b>	Insert in the SmartLink command to interrupt and place current SmartLink mode in the background (for example sending and e-mail). This command must <b>always</b> be used with <b>Restore Previous SmartLink Mode</b> .
<b>Restore Previous SmartLink Mode</b>	Insert in the SmartLink command to restore the previous SmartLink mode. This command must <b>always</b> be used with <b>Save SmartLink Mode</b> .

### Inserting an e-Mail Command in a SmartLink Macro

When building an instruction using SmartLink, EntraPass allows you to insert an e-mail command to that instruction.

- 1 Once you have selected an existing instruction or created a new one, click the Macro insertion menu for SmartLink and select the e-Mail command. The e-Mail instruction builder dialog will display on screen.

**E-mail instruction builder**

From... Network Administrator

To... Pos1; Pos2; Pos3; Pos4; Pos5; Pos6

Cc...

Subject Emergency Procedure


Attachment ...

Make sure that all doors have been secured after the emergency is over.

Clear OK Cancel Help

- 2 Enter the your e-mail address in the From... field.
- 3 Enter the e-mail address or addresses where the message should be sent in the Too... field. Each address should be separated by a semi-colon (;).
- 4 If you wish to send a copy of this e-mail to other people, enter their name in the Cc... field.
- 5 Enter the e-mail Subject.
- 6 If you want to attach a file to the e-mail, click the three-dot button to browse your directory and locate that file.
- 7 Enter the message in the large window.


- 8 Click OK to attach the e-mail to the SmartLink instruction. The message will appear in the Instruction window



### Inserting a Pager Command in a SmartLink Macro

When building an instruction using SmartLink, EntraPass allows you to insert a command that will send a message to a paging system.


- 1 Once you have selected an existing instruction or created a new one, click the Macro insertion menu for SmartLink and select the Modem command. The Modem instruction parameters dialog will display on screen.



- 2 Modem serial port parameter should already be setup.
- 3 Enter Dial information such as the pager Phone number.

Check the **Pager options** box and enter a **Message** that will display on the pager (if the receiving pager has the option to display) and the **Delay before message** will be sent to the pager.

- 4 Click **OK**. The phone number and message will appear in the **Instruction** window



## Message Filters Definition

The Message filter feature allows you to define filters for the Filtered Messages desktop. These filters are used to view a specific selection of events. For example, you may define specific filters for an operator: a Guard may be only interested by "Guard tour events". You can then create filters so that only guard tour events are sent to the Guard's EntraPass workstation.


There are many pre-defined filters such as: access events, controller events, etc. These filters can be accessed by all operators. You can select or create filters directly from the "Filtered Messages" desktop or from the Message Filters menu.



**NOTE:** For more information, see "Filtered Messages Desktop" on page 406.


### To Define Event for a Message Filter

- 1 In the System main window, select the Message Filter icon. The Message filter window appears.



- 2 From the Message filter drop-down list, select an event message type (for example: Door events or Relay events) for which you want to define a filter. You may also click the New icon to create your own filter.
- 3 From the Event list, select the events that must appear in the selected filter. You may check the Select all events option, if you do not want to select specific events. For example, for a Door events type filter, you may decide to include all events or select the Access-denied events.
- 4 Select the Door filters tab to filter doors that will send messages to the Filtered messages desktop. Additionally, when "Access events" are filtered, the cardholder's picture can be


displayed with the event (if pictures are assigned to cardholders). You can select which doors will display the cardholder picture when the event for this door is generated.




- 5 Check the **All doors** option or choose specific doors for which the cardholders's picture will be displayed an door event.
- 6 From the **Door filter type**, select the filter that will be used for filtering Door events:
  - **Door filter**: Only events related to the selected doors will be sent to the Filtered Message desktop
  - **Pictures filter**: Cardholders' pictures related to cards presented to the selected doors will be sent to the Filtered Message desktop
  - **Filters for doors and pictures**: Door events related to the selected doors as well as cardholders' pictures that triggered door events on the selected doors will be sent to the Filtered Message desktop.



- 7 Select the EntraPass applications tab to filter applications that will send messages to the Filtered Messages desktop.



- 8 Check the All EntraPass applications option for the Filtered Messages desktop to receive all events originating from all EntraPass applications defined in the system. You may also choose to display events from specific applications. To do this, select the EntraPass application from which you want to receive events.
- 9 Select the Gateway and site tab to filter gateways and sites events sent to the Filtered Messages desktop.




- 10 Check the **All events** option to receive events originating from the components of the gateways or sites. You may select the gateway or the site that will send events to be displayed.



**NOTE:** When you use filters, the system retrieves events that are already displayed in your Message desktop and sorts these events according to the settings of the selected filter. If events originating from a specific gateway are displayed in your messages desktop and this gateway is not selected in the filter definition, then these events will not be displayed when you select this filter.

- 11 Select the **Special filter** tab to filter events according to their type.



- **Picture:** all events associated with a cardholder's picture will be displayed in the Filtered Message desktop.
- **Fail-soft:** all events generated by a controller in stand-alone mode following a communication failure will be sent to the Filtered Message desktop. Fail-soft messages are identified with a + sign in the Filtered Message desktop (and Message Desktop) when this option is select when defining the Messages list properties (Desktop > Message Desktop > right-click an event > Properties).
- **Video:** all video record events will be sent to the Filtered Messages desktop.



**NOTE:** When you use filters, the system retrieves events that are already displayed in your Message desktop and filters these events according to the settings of the selected filter. If events originating from a specific gateway are displayed in your messages desktop and this gateway is not selected in the filter definition, then these events will not be displayed when you select this filter.

## Database Structure Definition


Use the Database structure menu to browse the system database. It will display the entire structure of the database including:

- The system *physical components* (EntraPass applications, gateways, sites, controllers, doors, relays, inputs and auxiliary outputs), and
- *Logical components* (cards, schedules, reports, instructions, groups, areas, alarm systems, etc.).

Operators can edit or sort the system components from the Database structure window.

### To View the Database Components

- 1 Form the System menu, select the Database structure icon.



**NOTE:** If the Video feature is enabled in EntraPass, its components will appear in the Database explorer.

- 2 To display only the Physical component, select the physical components icon. When selected, only the physical components of the database will be displayed.



**NOTE:** By default, physical components are **ALWAYS** displayed.

- 3 To display Logical components, select the logical components icon. When selected, logical components of the database will be displayed along with the physical components.
- 4 You may use the Refresh button to refresh the display in order to obtain the most recent information saved in the server database.
- 5 You may select the Full Expand button to fully expand the tree structure and view all sub-components of a selected component. For example, if you use this button on a controller, the

system will display the controller components (doors, inputs, relays) on the right-hand side of the window.

- 6 You may select the Collapse button to fully collapse the tree structure and hide all sub-components of a selected component.
- 7 To edit a component, right-click it and select **Edit** from the contextual menu. The system will display the definition window so you can modify the component's parameters.
- 8 To sort the component, right click the component, then select **Sort** from the contextual menu. Sort the components listed in the right-hand pane of the window for an easier find. You can sort by component address or name.



**NOTE:** You can define how the component's physical address will be displayed. This will also affect how components will be sorted. For more on this, see "Security Level Definition" on page 356.

## Chapter 12 • EntraPass Desktops

Desktops receive and display system events (current or historical), alarms, cardholders's picture, system graphics, etc. A desktop can also be used to acknowledge alarms, display instructions, etc. There are eight (8) pre-defined desktops. These can be configured as follows:

- Desktop 1: All system events
- Desktop 2: System events and pictures
- Desktop 3: Filtered system events
- Desktop 4: Filtered system event and picture, etc.
- Desktop 5: Alarms screen
- Desktop 6: Graphic screen
- Desktop 7: Network alarms screen
- Desktop 8: Video desktop, if the Video option is enabled in EntraPass.

The following windows can be combined with other desktops:

- Instructions
- Pictures
- Historical Reports

It is possible to display more than one window at a time. Depending on their security level, operators can modify the settings of each of these windows (background color, size, toolbar, etc.). However, an operator whose access level is 'read-only' on a given desktop cannot modify, move, maximize or minimize a desktop.



**NOTE:** Only operators with the required security level can customize their desktops (System menu > Access Level). They also have the ability to allow "Read-only operators" to modify their desktop settings. In this case, the changes apply only to the current session.


## Work Area Customizing

EntraPass enables operators with appropriate permissions to customize their work area and to modify the desktop properties.


To define an operator's security level: System menu > Security Level.

### To Change the Display Properties

- 1 From the Desktop window, right-click anywhere in the window.



- 2 Select Properties from the shortcut menu.



- 3 From the Properties window that appears, select the display options: you may change the default size of buttons, the default background color, etc.

- **Small buttons:** If this option is selected, small components' icons are displayed with no descriptive text. This option can be appropriate for operators who are familiar with Entrapass icons and do not need an additional description.
- **Large buttons with images:** Icons are displayed with their description.
- **Large buttons without images:** Large buttons are displayed with no description.
- **Display menu:** check this option to view the system menu.
- **Display toolbar:** check this option to view the toolbar for system menus.
- **Background color:** select a background color for the whole work area.
- **Change system font:** click this button to change the font for all the user interface.

---

## Specific Desktop Customizing

Entrapass enables operators with appropriate permission to customize their desktop. Moreover, operators with full access permissions can permit operators with read-only permission to customize their desktop for a limited time. They can also customize a specific desktop and transfer this customized desktop to other operators using the Assign desktop feature. The following sections explain how to customize a desktop:


- Customizing a desktop by a full access operator
- Customizing a desktop for a read-only operator
- Transferring a customized desktop

### To Customize a Desktop (Full Access Operator)

Operators with full access permission have the ability to customize their desktops. To grant full access to an operator: (System > Security Level).



- 1 Select the desktop you want to customize, then right-click to open the Desktop properties window, then select Properties from the short-cut menu.



**NOTE:** If the Video option is enabled in EntraPass, the Video desktop option appears in the lower part of the Desktop properties window.

- 2 From the Desktop name field, assign a meaningful name to the desktop you are configuring.
- 3 Select the window type:
  - **Floating window**—a floating window can be resized and positioned anywhere in the work area screen. For example, you can choose to send it to the back or to bring it to the front. If a floating window was sent to the back, you may bring it to the front by right-clicking the desktop button, then selecting the Bring to front menu item.
  - **Desktop window**—a desktop window is trapped within the work area. It is not possible to send the window in the background. It always remains within the main work area.
- 4 To save your changes:
  - Click OK—If selected, you just save your the changes, the window is not displayed.

- Click OK & GO—If selected, this function saves your changes and displays the window you have just configured.




**NOTE:** When opening a desktop window for the first time, you may need to re-size it in order to view the information correctly. To do so, point to the frame border you want to change; when the pointer turns into a double-headed arrow, drag the border to exact size. You may then position the window in the work area to the desired position.

## To Customize a Desktop for a “Read-Only” Operator

The security manager or an operator with the appropriate security level can give permission to operators who do not have the appropriate permission to customize their desktop during a session.

- 1 Log on, using the user name and password of the operator with ‘read-only’ security level. To do this, use Kantech2 as the username and kantech as the password.
- 2 Then, right-click a desktop, then select Properties. The desktop properties window appears.




**NOTE:** The *Permit* button appears when the operator who is logged on has ‘read-only’ access permission. The permission acquired during this session will be valid until the operator logs out.

- 3 Click the Permit button. The operator login window appears. Enter your username and password, and click, OK. The temporary permission will be granted.


## To Transfer a Customized Desktop

Another possibility available to the Security Manager (or to the operator with the appropriate security level) is to customize a desktop, and then to assign the settings to other operators who may not have the appropriate security level to modify their desktop settings.

- 1 Right-click the desktop you want to assign the settings.



- 2 Select the Assign (desktop) option from the shortcut menu.



- 3 From the displayed window, select the operators to whom you wish to assign the desktop properties (you must check the appropriate checkbox). You may select operators one by one, or you may use the Select all button.

## Message List Desktop

By default, the first desktop is defined as the Messages List Desktop. It displays all system events. Events are displayed with their icon, date and time, description, system components involved in the event such as controllers, cardholder pictures (if defined), etc. When a new event is displayed, the window scrolls up. The newest events are added at the bottom of the window.


### To View and Sort System Events

By default, the first desktop is dedicated to displaying system events. When you select an event from the list, you interrupt the incoming sequence (the green status indicator located at the bottom left part of the desktop turns red when scrolling is interrupted). By default, the scrolling will restart automatically after a pre-set period of time, unless the auto-scroll parameter was disabled. In that case, to restore the normal scrolling, click the Restart Scroll button.



**NOTE:** If you configure a Desktop as a message screen and a picture screen, two windows are displayed simultaneously when you select the desktop.

- 1 Select the first desktop. By default, all system events are displayed in ascending order with an area at the bottom of the screen that displays the selected event in the list.



**NOTE:** You may change the message color: *System > Events parameters*. You may also change the events display order; see "To Customize Event Display in the Message Desktops" on page 399.


- 2 From the Message list screen, you may change the sorting criterion (Sorted by scroll-down list). You may choose to sort by:

- **Sequence**—Events are sorted according to the normal sequence (default). New events are added at the bottom of the window. (This option is not available for Archived Messages Lists.)
- **Date and time**—This sort order interrupts the normal scrolling of events. This feature is useful when you want to know when an event was generated. This time may be different from the “normal sequence” for dial-up sites for instance or after a power failure.
- **Event**—When selected, the system sorts the Event message column in alphabetical order, grouping *identical* events. For example, all **Input** in alarm events are grouped together in alphabetical order.
- **Message type**—When selected, the system sorts the Event message column in alphabetical order, grouping *similar* events. For example, all **Site** events are grouped together in alphabetical order.



**NOTE:** To go back to the default display, Select **Sequence** from the **Sorted by** drop-down list.


- 3 Click the **Text filter** button (top of the window) to display specific events containing a text string. When you do this, the **Find** dialog box appears. Enter the string that will allow you to display specified events, then click the **Find next** button.



- 4 To close the **Find** dialog box, click the **Cancel** button or the Windows closing button (X).
- 5 To return to the normal display in the **Messages** list screen, click the **Text filter** button.

## To Customize Event Display in the Message Desktops


- 1 From the displayed shortcut menu (**Message desktop** > **Right-click a message**), select **Properties**.




- 2 From the **Properties** window, select the appropriate display options.

- **Multi-line**—Usually, events are displayed on a single line. You can increase the line spacing between events by checking the appropriate option (1, 2, 3 or 4 lines).
- **Show icons** —You can choose to display different types of icons beside each event.
  - **Message type**—When you select this option, the system inserts an icon next to events indicating the type of event. For example, if the event is a “door forced open” an icon representing a door is displayed (a hand represents a manual operation, a diskette represents the operation that modified the database, etc.). Access events are represented by the login/logout icons.
  - **Picture**—When you select this option, the system inserts a card icon next to events containing cardholder pictures.
  - **Fail-soft messages**—When you select this option, the system displays a plus (+) sign next to the events that occurred when controllers were off-line.
  - **Video**: check this option if you want the selected desktop to display video data from the video server connected to your system.
- The Miscellaneous section allows you to enable additional options:
  - **Keep card picture**—When selected, the system keeps the latest card picture (if the Picture window option is selected) until another event containing a card occurs.
  - **Display toolbar**—Displays/hides the toolbar on the top of the Message Desktop.
  - **Manual properties save only**—When you select this option, you have to click the Save button (once selected, the button is disabled). The system saves all the settings defined in the Properties window as well as the position of the window within the Messages Desktop.
  - **Display selected messages (full)**—When you select this option, a smaller window is added at the bottom portion of the Message window. It displays the selected event with its full description. This feature is very useful when your Message window is too small to display the entire description of an event.
  - **Display events in bold**: select this option to increase the legibility of text event messages displayed in EntraPass desktops (Message list, Filtered messages and Alarm desktops). Moreover, if the color selected for an event message is the same color as the background color, the event message will be displayed in black bold so that it can always stand out. (This option is not available for Archived Messages Lists.)
  - **Last Message on Top**: By default, event messages are displayed in ascending order of occurrence, with the area at the bottom of the screen reserved for the highlighted

event. You can select to display the events in descending order, with the highlighted event showing above the list of event messages.



## Ascending Order



## Descending Order

- Auto-scroll delay (mm:ss): Will automatically start scrolling the message list after a pre-set delay when the operator selects an item in the list. By default, this option is turned on with a preset delay. You can select to turn this option off which means that the operator will have to click the Restart Scroll button in the Messages List. (This option is not available for Archived Messages Lists.)
- Message background color—Allows the operator to modify the background color of the message window.



**NOTE:** To change the font color of system messages: System > Event parameters.

### To Perform Tasks on System Messages

Entrapass enables you to perform various tasks on system events. These include:


- Deleting messages

- Viewing card information
- Validating card status and card transaction
- Modifying the desktop properties (such as display options), etc.
- Play, edit and export video recordings
- Play archived videos from the EntraPass Video Vault



**NOTE:** Some tasks are related to the selected desktop. For example, if you right-click an alarm event, the shortcut menu displays tasks that are related to alarm events. For details, see "Alarms Desktop" on page 411.

- 1 From the Message desktop, right-click an event to enable a shortcut menu:



- 2 Do one of the following:
  - **Delete all**—This option allows an operator to delete all the events displayed.
  - **Card**—This menu item offers two choices: **View card transactions** and **Search card**. Select **View card transactions** to display all access information related to the cardholder who has triggered the access event. The **Search card** shortcut allows you to browse the card database and to display information about a card from the **View card information** window. From this window, operators can perform a variety of tasks including viewing and validating information contained on a card, such as the card number, cardholder name, card state (valid or invalid), card type, etc. They can also select a card and view its transactions or view and validate a card access. For details about validating cardholders' access and last transactions, see "Cards Definition" on page 258.
  - **Video recording**— This menu item offers three options: **Play**, **Play/Edit/Export** and **Play from Vault**. Selecting **Play** allows users to play the video event in the **Playback** window,



offering options to snap (copy) it and save it for future use. Selecting Play/Edit/Export offers users features similar to the ones in the Video Event List. Operators can then display details about the event (camera, server, comment field) and camera information, etc. The video event can also be played and exported. Selecting Play from Vault allows operators to view a video that is already stored in the Entrapass Video Vault.



**NOTE:** *If camera icons are not displayed, simply right-click a video event message, select properties from the shortcut menu, and check Video in the Show icons section of the Properties*

- **View parent**—Displays the parent of each component related to the selected event.
- **Edit**—This feature offers you the ability to edit each component associated with the selected event. If Edit is selected, a shortcut menu displays components associated with the selected event. In this example, the *Site definition modified* event involves the Entrapass application, the operator who was on duty when the event was generated and the site related to the event. It is now possible to edit any of the three components by selecting it from the shortcut menu.



**NOTE:** *If the selected event is an access event and if the card that triggered the event has already been registered in the system, it will be possible to edit the card. However, if the card is associated with an Access denied - card unknown event, the card will be created and registered in the system.*


- **Send to back**—This option only works when the window type is set to floating. It sends the active window behind the main application window. To bring back to front, right click the desktop button, then select Bring to front.
- **Properties**—This menu item enables users to modify the display properties for the selected desktop.

## Picture Desktop

If you selected Picture screen when defining the Message desktop, the Message desktop always appears with a Picture window. Access events are displayed with the cardholder's picture if you have set the appropriate display option in the Message filter definition (System > Message filters). For details, see *"Message Filters Definition"* on page 385.


### To Modify Pictures Display Options

- 1 From the Filtered Message list and Picture, select an access event, then right-click the cardholder's picture.



**Send to back**—This option only works when the window type is set to floating. It sends the active window (Picture window) behind the Message desktop main window. To bring it back to front, right click the Message desktop button, then select **Bring to front** from the shortcut menu.

- 2 From the shortcut menu, select Properties.



- 3 From the Aspect drop-down list, select the display size for the picture:

- **Design size:** the cardholder's picture will be displayed with its original size.
  - **Stretch** —This option stretches the picture to the window size without maintaining proportions. The picture may appear distorted.
  - **Stretch ratio**—This option stretches the picture to the window size while maintaining proportions.
- 4 Select the information you want to see displayed with the cardholder's picture:
- **Door:** The door where the card was presented will be displayed above of the cardholder's picture
  - **Event:** The event message will be displayed
  - **Card information:** The card information field will be displayed above the picture.
  - **Comment:** If this option is selected, a comment field appears below the cardholder's picture. The comment entered when defining the card appears in this field.

## Filtered Messages Desktop


The Filtered Messages desktop allows operators to display specific events. For example, you can create filters to display events that are related to a specific controller and from a particular gateway of the system. If this is the case, those events will be displayed in the Filtered Message desktop. Filtered messages are defined in the Message filters menu: System > Message filters.



**NOTE:** When you use filters, the system retrieves events that are already displayed in the Messages desktop and filters these events according to the selected filters.

### To Configure a Filtered Messages Desktop

- 1 From the Desktop main window, select the desktop you want to configure as a Filtered messages desktop.
- 2 Assign a meaningful name to the Filtered message desktop; then define the desktop type (Message window, Picture window or both).



- 3 You can change the Text filter, to display specific events. For details on the Filtered messages desktop, see "Message List Desktop" on page 398.

# Historical Report Desktop

The Historical Report desktop allows operators to display events that come from pre-defined, historical reports, view the report generation state and, when available, to play video recordings from the EntraPass Video Vault. Security levels will determine which historical reports are available to each operator.


The Historical Report message list operates the same way as all message lists in EntraPass except that it has an extra combo box that allows operators to select a pre-defined historical report.

Historical reports are defined under Report > Historical Report

Security levels for reports are defined under System > Security Level > under the Report tab.

## To Configure a Historical Reports Desktop

- 1 From the Desktop main window, click the desktop button you want to configure as a Historical Reports Desktop.
- 2 Assign a meaningful name to the Historical Reports Desktop, then define the desktop type (Message window, Picture window or both).




- 3 Select the sort criteria you want to use to display historical data (Date and Time, Event, or Message Type).



**NOTE:** The sequential sort option is not available for archived messages.

- 4 You can enter a text string that will be used for searching specific archived messages (when applicable).
- 5 In the combo-box, select the historical Report you want to generate. The list of available reports corresponds to your security level.

- 6 After selecting the report, a Date and Time window will popup requesting a reporting date and time period.



- 7 Enter Start and End date and time or click the calendar icon to open the calendar and select the start and end dates, and then type in the start and end times.
- 8 Check the Empty screen box process request box in order to clear the Historical Report message list of the previous search results.
- 9 Click OK. The status indicator light located at the bottom left of the screen will change from green to blue to indicate a historical report is being generated. It will turn green again when the data transfer will be completed and the historical data will be displayed according to the criteria you have selected.


## To Create and Edit Historical Reports

- When your security level allows you to create new reports, you can access the Historical Report dialog from the **New Report** command in the Historical Report Desktop pop up menu. For more information on Historical Reports, see *"Historical Reports Definition" on page 435*
- When your security level allows you to edit existing reports, you can access the Historical Report dialog from the **Edit Report** command in the Historical Report Desktop popup menu. For more information on Historical Reports, see *"Historical Reports Definition" on page 435*


## To Display Historical Report State in Real-Time

This feature allows you to view the progress of report generation for a specific report in the Historical Report Desktop List

- 1 Right-click an entry in the Historical Report Desktop window. A contextual menu will pop up.




- 2 Select Report State. The Report State dialog will open displaying Report generation information.



- 3 When the report is finally generated in the Desktop window, the information in the Report State dialog will disappear. Click Close.

## To Play Archived Video Recordings from a Desktop Message List

- 1 Select the video you would like to play and right-click to access the contextual menu.



- 2 If the video has been stored into the Entrapass Video Vault, the Play from Vault option will be enabled. Once you click on it, the Video Playback window will open and start playing the selected recording.



## Alarms Desktop

The Alarms desktop is used to view and to acknowledge alarm events. Alarm events are defined in the Event Parameter menu (**System > Event Parameters**). Any event can be defined as an alarm event. Alarm events require operator acknowledgment and are displayed in the Alarms desktop. A schedule must be defined for all alarms (**System > Event parameters, Alarm settings**). When an alarm is generated during a valid schedule, operators have to acknowledge the alarm. Alarms are displayed with date and time, alarm description, details, instructions (if defined) and associated graphic or video clip. New events are added at the bottom of the Alarm desktop unless you have setup the list to display in descending order (in the Alarm Desktop Properties dialog).



**NOTE:** An Alarm desktop may be defined as a Message window, a graphic window and an Instruction window. These features may apply to a single desktop. When you select a desktop defined with these three features, three windows are displayed simultaneously. For a better display, you may need to resize and to position the windows.


## To Define an Alarms Desktop

- 1 From the Desktop main window, select the desktop in which you want to display alarm messages, then define the window type: Floating or Desktop type.

- 2 Specify the secondary windows that will be associated with the Alarms desktop:
  - **Display on new alarm**—Will open the Alarms desktop automatically when an alarm occurs.
  - **Message screen**—This window allows operators to view and acknowledge alarms that have an “acknowledgement schedule” selected in the Event Parameters definition menu (System > Event Parameters, Alarm settings).
  - **Instructions screen**—This window displays the instruction that is linked to the event to be acknowledged (i.e. call the police, send a message to a client application, etc.). Instructions are defined in the System > Instructions. Then after, they may be associated with events.
  - **Graphic screen**—This window will display the location of the alarm being reported (if graphics are defined in the system). For more information on assigning graphic, see *"Graphics Definition" on page 217*.

## To View System Alarm Messages

- 1 Select the Alarm desktop. Alarm events are displayed according to the criteria selected in the Sorted by field.




- 2 You can double-click the log area (middle of the window) to add a comment. The Add a comment window opens and enables you to enter text data. Once you have finished and clicked the OK button to close the window, the alarm event will be preceded by a + sign, indicating that an annotation has been added to the alarm event.
- 3 You may change/define the sorting order (Sorted by drop-down list):
  - Sequence—alarms are sorted by their order of arrival. This is the default sequence. The window scrolls to the end each time a new alarm is displayed.
  - State—alarms are sorted according to their status (acknowledged, to be acknowledged or flagged). When you use this option, you interrupt the normal scrolling of events. Select "sequence" to go back to the default display.
  - Date and time—alarms are sorted according to the date and time of their arrival.
  - Event—The Event messages column is sorted in alphabetical order, grouping *identical* events. For example, all *Input in alarm* events are grouped.
  - Priority—Events are sorted by priority (as defined in Event parameter).
- 4 You may right-click anywhere in the window to enable the Properties window from which you can enable alarm status icons:
  - Red—To be acknowledged or suspended. If suspended, the suspension delay is displayed. When the delay expires, the operator is required to acknowledge again. If the delay is not expired but the operator wishes to acknowledge a suspended alarm, he/she has to click on the delay. The delay will be reset to zero.
  - Green—Acknowledged.
  - Yellow—Flagged.

- **Black**—Deleted. To view alarms that have been manually deleted, select the **View deleted logs** from the **Properties**.
  - **Blue**—Manual log.
- 5 Select the **Manual / Automatic** buttons to toggle the acknowledgement method (automatic or manual). Only operators who are assigned this feature in the **Operator Definition** menu can use this option. For more information, see *"Operators Definition" on page 352*.



**NOTE:** The **Manual / Automatic** acknowledgement option is only available through the **Alarms Desktop**. When the operator logs out, it will return to "manual" by default.

- 6 Right click an alarm message to perform additional tasks on alarm events:



- **Manual log**—When selected, the system displays the **Manual log** window to allow an operator to add log comments, and hence to generate a customized event (with priority, event details, color etc.). When a manual log is added, a hand and a blue circle are added beside an alarm message. These are visible when icons are enabled (right-click an alarm event > **Properties** > **Show icons**)
- **Acknowledge**—When selected, a green point is inserted beside an alarm message to indicate that the event was acknowledged.
- **Flag**—When selected, the system flags the selected event. A yellow indicator is inserted beside flagged events.
- **Add comment**—Allows operators to enter comments concerning the selected event. The added comments are displayed in the bottom part of the alarm window. A blue + sign beside an alarm message indicates that a comment was added to the alarm message (visible when icons are enabled: right-click an alarm event > **Properties** > **Show icons**)
- **Print log**—When selected, the system prints the alarm message.
- **Delete log**—When selected, the selected alarm message is marked for deletion (the indicator becomes "black" to indicate that the log has been marked for deletion). To view


the logs marked for deletion, before you actually purge them, right click anywhere in the window and select Properties then select View deleted logs.

- Purge deleted log—Select this option to permanently remove logs that were marked for deletion.

### To Display Alarm Desktops Automatically

Entrapass enables users to display graphics automatically - from any desktop - as soon as an alarm occurs. This feature enables operators on duty to automatically view new alarms without having to open the alarm desktop and secondary windows associated with it. If Display on new alarm is checked the alarm desktop (and its secondary windows) will be displayed as soon as an alarm occurs regardless of the active window.

- 1 Define a desktop and customize it as an alarm desktop: for this, you have to check the items of the Alarms desktop section.



- 2 Check the **Display on new alarm** option so that operators can automatically view new alarms without having to open the alarm desktop and secondary windows associated with it.



***NOTE:** If this option is checked and if an operator calls up the alarm desktop, the desktop icon background color turns blue, indicating that the alarm and its secondary windows are displayed when a new alarm occurs. If however this option is selected when defining a Filtered message desktop for instance and if the desktop icon is selected, the filtered message desktop will be displayed (the background color of its icon turns blue), but the windows below the Display on new alarm section will not be displayed; they are only displayed when a new alarm occurs. If those windows are displayed (on new alarm), clicking the "X" in the top right hand corner of one of them will close all the open windows. If **Display on new alarm** is not checked, the alarm desktop and all its secondary windows will be displayed on call (that is, when the alarm desktop is selected).*

- 3 Click **OK** and **Go** for your configuration to take effect immediately.



***NOTE:** When you define a desktop as an alarm desktop to be displayed on new alarm, it is recommended to reopen the Automatic Alarm Display desktop, to position its windows the way you want them to appear, then to click **OK** and **GO** again. This way, it will appear exactly as you have defined it.*

## To Acknowledge Alarms/Events

Usually, operators have to acknowledge receipt of an alarm condition (event—such as intrusion, input in alarm, etc.) by responding in ways such as depressing an acknowledgment button. In EntraPass, operators acknowledge alarm messages from an alarm warning box or from the Alarms desktop window.



***NOTE:** A sound can be added to alarm events. For more details about setting options for an alarm sound, see "Multimedia Devices Configuration" on page 470.*

Acknowledgement options are setup in the EntraPass application definition (Devices > EntraPass application (selected Workstation) > Alarm tab, Acknowledgement parameters). Events that require operator acknowledgment are defined in the System > Event Parameters.



***NOTE:** If the component that is in alarm is assigned to a video view, the video view or video recording is automatically displayed when an alarm occurs.*

### Automatic Acknowledgement


Alarms can be automatically acknowledged without operator intervention. This option is enabled in the Operator definition menu (System > Operators > Privileges, Auto acknowledge).



***NOTE:** Only operators granted the appropriate access privilege should be using this option. If the **Automatic acknowledge** feature is used, the alarm message box is not displayed; therefore, it will not be possible to suspend alarms. If this option is enabled in the Operator definition menu, the **Manual** button is added to the Alarms desktop. This button toggles between Manual and Automatic acknowledgement.*

## Acknowledging an Alarm Message

- 1 When the Acknowledgement required message box appears, take one of the following actions:



- Click the **Acknowledge** button to acknowledge the displayed alarm event. The red status button turns green once an alarm is acknowledged.
- Click the **Suspend** button to suspend alarms while doing other operations in the system. The alarm will be suspended for the delay time specified in the **EntraPass** application definition menu. Once the suspended alarm delay time expires, the system prompts the operator to acknowledge the alarm.
- Click the **Flag** button if you want to acknowledge an alarm message, and if you want to identify it for future reference. A flagged alarm is identified by a yellow button.
- Click the **Mute** button if you want to stop the alarm sound.



**NOTE:** The *Acknowledgement required* message box will be presented in a format without the Instructions window if there are no instructions associated with the alarm message.

**NOTE:** If the component that is in alarm is assigned to a video view, the video view or video recording is automatically displayed when an alarm occurs.

---

## Acknowledging Alarms from the Alarms Desktop

- 1 Select the alarm event you want to acknowledge (one that has been flagged, for instance), Right-click to enable a shortcut menu.
- 2 Select Acknowledge from the sub-menu. The status indicator becomes green.



*NOTE: To tag an alarm message for specific purposes, select the alarm event you want to identify; right-click and select **Flag** from the sub-menu. You can also click an alarm message until the color of its status indicator changes to the desired color.*




# Instruction Desktop


The Instruction window displays the instructions to follow when an alarm is reported. Instructions will only be displayed if this option is enabled during the Event Parameters settings (System > Event parameters, Alarm settings).

## To View an Instruction about an Alarm Message

- 1 You may view instructions about an alarm by selecting the Alarms desktop defined as a message and an instruction window, or defined as an instruction window. When a desktop is defined as being both a message window and an instruction window, the two windows are displayed at the same time:



- 2 You may also view an instruction about an alarm by selecting an alarm message and right-clicking it.



**NOTE:** This feature is very useful when the Alarms desktop is too small to display the entire description of an event.


## Graphic Desktop

The Graphic desktop displays the graphical location of the alarm being reported (if graphics are defined in the system). A graphic corresponds to the secured area of the system where components (EntraPass application, controllers, inputs, relays, etc.) are located on a site.

With graphics, operators can easily view the exact location of a component installed on a site, or the status of components and devices such as doors, contacts, motion detectors, controllers, assigned to the graphic. Operators can perform manual operations directly from the displayed component (for example lock/unlock a door). To define interactive floor plans, see *"Graphics Definition"* on page 217.

### To View Graphics in the Graphic Desktop

- 1 Right click the desktop icon you want to assign to graphic, name the desktop (Graphics, for example), then define the window type (Floating or Desktop).
- 2 Click OK and Go to display the Graphics desktop.
- 3 Right click anywhere in the Graphic desktop, then, from the shortcut menu, select the graphic you want to display.




**NOTE:** If the window is smaller than the graphic size, you can click-hold-and-drag the graphic to move it around within the Graphic window.

- 4 You may right click anywhere in the graphic to enable a shortcut menu in order to:
  - Adjust the display size of the selected graphic (Fit to screen, Design size or Picture size).
  - Select Auto result for the system to display a message indicating the cause of the communication loss in case of communication failure. If Auto result is not selected,

operators will have to manually request the results for the component by using the Show result.

- 5 Right-click a component in abnormal condition to enable a sub menu:



**NOTE:** Components in alarms are represented by their animated icons. Selecting an animated icon and viewing its parent components allows operators to learn more about the “alarm condition”.

- 6 Select Full status from the shortcut menu to display the error list related to one or all the components in alarm.
- 7 Select the Double click menu item to allow operators to modify the status of a component in alarm from the Graphic desktop. For example, if the displayed component is a door and if the *Double click* menu item was set to Unlock, an operator can manually open the door from the Graphic desktop.



**NOTE:** When you modify the Double-click feature via the Graphic desktop, the system does not save the modifications. Modify the default Double-click feature via the *graphic definition* (Definition > Graphics, Design window, right click a component > Default dblclick menu item). For more information on how to create graphics and on how to assign components to graphics, see “Graphics Definition” on page 217.

## Network Alarms Desktop

The Network Alarms desktop is used to view *all* the alarms in the system. Only events that require operator acknowledgment and that are programmed in the Event Parameters menu are displayed in the Network Alarms Desktop.




**NOTE:** Network Alarms are available on all workstations of the system. By default the server sends network alarms to all workstations at startup. If you do not want the system to automatically send network alarms, use the *No reload on startup* option (*Devices > EntraPass application > Network Alarm tab*). This option is useful when the connection between the workstation and the server is slow.

Operators will only be authorized to view network alarms that were sent to the Applications that are selected in their security level definition menu.

### To View Network Alarms

- 1 Select the Network Alarms desktop.



- 2 Right click anywhere in the window to enable a shortcut menu:
  - Refresh: this options allows operators to load new alarm messages in the Network alarms desktop. The Refresh menu item is particularly useful when the server does not load automatically network alarm at startup; that is, when the No reload network alarms on startup option is checked in the Workstation definition menu (*Devices> Workstation > Messages 1 of 2 tab*).
  - Print log—When selected, the system prints the alarm message.

- Delete log—Purges alarm records from the system. When you select this option, the Delete network alarms window appears. You can then specify the Deletion option (selected, all or custom messages).



*NOTE: To limit the number of records kept in the alarm database, use the **Maximum records in system logs: Options > Server parameters > Server tab**). This option is used for the server and workstation alarm message databases.*

## Video Desktop

If the Video feature is enabled in EntraPass, you can configure a desktop as a Video desktop.










### To Define a Video Desktop


- 1 From the **Desktop** menu, right-click a desktop to bring up the Desktop properties window.
- 2 In the **Desktop name** field, assign a name to the new desktop.
- 3 Select the window type for this desktop.
- 4 Check the **Video window** option.

### To Use the Video Desktop

- 1 In the Desktop window, select the desktop defined as the Video desktop. The Video display window appears.
- 2 Select an icon (in the lower part of the window) to determine for instance the size of the views or to display the Panel window (a small window associated with the video display).

The following table shows the available options:

View Icon	Description
	Large. This view sets the window to 1024x768 pixels
	Medium. This view sets the window to 800x600 pixels
	Small. This view sets the window to 640x480 pixels
	Tiny. This view sets the window to 400x300 pixels.
	Creates a new video view
	Shows panel window
 Video playback	These buttons appear in the lower part of the Video desktop when the operator who is logged on was assigned specific permission for viewing and generating video events. This custom buttons offer a fast way for viewing or generating video events.
	Edits the current video view
	Shows the help related to the Video desktop

View Icon	Description
	Closes the Video window



## Video Server Status


Entrapass offers the ability to display parameters of the video devices connected to the Video server. Operators can for example view information related to network data transfer (images and digital sounds).



*NOTE: Installing and using the Video feature may take a great amount of your company network bandwidth (LAN or WAN). The network administrator may control the use of the network bandwidth for Video transfer.*

### To View the Video Server Full Status

- 1 From the Graphic desktop window, right-click the Video Server icon to display a shortcut menu.



2 From the shortcut menu, select Full status to display information about the video server status.

**Full status : R&D**

Unit name	INTELLEX	10.15.0.100	Unit type	Intellex	
Schedule mode	Regular	Record mode	Circular	Record rate	60
Recording in progress	True	Recording mode	NTSC	Total number of images	63009026
Time span (h:mm)	146:10	Estimated remaining images	0	Version compatibility	Yes
Unit version	3.1.35	Interface version (API)	3.1.14.1	Number of text	1
Number of cameras	16	Number of audio	0		

Video List

#	Connected	Recorded	Camera	Termination	Camera control	Quality	Sensitivity	Mode	Pre-Alarm Time	Record Rate
0	True	True	Camera #1	75 Ohms	Dome	Normal	Normal	Active	0	18
1	True	True	Camera #2	75 Ohms	Fixed	Normal	Normal	Active	0	18
2	True	True	Camera #3	75 Ohms	Fixed	Normal	Normal	Active	0	18
3	True	True	Camera #4	75 Ohms	Fixed	Normal	Normal	Active	0	18
4	True	True	Camera #5	75 Ohms	Fixed	Normal	Normal	Active	0	18
5	True	True	Camera #6	75 Ohms	Fixed	Normal	Normal	Active	0	18
6	True	True	Camera #7	75 Ohms	Fixed	Normal	Normal	Active	0	18
7	True	True	Camera #8	75 Ohms	Fixed	Normal	Normal	Active	0	18
8	True	True	Camera #9	75 Ohms	Fixed	Normal	Normal	Active	0	18
9	False	True	Camera #10	75 Ohms	Fixed	Normal	Normal	Active	0	1
10	False	True	Camera #11	75 Ohms	Fixed	Normal	Normal	Active	0	1
11	False	True	Camera #12	75 Ohms	Fixed	Normal	Normal	Active	0	1

Audio and Text List

#	Type	Name	Video association mask	Text ID
0	Text	Test Text	FFFFFFFF	2

Retrieved status data successfully



**NOTE:** The content of the Full Status window depends on the video server associated with EntraPass.

The following list provides a short description of the displayed fields.

Item	Description
Unit name	The network name of the remote DVMS system (Intellex in this example). The Unit name is followed by the DVR IP address
Unit type	The type of the unit. can be Intellex, Iris (network client), etc.
Schedule mode	The current schedule mode of the remote DVMS unit. It indicates how images are recorded by the DVR installation. The values for this field can be: <ul style="list-style-type: none"><li>Regular (regular schedule)</li><li>Single (only a single camera)</li><li>Custom (a custom schedule has been set by the operator).</li></ul>
Recording in progress	The active record statue of the remote DVMS unit. Values can be: <ul style="list-style-type: none"><li>True: is recording</li><li>False: is stopped.</li></ul>
Time span (h:mm)	The time interval (in second) between the oldest and newest images in the database.
Unit version	The official version of the DVMS unit.

Item	Description
Number of cameras	The number of cameras connected to the Video server. The source of the video data is generally a camera, but it may also be a television station or other video source. The value varies from 0 to 16.
Record mode	The record mode can be linear or circular <ul style="list-style-type: none"> <li>• (Linear: if you select this option, the recording will continue uninterrupted until the available space is finished;</li> <li>• Circular: if you select this option, the DVR will notify the operators before the recording space is completely filled. The operator will then choose to continue the recording or to stop it. By default, the recording mode is set to Circular.</li> </ul>
Recording mode	The recording standard of the remote unit. The recording standard depends on the area. Values can be: <ul style="list-style-type: none"> <li>• NTSC: the NTSC standard is mainly used in America and in many Asian countries such as Japan and South Korea or</li> <li>• PAL: the PAL standard is mainly used in Germany, Great Britain, China, Australia and Brazil.</li> </ul>
Estimated remaining images	The estimated number of frames that may still be recorded in the video database before the DVMS unit space is completely filled. This option is only useful if the recording mode is linear.
Interface version (API)	Indicates the version of the application interface between EntraPass and the selected Video server.
Number of audio	The number of audio streams available of the video server unit. The source of the audio data is generally a microphone, but may be another audio source.
Record rate	The rate code value. This value indicates the aggregate recording rate for the DVR unit in number of frames per second. The value can be: 1, 2.5, 7.5, 15, 30, 60, 120, other value.
Total number of images	The total number of images in the remote unit's database.
Version compatibility	Compatibility between the versions of the DVR unit and the application interface used.
Number of text	The numbers of text data streams available from the DVMS. The text data source may be a cash register or other device.



---

## Chapter 13 • Reports

Entrapass software allows users to define and generate reports. These reports may be generated automatically or requested manually. Reports can be sent by e-mail or by using SmartLink.

There are three types of reports:

- **Quick reports:** these are based on selected group of events (i.e.: door, controller, etc.) and event types (normal, abnormal, etc.)
- **Historical reports:** these are historical and card use reports. The historical report type contains archived and filtered events, whereas card use reports contain events related to card use.
- **T & A reports (Time and attendance):** these are defined according to selected doors and cards defined as time and attendance.

From the Report toolbar, Entrapass users may also:

- **View reports**— this feature allows an operator to select pre-defined reports to view on screen or to print.
- **View Report states**—this features allows an operator to view the status of all reports that have been previously generated.
- **Perform Manual operations** on Time and Attendance reports to add, insert, and delete Time and Attendance entries.

## Quick Report Definition

The Quick report feature offers a rapid method of creating reports for certain types of events. For example, it is possible to create a report regarding all abnormal or normal access events in just a few seconds.

Quick report files may be viewed using the EntraPass Quick Viewer, a utility that allows users to display Quick report files and all.QRP files. These include report files that are saved from a report preview. The Quick Viewer is launched from Windows® Start menu, without the need to launch the software.

### To Define a Quick Report

- 1 From the Report toolbar, select the Quick report request icon.

- 2 From the Event drop-down list, select the event type for the current report (access, controller, door, relay, input, operator, manual operation events, etc.). If you have selected “access events”, the Card tab appears in the window.
- 3 Among the Event type options, select the event type to be included in the report.
  - **Normal**—Quick report can create reports based on normal events. In an access report, normal events would be such events as “access granted” for instance.
  - **Abnormal**—Such events as access denied (bad access level, supervisor level required), workstation server abnormal disconnection, gateway communication failure, or all events related to a process that is not complete (a controller reload failure, for example), are considered abnormal.
  - **Normal & abnormal**—Select this option to include normal and abnormal events in the report.
  - **Custom events**—Select this option to include your own events. The Custom tab appears when the Custom events option is selected. This option allows the operator to select the

components that have generated the selected events according to the setting in the “event” field.



**NOTE:** When you use the *Event* field, you have to specify which component(s) should be used or not used. Once you select an event (i.e. access), the system displays all the doors of the gateway. If you select Controllers, the system displays all the controllers for the gateway. Once you have selected an event (i.e. controller events), select the controllers (i.e. list of controllers) to be included in the report.

- 4 Select the Card tab to specify filter details about the report. The Card tab appears only if a card-related event is selected.

- 5 In the Card index drop-down list, specify the information that will be used as the filter. For example, if you select “card number”, only access events in which the defined card numbers appear will be selected.



**NOTE:** If you select *Card number*, the *Lower* and *Upper boundary* editable fields display the default numerical values to be replaced by card numbers. If you select *Card user name*, these fields are enabled to receive text data. For example, you can enter *A* in the *Lower boundary* field and *F* in the *Upper boundary* fields for the system to include events in which the selected door is defined and events in which the defined card numbers appear but only for card users whose names begin with A to F. If you select *All*, the editable fields are disabled.

- 6 In the Report name tab, enter a name for the report (this name will be displayed on your report).
- 7 In the Start/end date tab, enter the date and time on which the system will start to collect the events. For example, if you enter 7:00 and an event occurred at 6:00, this event will not be included. To target events that occurred during a specific time frame, use the Time period tab.
- 8 In the Time period tab, check the Specific time frame option to include events that match the specified time frame. Enter the target time for the report.

- 9 If you want to overwrite the previous file, select the Miscellaneous tab then check Overwrite existing output file. If you do this, the existing default output file will be replaced by this new one.
- 10 Define the output parameters:
  - **Database output type:** Select the database output format (Paradox, Dbase IV, or.CSV).
  - **Directory**—Indicates where the report is saved and stored. The default folder is: C:\ProgramFiles\Kantech\Workstation\_GE\Report\your file.xx.
  - **Output filename**—Indicates the output file name. By default, reports are saved on disk in C:\ProgramFiles\Kantech\Workstation\_GE\Report\your file.xx. The report filename is composed of the date and time on which the report was created. You can modify the filename if necessary, but do not modify the extension.
  - **Database output process**—Select the appropriate output processes. A report template is associated with each output.
    - Database only (the report will be saved in the system database)
    - Display historical report (the report will appear on-screen)
    - Report printed (sequence, date or events) (the report will be printed according to the specified sort order)
    - E-mail historical report: the report will be sent by e-mail to a specified valid e-mail address.
  - **Send to workstation**—Select the workstation to which the quick report should be sent. The list contains all applications defined in the system. When SmartLink is installed on two or more workstations connected to the network, you can generate reports on one workstation and send the results to another workstation by selecting the SmartLink that corresponds to the workstation where you want to display the report.
- 11 Click the Execute button to launch the report. To view the report, select the View report tab.




# Historical Reports Definition

The Historical report definition feature allows users to define customized historical reports and card use reports with their own automatic execution parameters. Reports that are defined with automatic settings are automatically generated at the specified time. However, they may be requested manually when needed. The “Historical Report Request” menu enables operators to trigger reports by overriding automatic settings. When requested manually, automatic settings are ignored.

## To Define a Default “All Events” Report


You may generate a default report that will include all events. The default report is an Historical report type. EntraPass enables you to send an automatic report by e-mail.

- 1 Select the Historical report icon from the Report toolbar. The Historical report window appears.



## To Define a Custom Historical Report

- 1 From the Report window, select the Historical report icon. The Historical report window appears.



- 2 To create a new report, click the New icon (in the toolbar) and enter the necessary information in the language section. The Report type field shows the selected/created report (Historical or Card use report). To modify an existing report, select it from the Report drop-down list.
- 3 You may check the Select all events option. All the listed events will be checked and included in the report. You may choose to check specific events that you want to include in the report.
- 4 If you are creating a Historical report type report: from the Report type drop-down list, select Historical report. This is the first filter for the report. The selected report will show events such as access granted events (with the time, the door that was accessed, as well as the card number).
- 5 If you selected the Historical report type, you have to select components associated with the event. The Components tab appears in the window when the selected report is an Historical report type.



**NOTE:** When you select Historical report and when a filter mode is selected (Filter mode drop-down list), the system displays additional tabs, the Components and Cards tabs. The Card tab is also displayed when "Access" events are selected.


- 6 Check the Overwrite existing output file option if you want the system to replace the existing output file each time the report is automatically generated according to the settings defined in the "Automatic report schedule".
- 7 *Historical Reports Only.* Select the Filter mode if you want a report from specific components. These filters are used to target specific events that were generated from selected components. You can select various filtering methods. When you use this field, you have to specify which component(s) to use.

- 8 *Historical Reports Only.* If you selected Historical report, check the Specific time frame option. If selected, the time frame specified will be used by the system. Only events (event time) that are within this specific time frame will be included in your report. For example, if you define 8:00 to 8:30, only events which occurred during this time frame will be included in the report.
- 9 Select the Automatic report schedule tab to specify details about the report. For details about defining an automatic report, see *"To Define Automatic Report Schedules" on page 440.*

## Defining Components for an Historical Report

If the selected report is a Historical report type and if you have selected a Filter mode, the Components and Cards tabs appear next to the Event parameters tab. You have to specify the components and filters that may affect the report.

- 1 From the Historical report window, selected the Components tab. The Components window lists all the component types that have a direct link with the selected events.



- 2 Select an event type to display its items in the right-hand pane. If you select Card type, the right-hand pane displays all the card types defined in the system. If you select Doors, all the access system doors are displayed in the right-hand pane.



**NOTE:** If an item in the left-hand pane (Selected components) is selected, its color changes (turns red). When it is deselected, it resumes to the default color.

## Defining Card Options for an Historical Report

- 1 From the Historical report definition window, select the Card tab. It is displayed only when access events are selected. It is used to add more filters to your report in order to target specific events.

**Historical report**

Report: Card Use Report

English  
Card Use Report

French  
Utilisation des cartes

Events parameters | Components | **Cards** | Automatic report schedule

☒ All cards  
☒ Use card type as filter

Card number: None 00:00000 00:00000

Filter index	Filter mode	Lower boundary	Upper boundary
Card user name	None		
Card information 1	None		
Card information 2	None		
Card information 3	None		

Close Cancel Help

- 2 Select the All Cards option to include all cards. When you do this, the other fields are disabled. When you select the Use card type as filter option, you can add filters for your report. You can view the fields that are included/excluded as filters and specify a lower and upper boundaries for each selection.
- 3 Specify the information that will be used as a filter (Filter index drop-down list). For example, if you select “Card number”, as the filter index, only access events in which the defined card numbers appear will be selected.
- 4 From the Filter mode drop-down list (None, Include, Exclude), specify if the system should exclude or include the value range that you specify in the Upper/Lower boundary fields. When a filter mode is selected (Exclude or Include), the “Boundary” fields are enabled.
- 5 Enter the value range in the Upper/Lower boundary fields according to the selection in the Filter mode field. These may be, for example, alphabet letters (if the filter index is by names; or numeric, if the filter index is by card number). You could, for instance, use the card user name and specify A to F in the Upper/Lower boundary as the lower and upper boundaries. As a result the system will include events in which the selected door is defined and events in which the defined card numbers appear but only for card holders whose names begin with A to F.



**NOTE:** Users may select more than one filter for the same report using the filter index. Events will be filtered *n* times depending on how many filter indexes are defined for the report.

## To Define a Card Use Report

The card use report feature is used to create reports that will list cardholders who did/did not generate events since a specific number of days or a specific date. For example, operators could request a report including “access granted” events that were generated since a specific date.




**NOTE:** When you select a card use report option, the Use definition tab appears in the Historical report window. It allows you to define the card use parameters, such as: used since a specific date, not used since 30 days before today, etc.

The system displays five event types:

- Access denied (bad location, bad access level, bad card status, etc.)
- Access granted
- Database (events that have affected the database, such as card definition modified)
- Time and Attendance events (entry, exit).

- 1 From the Historical report window, select a report from the Report drop-down list. If you are creating a new report, click the New icon in the toolbar, then enter the necessary information in the language section.



- 2 You may check the Select all events option (when it is checked the display pane is disabled), or you may select only the events you want to include in the report.
- 3 The Report type drop-down list, displays Card use report if the selected report is a Card use report type. If you are creating a new report, select Card Use report. When the selected report (in the Report drop-down list) is a Card use report type, only events related to card use are displayed in the left-hand pane.
- 4 You may check the Overwrite existing output file option, to replace the existing card use report every time you generate a new one. You may keep the default target folder.
- 5 You may also check the Process separately option if you want the events to be processed individually for each card. For example, if you want a report for “Access denied events” and “Access generated events”, if you do not check the Process separately option, the report will

contain all these events. When the **Process separately** option is checked the report will display Access granted event and Access denied events separately.



**NOTE:** The *Process separately* option appears only when the report type is a *Card use report*.

- 6 Select the **Use definition** tab to specify the card use options (**Not used since** or **Used since**) and target periods.



**NOTE:** The *Use definition* tab appears only when the selected report type is a *Card use report*.

- 7 To define the target period, check the **From** checkbox and enter a date in the **From** field. You may select a date in the calendar when you click the **Calendar** button. Alternatively, you may use the up/down controls or enter the **Number of days back**, starting from today's date.
- 8 When you have finished defining the report, save it. You may request it using the **Report request** button in the **Report** toolbar.

## To Define Automatic Report Schedules

For both Historical and Card use reports

Use the **Automatic report schedule** tab to define automatic settings for your reports so they can be automatically generated when needed. These settings indicate:

- The frequency: when the report should be generated (none, weekly, monthly, once)
- The time period covered
- The output process (display, print, etc.)
- The output type (dBase, Paradox, CSV)
- The destination (workstation)
- The language and the filename

- 1 From the Historical report window, select the Automatic report schedule tab.

- 2 From the Schedule mode drop-down list, select the frequency at which the report should be executed:
  - Select **None** if you want the report to be manually requested (see *Historical Report Request*).
  - Select **Weekly** if you want a report every week. You have to check the day on which the report should be executed automatically.
  - Select **Monthly** if the report is needed once a month. You have to specify the day (ex. the second Friday of the month or the 15th day of the month) when the report will be executed automatically.
  - Select **Once** if you want the report to be executed automatically on a specified date.
- 3 In the Start at this time field, enter the time at which the system will start executing the report.
- 4 Specify the Scheduling parameters.



**NOTE:** These settings are *ignored* when the report is requested manually by an operator.

- **Start this many days back**—The report will start collecting events according to the number of days specified in this field. It is based on the present date.
- **Start at this time**—Once you specify the amount of days, specify the starting time (i.e.: 7:00am). For example, if you enter 7:00, events that occurred at 6:00 will not be included in the report.
- **Stop this many days back**—The report will include the specified number of days entered in this field. It is based on the present date.
- **Stop at this time**—Once you specify the number of days, specify the ending time (i.e.: 5:00 pm), that is, the day on which the system will stop collecting data; you may also specify the time at which it will stop. For example, if you enter 7:00 and an event occurred at 8:00, then

this event will not be included. To target events that occurred during a specific time frame, you have to use the Specific time frame option.



**NOTE:** The start and end time are only used for the first day and last day, for example if you start collecting events on Monday at 8:00 and end on Friday at 17:00 all events between 8:00 Monday and 17:00 Friday will be included. The system **does not** use the start and end time for each day but for the whole period.

## Specifying Additional Options for an Automatic Report

- 1 Select the More button to add more settings to the automatic scheduled report. When you click the More button, the Automatic report output definition window appears.

The screenshot shows a window titled "Automatic report output definition" with a "Details" tab. It contains several fields: "Database output type" (set to CSV), "Database output process" (set to Database only), a checked checkbox for "Automatic filename (yyyy\_mm\_dd-hh\_mm\_ss)", "Filename" (2005\_01\_25-14\_48\_55.csv), "Report language" (English), and "Report destination" ((1) Monitoring Application). On the right side, there are buttons for "OK", "Cancel", and "Help".

- 2 From the **Output type** drop-down list, select the output format of the report. You may choose Paradox, Dbase IV, or CSV formats.



**NOTE:** From the *Database output process*, you can select *E-mail historical report* if you want this report to be automatically sent to specified recipients. If you choose this option, select the *E-mail* tab to enter the recipients' e-mail address in the *Send E-mail to* field. EntraPass enables you to protect the report by a password before e-mailing it.

- 3 You may check the Automatic filename (...) option. The default file name is YYYY\_MM\_DD-HH\_MM\_SS.X, indicating the year\_month\_day-hours, minutes\_second.file extension.



**NOTE:** For details on the output type and the output process, refer to the table below. It gives a comparison of the different report formats.

The following table shows the difference between these database formats and their output file formats:

Database	Description	.db	.rdf	.csv
Paradox	In addition to the traditional.db,.rdf output formats, the Paradox database generates the.px,.xg0,.xg1,.yg0,.yg1 files. These contain the indexes and are useful when using a "Paradox" database. They can also be used by the database administrator.	X	X	X



Database	Description	.db	.rdf	.csv
Dbase IV	A popular database management system format for storing data that is supported by nearly all database management and spreadsheet systems. Even systems that do not use the DBase format internally are able to import and export data in Dbase format.	X	X	-
CSV	Will save the report in a comma separated values format (yourfile.csv). A data format in which each piece of data is separated by a comma. This is a popular format for transferring data from one application to another; because most database systems are able to import and export comma-delimited data.	-		X

- 4 Refer to the following table for information on the editing tools compatible with the output files. Only.db file formats can be edited.

Output file	Paradox	Dbase IV	CSV
.db, Editing tool	dBase IV, dBFast, MultiEdit, DbVista, Paradox, SmartWare and XtreeGold.	dBase III, IV, FoxPro, dBFast, DataBoss and Excel.	-
.csv, Editing tool	-	-	Excel, NotePad, WordPad, etc.
.rdf, Viewing tool	Entrapass tool (Borland Database Engine)	Entrapass tool (Borland Database Engine)	NotePad

- 5 From the **Output** process drop-down list, select the report template. It will be used with the requested report. For details on the output format, see *"To Define a Report Output Format"* on page 443.

## To Define a Report Output Format

### Historical and Card use reports. 1

- 1 If you select **Database only (CSV, Paradox and Dbase)**: The report will include the following information: event sequence, date and time, event message, description types (displays a specific number that identifies a component in the system), description names (displays the name of the component as defined in the system—name of description type number) as well as the card number (for card-related events).



**NOTE:** A database only report is saved in the reports folder in the specified format. It will not be printed nor displayed.

- 2 If you select **Display Historical report - Display card last transaction report (Paradox Only)**: The report will automatically be displayed on your desktop when completed. You can customize the report before you print it manually. For more information on how to customize the report, see *"To Preview Historical Reports"* on page 459. The report will include the following information:

event sequence, date and time, event message, card number (for card-related events) and descriptions 1 to 4 which contain details on the event.

- 3 Report printed by sequence (*Paradox Only*): This report is sorted by event sequence number (order in which they were generated by the system) and printed automatically at the printer of the destination workstation.
- 4 Report printed by date and time (*Paradox Only*): This report is sorted by date and time and printed automatically at the printer of the destination workstation.



**NOTE:** The printed reports (option three and four) will be saved in the reports folder in the specified format. They will also be printed but not displayed.

- 5 Report printed by event (*Paradox Only*): This report is sorted by event message (alphabetically) and printed automatically at the printer of the destination workstation. The report is saved in the reports folder in the specified format, but not displayed.

### Time and Attendance Reports

Time and attendance reports will be saved in the reports folder, they are not printed nor displayed. User have to manually retrieve the report to view it, they can also use the “View Report” menu.

- 1 Single file with all data (*CSV only*): The report is generated in one file containing the data and the descriptions (date & time, transaction ID, card number, card user name and door description).
- 2 Database with transactions (*CSV, Paradox & DBase IV*): The report is generated with all the data and transactions in one single file. It includes the date & time, the transaction ID, the card number and the card user name.
- 3 Display time and attendance report (*Paradox only*): The report will automatically be displayed on the desktop when completed. You can customize the report before you print it manually. It contains: the card number, card user name, entry time, exit time, contents of the card information field as selected in report definition and total hours per cardholder. For more information on how to customize the report, see “To Preview Time and Attendance Reports” on page 460.
- 4 Two (2) databases with all data (*Paradox & DbaseIV*): the report will be generated in two separate files:
  - One file containing: date, time, event message (transaction type), pkcard, pkdoor, pkdoorgroup.
  - One file containing: pk description (explaining pkcard, pkdoor and pkdoorgroup), card number, object and contents of card information field selected in the report definition menu.



**NOTE:** Pk refers to a component unique number within the system

- 5 Single database with all data (*Paradox & DbaseIV*): The report will be generated in one file containing the data and the descriptions (date and time, transaction ID, card number, card user name, door description and sequence).
- 6 CSV compilation time and attendance (*CSV Only*): The report will be generated in two files. One file containing a total, of hours for instance, by department, and the other file containing detailed information. Depending on the number of days covered by the report, a “day” column will be reserved for each day.

- **Automatic filename**—Select this feature if you want the system to automatically use the date and time as the filename. You cannot use the “overwrite existing output file” when you use this option.
- **Filename**—If you wish to overwrite the same report (for example—every week), you can enter a filename here and when the report will be executed according to specifications, the new report will replace the oldest report.
- **Destination**: this is where the report should be sent/printed automatically. You can also use the **Overwrite existing output** option to specify a different destination file.
- **Report language**—This field is used to include additional information in your report. Select from the displayed list.

## To Request Historical Reports

With this feature operators can request pre-defined Historical reports or Card use reports that were created using the Historical Report menu. Operators can also e-mail the report to one or multiple recipients.



**NOTE:** If your report contain automatic settings, these will be ignored. You must indicate new settings.


- 1 From the Report toolbar, select the Report Request icon. The Report request window appears.

- 2 In the Report list display pane, select the report that you want to execute.
- 3 You may define output parameters, including the database output type, the target folder, the output filename, etc. For more information on how to select an output format, see *"To Define a Report Output Format"* on page 443.



**NOTE:** If a Card use report is selected, the “Date and time” section is disabled.


- 4 Click **Execute**. A system message informs you that the report is being processed. The Report options window appears and is then minimized to the task bar.



- 5 Select the **Preview** button to define the report and filter options. This will increase the readability of the report by adding, for instance, alternating band colors, framing events, icons in the reports, etc., or by sorting events in the report (by event ID number, alphabetical order or date and time). (TO check)
- 6 Enter the **description** in the Search description field. The report is updated in real-time when you enter a filter option.
- 7 You may use **Preview** to preview the report or the **Properties** button to view details about the report. When you click the **Preview** button, the system will display the result of the report. From that window, you can save the report (in a.QRP format) or print the report.

## To Request an Event Report

- 1 Select the Report request icon from the Report toolbar. The Historical report request window appears.



- 2 Specify the Start and End time. By default, the end date and time are set to the system time.
- 3 You may specify the output parameters or leave these to default.



**NOTE:** It is important to know the differences among the output type and processes. For details, see "To Define a Report Output Format" on page 443.


- 4 You may select the Report state icon from the toolbar to view the report status.
- 5 Select the View report icon from the toolbar to view the report. The default report name is YYYY\_MM\_DD\_-HH\_MM\_SS.db.

## E-mailed Reports

EntraPass allows you to e-mail any report to one or more recipients. The e-mail feature is enabled when defining an EntraPass workstation and when specifying the report database output format. Historical, time and attendance and quick reports can be sent by e-mail to any valid e-mail address.


### To Define a Report to Send by e-Mail

- 1 From the Report toolbar, define a new report or select an existing one, then select the appropriate Report Request button.




- To send a historical report, click the Historical Report button.
- To send a time and attendance report, select Time Request Report.

- To send a quick report, select Quick Report Request.



- 2 From the Report request window, select E-mail report as the Database output process option. When you select this option the Define E-mail parameters button is enabled. Click the Define E-mail parameters button. The Automatic report output definition window appears.



- 3 In the Send E-mail to enter the recipient's e-mail address. For multiple recipients, addresses are separated by a semi-colon.



**NOTE:** Sending reports does not compromise the security of your data. In fact, EntraPass allows you to protect rpf files with a password. Only recipients with the correct password will be able to access the file. You cannot set a password to CSV files.

- 4 Click the Execute button to send the report to the specified recipient. The report will be sent to the workstation selected in the Send to workstation drop-down list and to the specified recipients.

## Time and Attendance Reports Definition


This feature is used to define customized time and attendance reports with automatic execution parameters.



**NOTE:** Reports can be defined with *automatic settings* so they are generated when you need them or can be requested *manually* using the “Time and attendance report request” icon. When requested manually, automatic settings are *ignored*.

### To Define Time and Attendance Reports


- 1 From the Report toolbar, select the Time and Attendance icon.



- 2 If you select the Doors option, only the doors defined as “Time and attendance” doors (in the Door definition menu) are displayed. Check the View deleted doors to add deleted doors to the list. When you select the Door group option, the View deleted doors option is disabled. The system displays the door groups of your system; then you may select one.
- 3 Check the Overwrite existing output file option if you want the system to replace the existing file. If you leave this option unchecked, the system will create another output file.



- 4 Select the Card tab to add other filters for the report.



**NOTE:** The Card type tab appears if the *Use card type filter* box is checked.

- 5 Select a filter index, then select a filter mode (None, Include, Exclude). If you have selected a filter index, select the filter mode and enter the value range in the Upper/Lower boundary fields. To include all the fields, leave the filter mode to None. For example, if you select Card number as the Filter index, leave the filter mode to None so that all events triggered by cards will appear in the report.
- 6 To add information in the sort criteria, select an item from the Additional information drop-down list.



**NOTE:** Repeat these steps for all the card information fields that are listed in the filter index field. You could use the card user name and specify A to F in the *Upper/Lower boundary* fields for the system to include events in which the defined card numbers appear but only for card users whose names begin with A to F (G and up will not be included even if the card number is included in the range).

- 7 Select the Card type tab if it is displayed, then specify the Card types that will be included in the report. This tab appears if you have checked the Use card type filter option.
- 8 Select the Automatic report schedule tab to specify information for automatic reports. For details, see "To Define Automatic Report Schedules" on page 440.
- 9 Select the Rules tab in the Time Report window to define the rules of time and attendance in employee time reports. Rules can be created to define periods of time as specific values. For

example, all employee entries between 7:50 AM and 8:15 AM can be defined as the value of 8:00 AM on reports.

Time report

Report

English

French

Doors and cards

Automatic report schedule

Rules

	Rule type	Lower time	Upper time	Adjust time
1		00:00	00:00	00:00
2	None	00:00	00:00	00:00
3	None	00:00	00:00	00:00
4	None	00:00	00:00	00:00
5	None	00:00	00:00	00:00

Close

Cancel

Help

## Time and Attendance (T & A) Reports Request


The Request Time and attendance reports feature is used to request the pre-defined Time and attendance reports that were created using the Time and Attendance Report Definition menu. This feature is useful when you want to override automatic settings.



**NOTE:** If the report contains automatic settings, these will be ignored.

### To Request a T and A Report Manually

- 1 From the Report toolbar, select the T and A Request icon. The T and A Request report window appears.



- 2 From the Report list display pane, select the Time and Attendance report that you want to execute.
- 3 Specify Date and time as well as the Output parameters.
- 4 Click Execute to trigger the report.



**NOTE:** The Time and Attendance report is automatically saved in the output folder of the Application selected in the Send to workstation field. For the Paradox output type, the system displays a report preview window. For other output formats, you will have to retrieve the report manually since it is not printed or displayed. To view all the reports that have been generated, use the View report button in the Report toolbar. For details on reports output formats, see "To Define a Report Output Format" on page 443.

## Operations On Time and Attendance

Use the Operation on Time and Attendance feature to manually insert, add or delete Time and Attendance transactions in the database. This feature is useful for an organization using the Time and Attendance feature for the payroll system, for instance.

### To Add Transaction in the Time and Attendance Database

- 1 From the Report main window, select the Operation on T and A icon.

Delete	Date	Time	Transaction	Doors
<input type="checkbox"/>	2001/09/13	12:56	Manual entry	[ 01.01) 01 - KT200Corporate
<input type="checkbox"/>	2001/09/13	12:56	Manual entry	[ 01.01) 01 - KT200Corporate

- 2 Enter the Card number for which you want to modify the Time and Attendance transactions, then click the Load button. If you do not know the number, use the Find button.



**NOTE:** The card number field is mandatory to start loading.

- 3 Select the View deleted transactions option if you want to view the transactions that were previously deleted. Deleted transactions are marked with an "X" in the Delete column.
- 4 Check the Find deleted cards option if you want to find the deleted cards. This does not apply to entries that were added manually.
- 5 Specify the Start date, the day on which the system will start to collect the events, by clicking the Calendar icon and selecting a specific date. Only events that occurred on this date and after are displayed.



**NOTE:** The Start date is mandatory to start loading.

- 6 Specify the End date, that is the day and time on which the system will stop collecting events. Only events that occurred on the specified date and before are displayed. If you do not specify an end date, the system will include all the data up to the present day time.
- 7 In the Site drop-down list, select the appropriate site to view the Time and Attendance doors.



**NOTE:** The gateway is mandatory to start loading.

- 8 You may check the All Doors option, then all the doors displayed under this field will be selected. You may also select specific doors. All the Time and Attendance events that were generated for the selected doors will be displayed.
- 9 Check the View deleted doors option so that even doors that are no longer defined as time and attendance doors (but that have been defined as time and attendance) will be displayed.



*NOTE: Doors are mandatory to start loading.*

- 10 Enter the necessary information in the transaction table. The transaction table displays the transactions for the selected cardholder:
  - The Delete column indicates transactions that have been deleted (if the View deleted transactions option is checked). These are identified by an X.
  - The Date column indicates the date on which the transaction occurred. Use this field to specify the date when you manually insert a new transaction.
  - The Time column indicates the time at which the cardholder entered or exited an area. Use this field to specify the time (entry or exit) when manually inserting a new transaction.
  - The Transaction column indicates the transaction type. For every entry transaction, there should be an exit transaction.
    - Entry—indicates that this is an entry transaction generated when a cardholder presented his/her card at a door defined as entry.
    - Exit—Indicates that this is an exit transaction generated when a cardholder presented his/her card at a door defined as “Exit”.
    - Manual entry—Indicates that this is an entry transaction that was manually inserted or added in the system. When you manually insert a transaction, you have to specify if this transaction is an “Entry” transaction or an exit transaction. For every entry, there should be an exit.
    - Manual exit—Indicates that this is an “exit” transaction that was manually inserted or added in the system. When you manually insert a transaction, you have to specify if this transaction is an entry transaction or an exit transaction. For every entry, there should be an exit.
  - The Door column indicates which door was accessed by this user. When you manually insert a transaction, you have to specify the door according to the transaction type (Entry or Exit).



*NOTE: If you are inserting an entry transaction, only doors defined as “Entry doors” will be displayed in the list. If you are inserting an exit transaction, only doors defined as “Exit doors” will be displayed in the list.*

- 11 Click the Load button to load the transactions from the server for this cardholder. You have to enter the card number, select the gateway/site, door(s), then click the Load button. The button is disabled once you have loaded the transactions.
- 12 Click the Add button to add a transaction to the existing transaction list. The new transaction will be added at the end of the list.
- 13 Use the Insert button to insert a transaction between existing transactions or above any transaction.


- 14 Click Cancel to cancel any insertion or modification that was made BEFORE saving.



*NOTE: When you delete a transaction that was added manually, it is permanently deleted from the list; as opposed to transactions that were generated by controllers. When they are deleted, they are identified by an X in the Deleted column.*

# Report State

Use the Report state feature to display a list as well as the status of all requested reports that are still pending.



- 1 To delete/stop a pending report, select it, then click Abort.

## Reports Viewing


The View Report feature enables users to view the reports that were defined and saved in the system. Operators can use it to view reports in any format, or to customize a report before printing it.



**NOTE:** When you create a report (csv, db or dbf), the system automatically creates an associated rdf file. This rdf file is the one that is listed in the View report window. When you click “Preview”, the system automatically launches the appropriate program to view the report.

### To Display a Report

- 1 From the Report window, select the View report icon. The system displays the default destination folder. If the report was saved in a different folder, browse the disk, using the scroll-down arrow (bottom of the window) to the report you want to display.



- 2 Select the report you want to view. If there is a printer installed, the Preview button is enabled. It is used to preview the report before printing it.



**NOTE:** You *must* have a printer installed on your computer in order to preview or print reports. To setup a printer, click on *Start > Settings > Printers > Add Printer*. For more information, consult your system administrator.

- 3 Click the Details button to display information about the report. If you click the Details button, the Report details window appears, displaying information related to the selected report file such as the report filename, title, type, date, etc. To close the Report details window, click the Details button again.
- 4 Click the Preview button to view the report in the system displays the Report preview window.



## To Preview Historical Reports

- 1 From the View report window, select the report you want to view in the right-hand pane. If you select an Historical report, the following window appears. It allows you to customize the report before printing it

The screenshot shows a window titled "Report options" with a table of historical events and a section for filter options.

Sequence	Date and time	Event message	Card number	Description 1	Description 2	Description 3
1	2003-07-14 9:08:32 AM	Server communication failed				
2	2003-07-14 9:08:32 AM	Start server		Server		
3	2003-07-14 9:08:36 AM	Login on server		Server	kantech	
4	2003-07-14 9:09:01 AM	Start workstation server connection		Additional Corporate		
5	2003-07-14 9:09:01 AM	Start workstation		Additional Corporate		
6	2003-07-14 9:09:01 AM	Loop communication failure		Security Office		
7	2003-07-14 9:09:02 AM	Loop communication restore		Security Office		
8	2003-07-14 9:09:02 AM	Start workstation server connection		(1) Additional Works		
9	2003-07-14 9:09:05 AM	Failsafe mode off		KT200 - Security Offi		
10	2003-07-14 9:09:06 AM	Failsafe mode off		KT100 - Security Offi		
11	2003-07-14 9:09:06 AM	Failsafe mode off		KT300 - Security Offi		
12	2003-07-14 9:09:02 AM	Start workstation		(1) Additional Works		
13	2003-07-14 9:09:19 AM	Login on workstation		(1) Additional Works	kantech	

Below the table, there are sections for "Options" and "Filter options".

**Options:**

- ☒ Alternate band's color
- ☒ Framed events
- ☐ Icons in report
- ☐ Expand spaces between events: 0
- Sort: Sequence

**Filter options:**

Search description: \_\_\_\_\_

- ☒ Contains
- ☐ Starts with
- ☐ Ends with
- ☐ Exact words

Buttons: Preview, Print, Properties, Close

- 2 Select the display options. If one of the following options is selected:
- 3 Define the filter options: enter a text string in the Search description field. The report will be sorted leaving only events containing the specified text string. You may refine your filter:
  - **Contains**—All events which contain the specified text will be included in the report.
  - **Starts with**—All events which start with the specified text will be included in the report.
  - **Ends with**—All events which end with the specified text will be included in the report.
  - **Exact words**—All events containing the exact specified text will be included in the report.
- 4 Click **Preview**. The system displays the result of the report. From that window, you can save the report (in a.QRP format) or print the report.
- 5 Use **Properties** to view the settings and details of a pre-defined report. The selected report displays the following information:
  - **Report filename**—Displays the whole path where the report was saved as well as its name.
  - **Report title**—Displays the title of the report.
  - **Start date**—Reports are created for a selected time frame. This option specifies the starting date of this time frame.

- **End date**—Reports are created for a selected time frame. This option specifies the ending date of this time frame as well as the time.
- **Requested**—Displays the date and time at which the report was last requested.
- **Delivered**—Displays the date and time at which the report was produced and printed.
- **Requested by**—Displays the operator name that requested the report.
- **Count**—Displays the number of transactions (lines) in the report.
- **Output process**—Displays a list of the possible templates used for this report.

## To Preview Time and Attendance Reports

- 1 From the **View report** window, select the report you want to view. If the selected report was defined as a “Display Time and Attendance Report” and “Paradox Database” as the output format, the following window appears.

- 2 Select the display options:
  - **Group by**— Select this option for easier management. The report data may be grouped by card user names or by card numbers.
  - **Sort by**—You may choose a sort order, by user names, or by card numbers.
  - **Report type**—Select this option for easier management. You may choose to include details with or without total.
- 3 Click **Preview** to display the result of the report. From that window, you can save the report (in.QRP format) or print the report.

---

## Chapter 14 • EntraPass Options

The Options toolbar offers users the ability to change a number of system parameters. These include changing the card format, the authentication password, the date and time, or changing server parameters. Some of the system utilities may be accessed from the Server or the Workstation windows. The following menu options are available from both the Workstation and the Server windows:

- Change card format
- Change the authentication password
- Select a language
- Keypad family
- Change the system date and time
- Modify the system parameters
- Backup Scheduler
- System registration (this icon disappears from the Workstation menu once the system has been registered)

The following utilities are available from the Option menu only in the EntraPass Workstation application:


- Printer option (select a log printer and a badge printer)
- Multimedia devices (alarm, video and signature capture settings)
- Verify database integrity
- Custom Messages

## Card Format Modification

The system can accommodate various reader types. Depending on the reader type, the card display format may vary. Use this menu to specify how the system will display the card numbers

### To Define a Display Format

- 1 From the Options main window, select the Card format icon.



- 2 Select a display format—When you select a format, the system displays a preview of the selected format in the bottom part of the window.
  - **Decimal**—Refers to numbers in base 10.
  - **Octal**—Each octal digit represents exactly three binary digits. An octal format refers to the base-8 number system, which uses eight unique symbols (0, 1, 2, 3, 4, 5, 6, and 7). Programs often display data in octal format because this format is relatively easy for humans to read and can easily be translated into a binary format, the format used in computer programming.
  - **Hexadecimal**—Each hexadecimal digit represents four binary digits. An hexadecimal format refers to the base-16 number system, which consists of 16 unique symbols: the numbers 0 to 9 and the letters A to F. For example, the decimal number 15 is represented as F in the hexadecimal numbering system. The hexadecimal system is useful because it can represent every byte (8 bits) as two consecutive hexadecimal digits. It is easier for humans to read hexadecimal numbers than binary numbers.

- 3 Indicate How many digits are to be displayed. You may use the up/down controls. When a 64-bit decimal format is chosen, it is possible to specify the number of digits the system must use.



**NOTE:** Avoid alternating between different card formats because this may result in lost card information.

**NOTE:** KT100 and KT300 Controllers will do a hard reset on format change.

## Authentication Password Modification

The authentication password is used to authenticate EntraPass Workstations to the EntraPass Server.

The authentication password window is automatically displayed when the system has not yet been registered.



**NOTE:** If you are not using a specific password for authentication, then the user will have to use the master default password for workstation authentication. The default authentication password is *kantech*, in lower case. Passwords are case sensitive.

### To Change the Authentication Password

- 1 From the Options main window, select the Authentication password icon.

- 2 Enter the current authentication password (case sensitive) in the Old authentication password field. The default authentication password is *kantech*, in lower case.
- 3 Enter the new authentication password in New authentication password field (case sensitive).
- 4 Enter the new authentication password in the Verify authentication password for confirmation. This field will verify that the new authentication password was typed properly (case sensitive).
- 5 Click OK to exist. When you receive an error message, make sure that the data you have just entered in the New authentication password and in the Verify authentication password fields are identical (case sensitive).




**NOTE:** The authentication password is different from the operator password. The authentication password is used to authenticate workstations, whereas the operator password is used to open a session.

## System Language Selection

Entrapass allows you to run the software in the language of your choice. The basic languages are English, French, Spanish and German. The Vocabulary Editor utility enable users to add other custom languages.

### To Change the System Language

- 1 From the Entrapass main window, select the Options tab, then select the Select language icon.




**NOTE:** Important note: When you modify the primary language, the database operation will be suspended during the operation and the changes will be effective only when you shutdown and then restart the system. The database language will be modified according the ascii values of the characters in the primary language. Accents and special characters of different languages may have an impact on your database.

- 2 From the Select primary language drop-down list, select the language you want to use as a primary language. From the Select Secondary language drop-down list, select the language you want to use as a secondary language.
- 3 Restart your computer, and login to Entrapass.

## Keypad Family

The PIN numbers are generated by the system using an algorithm. For additional security, a keypad family number can be used to modify the keypad numbers.



**NOTE:** *Modifying the keypad family will change the keypad code (PIN) on all existing cards.*

**Keypad Family**—Enter the number on which the system's keypad code generation algorithm is based on.



## Printers Selection and Configuration

The Printer option menu allows users to select a log printer that will be used when printing events and to select a badge printer that will be used to print badges.


### To Select and Set Up a Log Printer

When you define events (in the Events parameters definition menu), it is possible to determine how and when events will be printed. For example, you can decide to dispatch events to an EntraPass application, a printer, or to activate a relay. Your decision may be based on, for instance, schedules that will send alarms to a remote terminal at a specific moment.



**NOTE:** You need to assign a “print” schedule to certain events to print them at a specified time.

- 1 From the Options menu, select the Printer option icon.




- 2 Select a printing option in the Log printer section:
  - **No log printer**—If you select this option, no event will be printed, even if a print schedule is defined for the events.
  - **Use Network/Local Windows® printer (page printer)**—If you select this option, all events sent to the printer will be buffered and printed when a full page is ready to be printed. Events will be printed on the network/local printer - not on a specific log printer.
  - **Use local dot matrix printer**—If you select this option, all events sent to the printer will be printed one-by-one and one under the other, or it will print one event per page, depending on your printer type. Select the printer port that will be used in the “printer” field. Specify if messages and alarms will be printed on this printer.
- 3 In the Printer selection section, specify whether you want to print message or alarms.
  - **Print messages log**—If you select this option, all events that are assigned a “display” schedule in the events parameters menu will be printed.

- Print alarms logs—If you select this option, all events that are assigned an “alarm” schedule (and need to be acknowledged) in the events parameters menu will be printed.
- 4 From the Printer drop-down list, select the specific printer that will be used as a log printer.
  - If you have selected a dot matrix printer, select the Port on which the printer is connected to communicate with the computer. The Port field appears when a dot matrix printer is selected.
  - If you are using a network/local printer, select the Font and the Font size. The font and font size influence the number of events that will be printed on one page. Using a smaller font increases the number of events printed on a page.

## To Select and Set Up a Badge Printer

- 1 From the Printer option window, select the Badge printer tab.




- 2 Check the Badge printer option if a badge printer will be used; as a result, the Print badge and Preview badge button will be displayed in the Card, Visitor, and Day pass windows.
- 3 From the Select badge printer drop-down list, select the appropriate badge printer.
- 4 If you want the picture on the reverse side of the badge to be inverted, click the Invert Reverse Side box.

## System Date & Time Modification

The Change system y option should be used with caution and only when necessary; this functions may affect logical components of the access system (i.e. schedules, etc.).

If, for any reason, you want to adjust the system time and date, it is better to do so using the Server parameters settings (Options > Server Parameters > Time adjustment).For details on network time adjustment, see "Entrapass Options" on page 461.

- 1 From the Option main window, select the Change System date and time icon.



- 2 Enter the date in the Date field, or select a date from the calender. Connected components of this application will also receive the date change notification.
- 3 Enter the time in the Time field. Connected components of this application will also receive the time change notification.
- 4 Click OK to exit.



**NOTE:** If you want the system to automatically change the time when necessary, use the Time adjustment tab of the Server Parameters definition menu. For details, see "Entrapass Options" on page 461.

**IMPORTANT NOTE:** You should not change the time using Windows® settings. It is strongly recommended to change the system time through the server parameter settings.


## Multimedia Devices Configuration

The Multimedia devices utility allows you to set up your system multimedia objects:

- Alarm sound
- Video capture devices
- Signature capture devices
- Video feature devices

### To Select an Alarm Sound

- 1 From the Options main window, select the **Multimedia devices** icon.



- 2 Check the **Enable alarm sound** option if you want an alarm sound notification.
- 3 Select a sound from the displayed list.
- 4 Select a **Priority** level for the selected sound so that it is played when an alarm defined with this priority is sounded.



**NOTE:** The **Priority** level refers to the order in which alarm messages are displayed in the Alarm desktop. In Entrapass, 0 is associated with the highest priority, and 9 to the lowest. For more information, see "Event Parameters Definition" on page 372.


- 5 Click the **Play** button to listen to the selected sound. The system will play the selected sound.
- 6 Click the **Add** button to add a new sound from your personal files. Clicking on this button displays a new window allowing you to add new alarm sounds.



**NOTE:** The **Current selection** section displays the sound currently selected (in use). You can adjust the delay of the alarm sound in the **Delay** field.

## To Define Video Options


- 1 From the Multimedia devices window, select the Video capture tab.



- 2 Check the Enable video capture box to enable the video capture options in your system.
  - MCI device: Standard Windows® capture drivers.
  - Twain device: Twain capture drivers. (Recommended).
  - Use overlay: Option activated for image capture devices.
  - Enable controls menu: Activates options (such as zoom, pan and tilt) on image capture devices, if applicable.
  - MCI device number: Select identification number of MCI device.
  - Portrait: Enables portrait orientation of captured images.
  - Landscape: Enables landscape orientation of captured images. (Default value).
- 3 Click the Test button to verify if the video camera is functional.

## To Set Up the Signature Capture Device

- 1 From the Multimedia devices window, select the Signature tab.




- 2 Check the Enable Signature pad option to enable the use of a signature pad device.
- 3 From the displayed list of supported Signature pad devices, select the driver for the signature pad you want to use.



**NOTE:** The *Test* button allows you to check if the driver selected is functional. When you click the *Test* button, the *Signature Pad Test* window appears. This window appears whenever you choose the *Signature pad* option (Card, Visitor and Daypass definition windows).

- 4 Select the Video tab to set video options for use with the Video Integration feature. This option allows you to choose between the windows or video format for Video playback.



- **Disable DirectX option:** DirectX is a Windows® technology that enables higher performance in graphics and multimedia, including video and sound. By default, DirectX is enabled with the Video feature. However, you may want to disable it; if for example Video images are not correctly displayed or are not displayed at all, disabling DirectX can be useful. However, when DirectX is disabled, the system will use more system resources.


## System Parameters Configuration

The System parameters dialog allows the System Administrator to modify server parameters. This dialog may be accessed from a workstation or a server. Parameters have been grouped together under different labels such as Server Gateway, Firmware, etc. If the Video Integration feature is enabled in your system, the corresponding parameters will appear under the Report label.

### Server Parameters

Under the Server tab, you will define server logs capacity, diagnostic capabilities, security parameters, disk space threshold, network alarms and icon status.

### Server Logs




You can define the maximum number of records to store in the system logs and the system error logs. Records include transactions such as: login to server, logout from server, disconnection, connection, stop or start server, registration requested, etc. These records are kept with the date/time, the workstation (where the event or error came from), the operator and the description of the transactions.



## Redundant Server




*NOTE: This option will not be available if you don't have a redundant server.*



You can define the automatic restart delay for the Mirror Database and Redundant Server.

## Logout and Idle

You will access this tab to specify the EntraPass applications behavior when idle (when there is no action on the keyboard from the operator).



- **Automatic logout on idle:** the operator will have to re-enter his/her user name and password to enable the server application again. The maximum allowed delay is (mm:ss): 59 minutes and 59 seconds.

- **Send to tray on idle:** the server application will be minimized and sent to the task bar when the specified delay expires, if the operator who is currently logged in is inactive. The maximum allowed delay is (mm:ss): 59 minutes and 59 seconds.
- **Must login to close a Server application:** if checked, this option obliges operators to authenticate themselves by entering user name and password to close the Server application.
- **Notify last log out:** if checked, EntraPass will notify the last operator who is logging out.
- **Display description in title bar:** the workstation name will be displayed on top of the window.
- **Display description in taskbar:** the workstation name will be displayed in the lower part of the window.
- **Display Login List:** if checked, the five most recent operators to log into any EntraPass application will be displayed in the login dialog. This feature allows for easier system access for the operators who will simply select their user name and enter their password. It can also be used for administrative follow up where a System Administrator can view the list of operators who have recently logged on a specific application.




**NOTE:** Despite the advantages, it is recommended to disable the Display Login List whenever system security is at stake.

## Schedule


The Schedule tab is where you will be able to upgrade to advanced schedule capability. In fact, EntraPass offers users more flexibility and ease of use by grouping schedules per gateway, site or system logical components. This option is not automatically enabled upon installation of this new version. Schedules are grouped as follows:

- **System schedules:** System schedules are applicable to system logical components such as: event parameters, operators login schedules, video triggers, etc. System schedules are not loaded in a particular controller; they are applicable to all the system. You can program an unlimited number of system schedules.
- **Global schedules:** Global schedules are grouped by gateway. These are defined per Global Gateway. You can define 100 schedules per Global Gateway for such devices as event relays, secondary access levels, alarm systems, areas, guard tours, elevator controls. You can program 100 schedules per gateway.

- Corporate site schedules: These are defined per site. You can define 100 schedules per corporate site for such purposes as: power supervision (controllers), door unlocking, REX trigger (doors), activation mode (relay), input monitoring, etc.




- After checking the box and clicking OK, a warning will popup on screen indicating that the action is irreversible before it performs a backup of your data.



## Disk Space

The Disk Space feature has been developed as a protection against system failures that may be caused by the lack of disk space. This feature allows you to monitor the amount of free disk space


for optimal system operation or for generating reports. In fact, EntraPass offers the ability to have the system abort the execution of a report if the free disk space has reached a specified threshold.



- **Disk free space threshold (MB)** scroll-down list: specify a disk space threshold that indicates when you want the system to send a warning when the amount of free space falls below the value indicated. This value is in mega bytes.
- **Time between notifications (hh:mm)** field: enter the amount of time between notifications when the disk free space has reached the quota specified in the **Disk space threshold** field. For example, if you enter 00:30 in the field, a system warning will be displayed every half an hour.

## Diagnostic

The diagnostic feature allows the system to make network diagnostic.




- **Allow diagnostic on network** uses the PING (Packet INternet Groper) utility program. This stand-alone program diagnoses network intermittent related problems and/or determines whether a specific IP address is accessible. For details on the PING program, see *"System Utilities"* on page 511.

- Show system database will display system components unique numbers. For example, if you are in the Door dialog, you can view the door number by placing your mouse cursor over the Door scroll list. A hint will pop up to display the component's (door) unique number.

Network Alarm

The network alarm feature is where you will define the maximum number of records that will be kept in the network alarm table.




- Use the up/down scroll to enter the number of records allowed (maximum is 100,000).
- When you define this setting, the server will automatically apply the same setting for all workstations of the system. This is to ensure that the file size does not take too much disk space on the workstation and the server's hard disk.



***NOTE:** When the table reaches the maximum records, events are removed from the table on a first in first out basis. For approximately 100,000 (max) events, the file is about 100 MB. For more information on network alarms, see "Entrapass Desktops" on page 391.*

## Icon Status

The Status time out delay (mm:ss) parameter allows you to define a period of time before the server queries workstations for the latest icon statuses. The higher the delay, the lower the icon refresh rate will be therefore creating less traffic on the network.




## Gateway Parameters

The Gateway section is only available in EntraPass Global Edition to setup parameters for your NCC Global and KT-NCC gateways.

## NCC Global Features

These parameters will be defined for a Global gateway.




- **Report input in alarm when the alarm system is armed:** check this box if you want the system to generate the "input in alarm" messages only if the alarm system is armed. If there is a

monitoring schedule on an input, and if this box is not checked, the system will generate the input in alarm event even if the alarm system is not armed.

- **Enable card already busy feature:** If this feature is checked, a cardholder will not be able to open another door before the door open delay is expired on the first door. Check this feature to prevent cardholders from opening a door for example for someone else and then attempting to open another door during the first door open delay.
- **Multiple messages on prevent arming:** an input or group of inputs can be used to prevent arming (Definition > Alarm System > Input). If arming is attempted while a group of inputs is in alarm, the system will not arm and will generate an “aborted arming event”. If this option is not checked, only one message will be generated even if arming was prevented by more than one component.

## KT-NCC

The KT-NCC feature is where you will define your network environment: LAN or WAN and determine if you will use a static or DHCP IP address.




- In a LAN environment where you will be using the EntraPass Global Edition DHCP server, check the box labeled **Enable DHCP server for KT-NCC**.
- In a WAN environment where you will need to access the network through a router, check the **Inbound Server Router** box and enter the router IP Address and/or Domain Name.

## Firmware Parameters

This section contains all the information pertaining to your controllers, as well as the section to update your firmware.


## KT-300

The KT-300 tab specifies the location of the folder containing the firmware for KT-300 controllers. The system will use this data to update the installed controllers.



## KT-100


The KT-100 tab specifies the location of the folder containing the firmware for KT-100 controllers. The system will use this data to update the installed controllers.






### KT-NCC

The KT-NCC tab specifies the location of the folder containing the firmware for KT-NCC controllers. Unlike the other firmware, KT-NCC is updated automatically when a version of EntraPass Global Edition is upgraded.



### KT-IP

The KT-IP tab specifies the location of the folder containing the firmware for Kantech IP Link module. The system will use this data to update the installed controllers.




### Image Parameters

the Image directory is where you will define parameters for the badging features. You will define image quality for picture, signature and background images.  
If you are using the badging feature, it is recommended to leave the jpeg quality to default. If you are not using the badging feature, you may reduce the jpeg quality of your images so that they will

not occupy a large space in the database. You must take in consideration, however, that reducing the quality of the saved images may affect the quality of the photos imported into badges. A parameter allows you to save cards and visitor card pictures, signatures and background graphics to a file instead of directly to the database. We are offering this option for sites that have large banks of pictures and graphics. The picture, signature and graphic database can currently contain up to 2 Gb of data each. The parameter will be used in instances where a site may need more space to save pictures, signatures and graphics.

## Picture and Badging

The picture and badging feature allows you to adjust the image and signature quality for use with the Badging feature.



- Unchecking Use JPEG format for pictures, signatures and badges tells the system to save pictures (or signatures) in a tiff format.



**NOTE:** Remember that this may affect the image quality. If you are not an advanced user, leave these values to default.

- The User picture, Signature, Badge background and Badge picture indicate the quality of the image that will be saved. If you choose 0, the saved image quality will be poor; 100 indicates an excellent quality.
- Select the location of the Picture (Signature) transparent color position for pictures and signature. Four choices are available (top-right, top-left, bottom-right and bottom-left). By default, the system chooses the bottom left-hand corner for the transparent background color. EntraPass allows operators to choose a more suitable color.
- When checking the Save pictures (signatures) in a file box, the system will create Picture and Signature directories under C:\Program Files\Kantech\Server\_GE\Data where all pictures and signatures will be saved instead of directly in the database.


- When checking the Save visitor pictures (signatures) in a file box, the system will create Picture and Signature directories under C:\Program Files\Kantech\Server\_GE\Data where all visitor pictures and signatures will be saved instead of directly in the database.



**NOTE:** When modifying an existing picture or signature, EntraPass will save it to the appropriate file and delete the corresponding entry in the database.

## Graphic

The graphic feature allows you to adjust the graphic quality for use with the EntraPass software.



- Unchecking Use JPEG format for pictures (signatures) tells the system to save pictures (or signatures) in a tiff format.



**NOTE:** Remember that this may affect the image quality. If you are not an advanced user, leave these values to default.

- The Jpeg quality value for Graphic background (picture) indicates the quality of the image that will be saved. If you choose 0, the saved image quality will be poor; 100 indicates an excellent quality.
- When checking the Save graphics in a file box, the system will create a Graphic directory under C:\Program Files\Kantech\Server\_GE\Data where all graphics will be saved instead of directly in the database.




**NOTE:** When modifying an existing graphics, EntraPass will save it to the appropriate file and delete the corresponding entry in the database.

## Report Parameters

The Report tab enable users to define the field separator for reports, disk space threshold and user name format.

## CSV


Under the CSV tab, you can define the field separator for your reports.



- By default, the system uses a comma (,) as the Field separator. You can modify the comma for another character. Other options are: Period, Equal, Semicolon, Colon, Space and tab.
- It is recommended to check the Date and time on separate fields option. When selected, CSV (comma separated values) as the output process for your reports, by default, the system includes the date and the time in a single field. When you select this option, the system will separate the date and the time fields.

## Disk Space


This feature is a protection when for instance a huge report has been requested. In this case, the system will abort the execution of the report and displays an alert message indicating the reason of the abortion.



- **Abort report if free space lower than (MB)** scroll-down list allows you to specify the minimum amount of free disk space required for the execution of reports.

## User Name Format

Specifying the user name format will tell the system how cardholder's names will be sorted by the system.



- Parse user name should be checked if you want to select a method of parsing the user's name in the system.
- User name format lets you select the parsing method. Options are: Begin with last name, Begin with first name.
- Parse user name with lets you select the character that will be used to parse the user name fields. Options are: Comma, Period, Equal, Semicolon, Colon, Space.
- Strict search on card field should be left empty unless you wish to keep the previous method (EntraPass Version 3.17 and lower) of strict searching a card field for reports.




**NOTE:** Prior to version 3.18 of EntraPass, the system used a strict search method that required Administrators to enter specific upper and lower boundaries to attain specific results. For example, for generating a report that included all users whose last name started with A, the lower boundary had to be A and the upper boundary had to be AZZZZZ. Now, the system will display all user names that start with an A just by entering A as a lower and upper boundary.

## Video Parameters

The Video section will display only if the Video integration option is enabled in the EntraPass system. You will define the time synchronization, remote video process and JPEG format for video images.

## Parameters

The Parameters tab allows you to define parameters for the video process.



- **Disable manual time synchronization** will keep the EntraPass server from updating the video server date and time following a manual modification of time. This feature is useful when, for example, you want to keep all recording events that occurred at the video server regardless of the actual time at the EntraPass server.
- The **Remote video process control parameters** section contains parameters that define remote management of video processes between the EntraPass Server and the video servers connected to EntraPass. It manages all the tasks (controls) related to: recordings, polls, events, and presets and patterns.
  - **Preset and pattern control application** field allows you to enter the number of applications that will be simultaneously launched for processing presets and patterns. The system is preset with a range value of 1 to 8 concurrent applications.



**NOTE:** A Preset and Pattern Control application is launched each time a video recording is started following a trigger on a preset. If you set this number to 1 and if there are for instance more than 1 video servers with presets and patterns defined, the control application will process presets on all video servers. If you decide to increase the number of Preset and Pattern Control Applications, keep in mind that running many concurrent applications takes a great amount of system resources.

- **Disable DirectX** will disable DirectX, a Windows® technology that enables higher performance when working or viewing graphics and other multimedia contents, including video and sound. By default, DirectX is enabled with the Video feature. You may sometimes need to disable it if, for example, video images are not correctly displayed or are not displayed at all.




**NOTE:** The system will use more system resources when DirectX is disabled

- Reset remote video process application will allow the system to terminate and automatically restart the Remote Video Process application a few seconds later. This option may be used in instances when the video events are not being displayed.
- Reset remote video process applications control will allow the system to terminate the Control applications (recordings, polls, events and preset and patterns) and automatically restart the Remote Video Process application.
- Log Video process error will allow the system to keep a log of all video process errors in the EntraPass server files. Video process errors are logged in C:\Program files\Kantech\Server\_GE\Bin\Log. Each Remote Video Process Control application generates a log file:
  - CONTROL\_LOG\_01.txt (errors generated by RVPCONTROL1.exe)
  - CONTROL\_LOG\_02.txt (errors generated by RVPCONTROL2.exe)
  - CONTROL\_LOG\_03.txt (errors generated by RVPCONTROL3.exe)
  - CONTROL\_LOG\_04.txt (errors generated by RVPCONTROL4.exe). The system will generate as many log files as there are control applications running concurrently (CONTROL\_LOG\_05 to 08). The number of error log files will be equal to the number defined in the Preset and pattern control application field.

## Snap


The Snap option allows you to define the image quality that will display in the video thumbnails.



- The Video image snap indicates the quality of the image that will be saved as a thumbnail for each video. If you choose 0, the saved image quality will be poor; 100 indicates an excellent quality.

## Time Parameters

The Time section allows you to specify which gateway will be used to automatically adjust the time of all the computers connected to the EntraPass server. This feature is very useful when managing remote sites.



**NOTE:** The gateway polls the first controller on the first site at 5:47 am or 05:47, 1:47 pm or 13:47 and 7:47 pm or 19:47 to get the controller time.

- No time adjustment will disable the option.
- By Gateway will automatically synchronize the time of all computers with the Gateway selected in the scrolling list.
- By Server will automatically synchronize the time of all computers at regular intervals. You must also select the rate of Hours between refreshes in the adjacent selection box.

## PIN Parameters


EntraPass has the ability to prevent or allow PIN duplication. The system can also be configured to send a notification if a PIN is duplicated. Each time a card is issued, the system checks the PIN settings.



This feature can be used for example while loading cards in a batch. An operator may decide to set the PIN option to allow duplication. Later, if desired, the duplicate PINs can be changed to prevent confusion.



**NOTE:** Optionally, the operator can display the list of PIN owners. For details, see "To View and Verify PINs" on page 261.



In the Duplicate PIN process section:

- **No duplication:** a warning appears on the workstation, the PIN field will be reset to the value you are attempting to duplicate and will be enabled, inviting you to enter a valid PIN. Only PIN 00000 will be duplicated regardless of the PIN setting option.
- **Notify when duplication:** the server verifies if this PIN already exists. If the PIN exists, a message box appears, indicating that the PIN exists. A Details button will allow operators to view a list of cardholders who were issued this PIN.
- **Duplication:** no test will be processed, the PIN will be accepted even if it is a duplicate.

## Backup Scheduler

A backup is a copy of the systems database which serves as a substitute or alternative in case the computer fails. If your system computer fails, you may restore a backup copy onto another computer (on which the EntraPass software has been installed).

- Back up your files regularly, at least once a week or more if many modifications were made to the database.
- We recommend that you make two backups of all your database files. To be especially safe, keep them in separate locations.
- To backup your files, you can use:
  - the menus of the Server/Backup Tab, or
  - the Backup Scheduler to apply automatic schedules, or
  - other third party software and hardware.




***NOTE:** By default, when you backup or restore files, the Server databases will temporarily be disabled (not available). The Workstations will not be able to modify the databases.*

The Backup Scheduler program is used to schedule automatic backups of your data, archives, and Time and attendance databases. Define the default settings and the system will do the rest!

## To Schedule Automatic Backups of the System Database

- 1 From the Options main window, select the Backup Scheduler icon.



- 2 Select the tab corresponding to the information you want to backup: Data, Archive, or Time & Attendance.



**NOTE:** By default, the system will automatically backup your files every Sunday at 4:00 AM for all new installations. Setting this feature at 4:00AM has an added benefit of not interfering with the system processing time or other tasks scheduled around midnight.

- 3 Select the Automatic backup option to enable the options displayed in the window. The options displayed depend on the tab that is enabled.
- 4 Select the backup folder:
  - Default folder—will backup your files in a system default backup folder. By default, the name of the backup sub-directory is generated automatically according to the following

convention: X\_YYYY\_MM\_DD\_HH\_MM\_SS (Where 'X' = Data or Archives or Time and Attendance (D, A or T), year, month, day, hour, minutes, and seconds.



**NOTE:** By default, the system backs up all the information originating from the following directories: C:\PROGRAMFILES\ KANTECH\SERVER\DATA or ARCHIVE or TIME. The information is sent to: C:\PROGRAMFILES\KANTECH\SERVER\BACKUP\X\_YYYY\_MM\_DD\_HH\_MM\_SS

- Specific folder—will backup your files in a sub-folder labeled according to the default convention in the XXX folder.
- 5 Select the **Backup type**. The options that are displayed depend on the type of the data to be saved.
    - Separate files: will backup the databases one by one (standard) (*Data only*).
    - Separate files (full backup): will backup all databases (*Archive, Time and Attendance*).
    - Separate files (incremental): will backup all databases. Only the information that was modified since the last backup will be saved (*Archive, Time and Attendance*).
    - Self-extracting compressed file: will create an executable file (\*.exe) that will compress the information so as to reduce the amount of disk space taken by the backup. (*Data only*)
    - Self-extracting compressed file (full backup): will create an executable file (\*.exe) that will compress the information so as to reduce the amount of disk space taken by the backup (*Archive, Time & Attendance*).
    - Self-extracting compressed file (incremental): will create an executable file (\*.exe) that will compress the information so as to reduce the amount of disk space taken by the backup. Only the information that was modified since the last backup will be saved (*Archive, Time & Attendance*).



**NOTE:** When you have selected “full backup”, each time a backup is done a new sub-folder containing the data or the self-extracting file will be created. If you are using the incremental backup type, only the information that was modified since the last backup will be saved. If you want to restore information, you will have to restore all the sub-folders one-by-one (starting from the oldest).

- 6 Select the frequency of the backup,
  - Weekly: the backup will be carried out once a week. Specify which day (example, the backup will be executed every Thursday).
  - Monthly: the backup will be carried out monthly, specify the day of the month (example, the backup will be carried out every first day of the month).
  - Daily: the backup will be carried out every day.
  - Now: this option allows you to request a backup when you need it.
- 7 Enter the time at which the backup will start (24:00 format), then click on OK to save.
- 8 Repeat steps 1 to 8 for all the tabs.


## Custom Messages

The Custom Messages option allows operators with proper security rights to define custom messages that can generate an event based on a schedule. Up to 10 custom messages can be programmed to trigger an event at a preset time. And each custom message can be triggered when the schedule becomes valid, invalid, or both. In other words, you can trigger up to 20 custom events if you take into account the start and/or end of a schedule interval.

Each custom events will be displayed in the Messages List on the Desktops.

### To Set Up Custom Messages


- 1 From the Options Main window, click Custom Messages.



- 2 In the first tab, enter the first custom message you want to see display in the Messages List. Two fields are available for primary and secondary languages.
- 3 Select a preset schedule that will determine when the custom event will be triggered.
- 4 Select if you want the custom event to be triggered when the schedule becomes Valid or Invalid, or both.
- 5 Move to the second tab to enter a second custom message, and so on.

## System Registration

This menu is used to register new system applications such as Workstation, Gateway, SmartLink, etc. in order to register and use the system's database and to establish communication with the Server.



**NOTE:** For more information on how to install and register new applications, see "Software Installation" on page 7. Before you install new applications, make sure that you have the proper serial numbers for the installation.

## Database Integrity Verification

The database utility program allows to verify and to repair the system databases. When the Database Utility is launched, the system scans all the tables for any possible errors and repairs them automatically.


Note that when you launch the Verify Database Integrity utility from the EntraPass application menu, this is a surface operation. If your system is experiencing problems, when your system experiences problems, you have to run the Database Utility program from Windows® Start menu

### To Perform a Quick Verification of the Database Integrity

- 1 From the Option toolbar, click the Database Integrity icon. The system displays a warning.
- 2 Select Yes to continue.



**NOTE:** When you launch the *Verify Database Integrity* utility from the *EntraPass* application menu, this is a surface operation. If your system is experiencing problems, you must run the Database Utility program from Windows® Start menu.







---

## Chapter 15 • The EntraPass Server Module

The EntraPass Server is a dedicated computer on a network that manages the access control system database. It is used to receive and dispatch information received from the different gateways and workstations receiving information from connected controller sites.

In some applications, a Redundant Server and a Mirror Database can be used as an alternative if the Primary server failed.


The EntraPass server can be used for:

- Displaying all the workstations connected to the server, the system event log and system error log
- Registering new connections and system options (workstation, gateway, client applications, etc.)
- Creating and restoring backups (Data, Archives, Time and Attendance databases)
- Restoring data (Data, Archive, Time and Attendance databases)
- Verifying database integrity
- Changing the database language
- Cleaning the database by clearing records relating to previously erased data

## The Server Launch

In order to access the EntraPass Server commands, you have to start the Server and login. Operators are identified when they login. This allows them to have access to the security system menu associated with their access level, and to establish communication and initiate interaction with the workstations. However, it is not mandatory to login for the Server to operate.


- 1 From the Windows® Start menu, click Start > Programs > EntraPass Global > Server > Server. You may also click the Server icon on the desktop, if applicable.



- 2 Enter your User name and Password (case sensitive) and click OK to continue. To modify this password, see "Operators Definition" on page 352.



**NOTE:** To allow an operator to login to the server, select the "Allow login on server" option, during the Security Level definition of an operator. For more information, see "Security Level Definition" on page 356.



- 3 To login to the server, click the **Login/Logout button**, the system displays the login window. The status bar indicates the communication status: **Green**: Communication is OK, **Red**: Communication problems.
- The colored flags represent the status of a system logical or physical component:
  - Database state availability state
  - Database locked state: it turns red when the database is locked
  - System date and time
  - Login name of the operator who is currently logged in the Server
  - Number of client connections, that is, the number of workstations connected to the server
  - Number of system logs (messages and events)
  - Number of error logs
  - Computer name (NetbEUI) where the server is installed
  - Server's IP address
  - Secondary IP address, if the Mirror database and Redundant server communicate with the server through a TCP/IP connection and if they are configured in the system
  - Other IP address, if applicable.


## Server Connection list

This menu allows operators to view various lists which show current operational status between the EntraPass server and the workstations connected to it

### To View Applications Connected To The Server

Operators can view the status of all Entrapass applications from the Workstation or Server user interface.

- 1 In the EntraPass server application, select the Connection tab and click the Connection List icon.




- 2 Click the + sign next to each workstation to view details about a workstation (such as: registration codes, TCP/IP address, connections, messages buffered, etc.).

### To View the System Log

The System Log window contains all the login and logout events for all workstations defined in the system. The logs are displayed with date and time, the workstation name, the operator name using the workstation as well as the log type.

The System Log window contains all the login and logout events for all workstations defined in the system.

- 1 To view system log, select the View System Log icon.




Date and time	Workstation	Operator name	Transaction
2001-09-28 10:54:26 AM	Security Office	KANTECH	Login
2001-09-28 11:29:04 AM	Security Office	KANTECH	Logout
2001-09-28 11:30:46 AM	Security Office	KANTECH	Login
2001-09-28 11:31:42 AM	Security Office	KANTECH	Logout
2001-09-28 11:31:42 AM	Security Office		Disconnecting
2001-09-28 1:40:14 PM	Server	KANTECH	Logout
2001-09-28 1:40:40 PM	Server		Login denied
2001-09-28 1:40:49 PM	Server	KANTECH	Login
2001-09-28 2:06:49 PM	Security Office		Connecting
2001-09-28 2:07:09 PM	Security Office	KANTECH	Login
2001-09-28 2:15:50 PM	Security Office	KANTECH	Logout
2001-09-28 2:15:50 PM	Security Office		Disconnecting
2001-09-28 2:19:33 PM	Security Office		Connecting
2001-09-28 2:19:45 PM	Security Office	KANTECH	Login
2001-09-28 2:54:49 PM	Security Office	KANTECH	Logout
2001-09-28 2:54:49 PM	Security Office		Disconnecting
2001-09-28 3:42:07 PM	Security Office		Connecting
2001-09-28 3:42:38 PM	Security Office	KANTECH	Login

- 2 From the Sorted by drop-down list, select the sorting criterion: the system events will be displayed according to your specifications.
- **Date and time**— This is the normal incoming sequence, if you select another sorting mode, you interrupt the normal sequence. Select date and time to restore the normal sequence. To do this, you have also to use the “restart scroll” button.
  - **Operator**—When selected, all columns will be sorted according to the Operator column in alphabetical order.
  - **Workstation**—When selected, all columns will be sorted according to the Workstation column in alphabetical order.
  - **Text filter**—When selected, a new window will be displayed. From that window, enter the text string (i.e.: kantech), and the system will only display logs containing the specified string text. To return to normal display, click on text filter.
- 3 You may change the background color. To do this, right-click on the window and select a color from the displayed short-cut list.
- 4 You may also clear the window. To do this, right-click in the window, then select Clear from the shortcut menu.

To View System Errors

The system errors are displayed with the date and time, the workstation name where the error originated from, the code number and its description.

- 1 Select the View system errors icon to view all the errors that occurred in the system.



Date and time	Code	Workstation	Error code	Description
2001-09-27 12:57:41	4		55	
2001-09-27 1:12:46	P 4		55	
2001-09-27 1:29:58	P 4		55	
2001-09-27 3:16:50	P 4		55	
2001-09-27 3:29:23	P 4		55	
2001-09-27 3:34:54	P 4		55	
2001-09-27 4:26:41	P 4		55	
2001-09-27 4:30:14	P 4		55	
2001-09-27 4:30:29	P 4		55	
2001-09-27 4:32:58	P 4		55	
2001-09-27 4:33:28	P 4		55	
2001-09-27 4:33:28	P 30	Corporate Gateway	0	Registration denied - workstation locked
2001-09-27 4:33:52	P 4		55	
2001-09-27 4:33:55	P 30	Security Office	0	Registration denied - callback failure
2001-09-27 4:52:34	P 4		55	
2001-09-27 5:00:13	P 4		55	
2001-09-27 5:00:52	P 4		55	
2001-09-28 11:31:42	P 4		55	
2001-09-28 2:15:50	P 36		55	
2001-09-28 2:54:49	P 4		55	

- 2 You may also use the right-click menu to change the window background or to clear all the data displayed.



**NOTE:** For information on system registration, see "System Installation" on page 12.

## Backups

A backup is a copy of your system database which serves as a substitute or alternative in case the computer fails. Backing up your files safeguards them against accidental loss when for example the hard disk fails or when you accidentally overwrite or delete data.

If your system computer fails, you may restore a backup copy onto another computer (on which the EntraPass software has been installed).

The EntraPass Backup tab allows operators to perform manual backups of the system data, archive and time and attendance databases. It is also used to restore backup data.

Safeguard tips:

- Back up your files regularly, at least once a week or more if many modifications were made to the database.
- We recommend that you make two backups of all your database files. To be safe, keep them in different locations.
- To backup your files, you can use:
  - The menu of the EntraPass Backup utility, or
  - The EntraPass Backup Scheduler to apply automatic schedules parameter, or
  - Other third party software and hardware.



**NOTE:** By default when you backup or restore files, the EntraPass databases will temporarily be disabled. The second colored square of the database status turns red when the database is unavailable. The Workstations will not be able to modify the databases.

All the system data can be found under the following path: C:\Program Files\Kantech\ Server\XXXX. If you are using a third party program to perform backups, it is recommended to backup the whole Kantech directory and sub-directories.


Each time a backup is done (even if it is done automatically), a new sub-folder containing the data or the self-extracting file is created. If you are using the “incremental” backup type and you want to restore information, you will have to restore all the sub-folders one-by-one (starting with the oldest).

### To Create Backups of Type D, A, and T

By default, the name of the sub-directory in which the data/archive/time and attendance databases will be saved is generated automatically according to the following convention: X\_YYYY\_MM\_DD-h\_mm\_ss, where X is the data type (D for Data, A for archive and T for Time and Attendance).

The following steps explain how to backup data. The same steps apply also when you backup archives or time and attendance data.

- 1 Select the item you want to backup: data, archive, time and attendance databases. The system displays the backup sub-directory in which the information will be saved. You may keep the default folder, or you may browse your disk to specify a new destination folder for the backup.



**NOTE:** By default, the system/workstation will backup all the information originating from the following directory: C:\Program Files\Kantech\Server\_GE\Data or Archive or Time and attendance to C:\Program Files\Kantech\Server\Backup\X\_YYYY\_MM\_DD-h\_mm\_ss, where X is the data type. The data type is followed by the year, month and day information as well as the time of the backup.

- 2 Select the Backup type:
  - **Separate file:** the system will back up the databases one by one (standard). This backup type includes the *Regdata.ini* file containing the following identification data: software used to create the backup, backup type (data, archive, time and attendance), operator who requested the backup, date and time of the backup as well as the software version.
  - **Self-extracting compressed file:** the system will create an executable file (.exe) that will compress the information so as to reduce the amount of disk space taken by the backup. The system displays information identifying the backup: software used to create the backup, backup type (data, archive, time and attendance), operator who requested the backup, date and time of the backup as well as the software version.
- 3 From the Drives drop-down list, select the drive on which the backup will be performed. A list of choices is available according to your computer settings. To save as default, leave as is.
- 4 You may click the **New folder** button if you want to specify a new destination folder.



- 5 Click OK to launch the backup procedure. The backup process can be viewed on the bottom part of the window.




**NOTE:** You can use the "Backup Scheduler" to schedule or plan automatic backups. To schedule automatic backups see "Entrapass Options" on page 461. When you backup or restore files, the Server databases are temporarily disabled. You cannot modify the databases when a backup is in process.

## To Restore Data (D, A and T)

If you are restoring data, it is strongly recommended to perform a backup before.

If you are using a third party program to restore the data, it is recommend to restore the whole Kantech directory and sub-directories.

- 1 From the Server window, select the desired Restore button (Data, Archive, Time and attendance). The system displays the Restore data window. It displays the path of the backup folder.



**NOTE:** By default, the system restores all the information originating from the following directory: C:\ProgramFiles\Kantech\Server\_GE\Backup\ X\_YYYY\_MM\_DD-h\_mm\_ss to C:\Program Files\Kantech\Server\_GE\Data or Archive or Time and Attendance.

- 2 To change the destination folder, browse the Drives drop-down list. Click OK to launch the restore process.




**NOTE:** It is recommended to reload the Gateway after restoring the data (*Operation > Reload data*).


## Server Utilities Usage

This menu allows users to verify the system database integrity and to restore the system data bases. This menu is also accessible from workstations. For more information on the system utilities, see *"System Utilities"* on page 511.

- 1 Select the Utility tab to use the server utilities.



- 2    Select an icon in the toolbar.



- 3    Click the Rebuild button. The system automatically starts the operation and displays a progress bar indicating that the process is on-going.




*NOTE: Certain windows may provide only a Yes or No button rather than a Rebuild button to start the operation.*

*NOTE: The Clean database utility also provides a Yes or No button to clear records from the database relating to previously erased data.*

## System Language Modification

In order to have the system run in the language of your choice, first change the system language (Option > Select a language) and then run the Swap description utility.

- 1 From the Server main window, select the Options tab.



**NOTE:** Important! When you modify the primary language of the database, the database operation will be suspended during the operation (not available for users) and the changes will be effective only when the server is shutdown and restarted.

- 2 From the Select primary language drop-down list, select the language you want to use as a primary language. From the Select Secondary language drop-down list, select the language you want to use as a secondary language.
- 3 Shutdown the server.
- 4 Restart the server and login.
- 5 Select the Utility tab, then select the Swap descriptions button.
- 6 Once completed, restart the server.



**NOTE:** You may also click the *Change system font* button to modify the font: this option is used to select the font for the database.

## Chapter 16 • System Utilities

This section groups the utility programs of the EntraPass Software. These programs are accessible from the Windows® Start menu. The following programs are launched from the server or the workstation.

- **Database Utility** —Program intended to re-index archived files, update database fields, verify archived files, verify the database integrity, verify the database index, verify the database links and to verify the database hierarchy while the server is shutdown.
- **EntraPass Video Vault Application** —Program used to manage video segments archive. This program will process requests from EntraPass users to view archived video segments and to monitor video archiving processes.
- **Express Setup** —Program used to configure all the components related to a gateway including the type of readers used, type of connection, number of controller sites, number of controllers in a site, etc.
- **PING Diagnostic** —Program used to diagnose network intermittent related problems.
- **Quick Report Viewer** —Program used by the operator to view reports without having to start EntraPass.
- **System Report Viewer**—Program used by the operator to view reports without having to start EntraPass. This utility is installed from the Setup window.
- **Vocabulary Editor**—Program used to translate, in the language of your choice, the display text of the software.
- **Workstation—Configuration Program**—Program, similar to a standard workstation, used by the system administrator to configure the system logical and physical components.
- **Migration Utility**—Program used to transfer database information for the upgrade from Special to Corporate Edition or Corporate Edition to Global Edition.
- **The Gateway Interface**—The CardGateway software is a program that creates a mirror copy of the EntraPass card database in the MS-SQL or ORACLE Server. This interface allows user to modify, add or obtain card-related information, all this in real-time, from the MS-SQL or ORACLE Client version. The mirror card database, which contains cardholder information, will be updated automatically as soon as new information is available in the EntraPass card database.
- **The SmartLink Interface**—The SmartLink interface allow users to define a message and format data that may be sent on the second COM port or to a disk file. Using the SmartLink feature, you can interface to just about any intelligent device such as video matrix switchers, paging systems, etc.

## Database Utility

Since the information from the system databases is sent back and forth between components, some data might end up in the wrong table.

Some of these verifications such as re-indexing the archive files, updating database fields, verifying archive files, or swapping database descriptions require that the Server be shutdown.

When an operation that requires the server to be shutdown is launched, the operator is warned that the databases will be suspended during the operation.

From EntraPass, the Database utility program verifies the integrity of the tables that are used to store events, alarms, network alarms, and graphic. Basically, the system scans all the system tables and correct errors (if they are found).

You may want to start this utility when your systems hangs up frequently.



**NOTE:** You may also verify the system databases from the Server (*Server > Utility*). However, this will only allow you to perform “surface” verification. If the system hangs frequently, for instance, use the Database Utility program. To do so, you have to shutdown the server.

### To Verify the Database Integrity

The database utility program allows to verify and to repair the system databases. When the Database Utility is launched, the system scans all the tables for any possible errors and repairs them automatically.

- 1 You can use the icons under the Utility tab in the EntraPass server application, or launch the Database Utility from the Windows® Start > Programs > EntraPass Global > Workstation > Database Utility menu.
- 2 To verify the database integrity, click the Verify database integrity icon in the toolbar. You have the choice to perform a quick or complete check.



**NOTE:** When you launch the Verify database integrity utility from the Options menu, this is only a surface operation. When your system hangs frequently, you have to run the Database Utility program.


- 3 Select the type of verification you want to perform. If you select a quick check, the system scan through the tables, but does not display a detailed report after.
- 4 If you select a Complete check of the database, a detailed report is displayed.

### To Update Database Fields

This function is automatically executed when the software is updated.

If an operator performs a database restore (Server, Options tab, Restore), the database fields are automatically updated when the information is restored. Even when an operator performs a database restore outside the Server (copies the databases from a third party backup program), this function is automatically carried out when the Server is started up again.

- 1 From the EntraPass Database utility window, select the Update database field icon.



**NOTE:** Use this function when, for instance, you experience problems when starting the server or workstation. When the system does not start, this may imply that there are problems in the database; that the source and the structure do not match.

## Database Utility, Server

Usually, the system verifies the database integrity automatically at start-up (a system message is displayed). If an operator decides not to perform a database check at startup, he/she may trigger the operation later, using the Database Utility program.


It may also be necessary to launch the database utility program when for instance the system experiences problems frequently. This operation should be executed when the system is not much used since the system databases are not available during operations on the databases.



**NOTE:** It is recommended to exit the Server before you run the Database utility.

### To Run the Database Utility


- 1 Exit the server program. During this operation, the system databases are suspended. A red square button in the status bar indicates that the databases are unavailable
- 2 From Windows® start menu, select Start > Program > EntraPass Global Edition > Server > Database Utility.



**NOTE:** When you select *File > Workstation*, the system displays only two icons, the *Verify database integrity* and the *Update database fields* icons. The Server toolbar offers more choices.



- 3 Select the icon or menu item corresponding to the program you want to execute. The system displays the result of the analysis.



**NOTE:** Use this function when, for instance, you experience problems when starting the server or workstation. When the system does not start, this may imply that there are problems in the database; that the source and the structure do not match, for instance.

## To Verify Database Index (Server)

This program allows to entirely rebuild the index by using the information that was copied in the primary databases and grouping it to rebuild the Registry.DB database. The latter is used to increase the system performance.



**NOTE:** This program can be used when a database is corrupted because it has not been backed up.

## To Verify Database Links

The Verify Database Links utility is used to rebuild all the links of the database. Moreover, this program cleans the databases by deleting links that are no longer valid. For example, if a schedule was assigned to a functionality and this schedule was deleted, the system will initialize the field where it was assigned in the primary database. It will also remove the records that point to deleted components. For example, if an access level is assigned to a gateway and this access level was deleted, it will delete the record in the database.

The Verify Database Links utility enables complete management of the links between each component and ensures that the correct information is displayed when:

- Viewing the structure of a component's links to all other components of the system,

- Removing all the traces of a component within the database when this component has been deleted. For example, if a schedule is deleted, the system will use the link list to initialize all the database fields that contains this schedule.



**NOTE:** It may be necessary to use this function when it is obvious that the database links are incorrect. This features is useful when for example the system experiences abnormal terminations.

## To Verify Database Archive Files

This function is used to verify archive files. It assigns a new unique sequential value to all primary indexes of archive files.

## To Verify Time & Attendance Files

This function is used to verify time and attendance database files. It assigns a new unique sequential value to all primary indexes of time and attendances database files.

## To Verify Database Hierarchy

In EntraPass, the database is set up in a hierarchical way, which means that all components have a parent and can have child components.

The Verify database hierarchy utility is used to rebuild the parent-child links within the database. The results of this program are limited if the damages of the database are severe.



**NOTE:** When a user tries to access a controller by selecting a gateway and a site and when the result does not correspond to the reality, this means that the database hierarchy is probably corrupted. In this case, the Verify database hierarchy feature can be used to correct the problem. If the problem could not be fixed, this could mean that the database is too damaged to be fixed. It will be necessary to restore the database.

## To Swap Descriptions

This function is used to interchange description #1 (primary language) with description #2 (Secondary language) in all the database of the system.



**NOTE:** When this function is executed, the current primary language becomes the secondary language, and the secondary language becomes primary. This function must be executed with caution to avoid system language problems.

Follow this procedure to modify the database language, otherwise the database operation will be suspended during the operation and the changes will be effective only when the server is shutdown and restarted.

- 1 Under the Utility tab in the Server main window, click the Swap Languages tab, or start the Database Utility program (Windows® Start menu > Programs > Entrapass Global Edition > Server > Database Utility).
- 2 A warning will popup to confirm that you want to swap languages. Click OK.

- 3 Restart the server.



*NOTE: If the server or workstation is not shut down, the Database Utility program will not operate.*

## To Clean the Database

This option is used to physically remove database records which have been identified by the system as erased. Most of these records relate to cards and are kept in the Deleted Components section of the database. Using this option will considerably reduce the space required by your database. It will also improve system performance relating to searches for card information. It will not affect the table Registry, nor will it have an impact on historical reports.

- 1 Start the Clean database utility (Server > Utility > Clean database icon).
- 2 Click on the Yes button.



*NOTE: It is strongly suggested to back-up the database before performing this operation. Clean database will suspend operation of the database while cleaning is in effect.*

## EntraPass Video Vault

The EntraPass Video Vault application addresses the need for optimal video data storage and archive management. This application offers an easy way for collecting important video data for future reference. In fact, video recordings have a limited life span depending on the video server setting and capability. Moreover, since video recordings require a great amount of disk space, using an archive management tool such as EntraPass Video Vault enables organizations to better manage and easily retrieve video contents.

EntraPass Video Vault enables EntraPass users to:

- View the status of video archiving requests
- Monitor the status of video servers associated with the active EntraPass Video Vault application
- Monitor video download logs
- Archive video segments

The EntraPass Video Vault application will process the following video segment types:

- Video segments that were triggered by an automated trigger
- Video segments triggered by a manual operation
- Video segments recorded following video server triggers
- Exported video segments tagged for archiving




**NOTE:** The EntraPass Video Vault application requires an additional license. It is possible to install more than one EntraPass Video Vault application with EntraPass. Each EntraPass Video Vault must be configured for use with EntraPass (*Devices > EntraPass Applications*).

### To Install the EntraPass Video Vault

An Option Certificate is required to install EntraPass Video Vault. For details about installing EntraPass advanced options, see *"To Add Optional Components/Features" on page 11*.

- 1 From the Entrapass System Registration window, select the Entrapass Video Vault, then select the Click here to install component button



- 2 Enter the Option Serial Number found on the Entrapass Video Vault Management Option Certificate.
- 3 Enter the Registration Confirmation Code provided by the Kantech Technical Support personnel.
- 4 Click OK to close the Component registration window. Once you have completed the registration process, the Entrapass Video Vault application is added to the Components list in the System Registration window.

Components	Installation Code	First time connected
(2) Additional Corporate Ga...	A969-CCCB-8BE2-62E6	
(3) Additional Corporate Ga...	A6AC-2A7A-328D-7DED	
(4) Additional Corporate Ga...	BAD2-23FA-9543-D796	
(9) Additional Corporate Ga...	D9C9-2B59-5F45-8E4E	
Oracle/MS-SQL Interface	AE9E-112B-88C5-EE8C	15/09/2004 3:27:34 PM
Video Vault	BFA3-E4E7-3C5A-ED4E	29/11/2004 4:30:03 PM


Components	Installation Code	First time connected
(2) Additional Workstations	0478-E8B9-B05C-D6C4	
(3) Additional Workstations	F778-559A-AA30-9403	
Additional Corporate Gatew...	169F-124D-095A-CF72	
SmartLink	0FBF-FA74-96A0-C54B	
Video Vault	B486-DC7C-7213-3A4E	

- 5 Use the Installation code and the installation CD to install Entrapass Video Vault on any computer meeting the minimum requirements for the Entrapass workstation application. For details about system requirements, see "System Requirements" on page 8.

## To Launch the EntraPass Video Vault

At startup, the EntraPass Video Vault application tries to connect to the EntraPass server. If you are launching the application for the first time, you may need the EntraPass Server's IP address. Also, make sure to launch the EntraPass Server before attempting to run EntraPass Video Vault.


- 1 From the shortcut menu on the desktop, or from the Windows® Start menu, launch the EntraPass Video Vault application.




- **Video Vault root directory:** indicates the default folder where video segments are stored. The EntraPass Video Vault root directory is determined when configuring EntraPass Video Vault from the EntraPass environment (EntraPass workstation application > Devices > EntraPass Applications > EntraPass Video Vault). The default EntraPass Video Vault root directory is C:\Kantech Video Vault.
- **Current process:** indicates the number of video segments that are being retrieved for archival purposes.
- **(KVI, KVA, AVI, IMG) files archived:** shows the number of video segment files retrieved by EntraPass Video Vault.
- **Default video file format:** the default format for archiving files. This format is defined while configuring video archiving parameters for the EntraPass Video Vault: EntraPass workstation application > Video > Video server > Video Vault Parameters tab.
- **Registered Video Server(s):** indicates the number of video servers associated with the active EntraPass Video Vault application. An EntraPass Video Vault application is associated with a video server when defining the Video Server (EntraPass workstations application > Video > Video server > Video Vault Parameters tab).
- **Processing error count:** indicates the number of unsuccessful video archiving processes. To learn why the archiving process was not completed, log on to Video Vault > Action menu item > Video Server List. The Action menu item appears only when you have entered a valid operator user name and password. EntraPass enables you to retry retrieving unsuccessful archiving processes from the Video Events List window: EntraPass workstation application > Video > Video Events List.

## To Manage Archived Video Segments

- 1 From the Entrapass Video Vault main window, select System > Login to launch Entrapass Video Vault and login.




- 2 Enter the User name and Password for Entrapass Video Vault, then click OK to close the Operator login window. You cannot log in two Entrapass applications simultaneously using the same user name and password. Since you must run Entrapass Video Vault and the Entrapass server at the same time, make sure to use a different user name for Entrapass Video Vault.




**NOTE:** To view detailed information about the numerical values displayed on the main window, log on to Entrapass Video Vault.

- 3 To view the list of Video servers associated with the EntraPass Video Vault application and the status of the archiving process, select the View Video server menu item.




- Video server on line, archive period valid: During this period, the EntraPass Server retrieves video segments from the Video server and queues them for archiving by EntraPass Vault. All video segments originating from video triggers (automatic or manual) and segments tagged to be archived in the Video Events List are archived in the EntraPass Video Vault.
  - Video server offline, archive period valid: This status is tagged with a red flag. It indicates that the EntraPass server cannot retrieve video segments from the Video server for various reasons. Video segments recorded during that period will not be available for EntraPass Video Vault.
  - Video server online, archive period not valid
  - Video server offline, archive period not valid
- 4 To view the list of drive on which video data have been archived, select the View drive list menu item. The Drive list window shows the status of all the files retrieved by EntraPass Video Vault from the Video server.





- Disk ready
  - Disk space lower than 100 MB
  - Network drive not available
  - Cannot access this drive
- 5 Select Transaction log to view the list of transaction errors.



**NOTE:** The transaction log window shows all the transactions that have occurred in the software since the last time it was run. The Filters fields enable users to select the type of transactions to be displayed.

## Vocabulary Editor

The Vocabulary Editor allows users to translate the display text of the software in the language of their choice.

EntraPass offers you the possibility of adding up to 99 languages for the purpose of changing the text language in the graphic user interface. However, you can only run the software in two languages at a time, a primary and a secondary language.

If you want to use the software in a language other than English, French, German or Spanish, you can have the database dictionary translated in the language of your choice. You will then have to integrate the translated dictionary in the software. The creation of a new display language is carried out in three stages:

- Translating the source text,
- Integrating the newly created language to the EntraPass dictionary in the Server,
- Distributing the new custom language to all EntraPass application.



**NOTE:** In order to be able to run a new language, your operating system (Windows®) must support the desired language. For example, your keyboard (characters) and window (display) must support the specific characters of the desired language. The computers where EntraPass applications are running must also support the language. For more information on language support, refer to your system administrator.

### To Install the Vocabulary Editor

EntraPass Vocabulary Editor is a stand-alone program. You can install it and run it independently.

If you want to translate the system language, you just have to install the Vocabulary editor and then to translate the vocabulary database.




**NOTE:** You do not need an additional license to install the Vocabulary Editor. You just have to select it in the Setup window.


### To Translate the System Language

EntraPass Vocabulary Editor is a stand-alone program. You can run it independently, you do not need to launch EntraPass software to run the Vocabulary editor. The Vocabulary Editor program will assist you if you want to translate the software in a language, other than English, French, Spanish or German.


- 1 Start the Vocabulary editor from the Windows® Start menu: click Start > Programs > EntraPass Global Edition > Vocabulary Editor > Vocabulary Editor.




- 2 From the available Language list, select the new language, then click New. The system displays again the Select language window. Select the source language for the translation, then click OK. The newly selected language is transferred to the right in the Custom Languages display list. The Edit and Delete buttons are enabled.



- 3 Select the Edit icon to view the vocabulary database table.



- 4 In the Vocabulary Editor window, click the Edit button to start translating the software vocabulary. The system displays the dictionary database.



**NOTE:** You must make sure that the Customdictionnary directories are regularly backed up (C:\ProgramFiles\Kantech\Vocabulary Editor\CustomDictionary\files.xxx.ath) or C:\ProgramFiles\Kantech\“Application type”\CustomDictionary\files.xxx.0

The table below shows the value of the Vocabulary Editor color codes.


VOCABULARY EDITOR COLOR CODES	VALUE
Green	Valid text string.
Blue/Green	New text string.
Red	Obsolete text string.

- 5 The “Source language” column contains text based on the basic language that was selected during the creation of the vocabulary. This column will serve as a “source” for the translation. Software language columns cannot be modified by the user.
- 6 Use the right-click to enable a contextual sub-menu or use the Language editor toolbar. A hint appears when you position the mouse over a button.

## To Integrate your Custom Language in Entrapass


Once the translation is finished, you have to integrate the new dictionary into the system dictionary so that system operators can use it.

- 1 Start the Vocabulary Editor. The Vocabulary Editor window toolbar displays five buttons.




**NOTE:** The Graphic User Interface will only appear in one of four languages: English, French, German or Spanish.

2 Select a newly translated vocabulary.



- You may choose to **Apply changes to the Operational dictionary**: this option is useful when you want to test your changes before you update other workstations.
- **Restore the operational vocabulary**: this option allows the user to easily restore the default languages. It creates a self-extracting file which restores the original dictionary.
- **Scan dictionary for new entries**: this option is useful when the software was updated for example.

- 3 If you decide to implement the new vocabulary, select the Actions menu, then choose Create self-extracting file for update option. The system creates the Updatedictionary.exe file, and prompts you to select a destination folder for the file:



- 4 Select the destination folder for Updatedictionary.exe. By default, the Self-extracting file is stored in C:\Program Files\Kantech (application).



**NOTE:** It is recommended to copy the Updatedictionary.exe file on a network folder if you want operators to access the file to update their software application.

## To Distribute the New System Vocabulary


Before you run the file, make sure to exit the EntraPass software; otherwise the operation will not work. To update the system vocabulary, you have to update the EntraPass server first. If you have a Mirror database application, close it before you shutdown the server (so it does not start the Redundant Server when you close the EntraPass server). Once the Mirror database application is shutdown, shutdown the Primary server, update it and re-start the server. Update the Mirror database and the Redundant server, then start the Mirror database.

## To Update the Server Vocabulary

- 1 Exit all Entrapass programs.
- 2 Start Windows Explorer® > Kantech > (EntraPass application), then copy the Updatedictionary.exe on the server.



- 3 Double-click **Updatedictionary.exe**. The system displays the Entrapass applications that are installed on the computer.




- 4 Select each application, then click the **Update dictionary** button.
- 5 You have to copy **Updatedictionary.exe** on every computer where Entrapass is installed, and then double-click it in order to launch the language update. To do so, you have first to exit all Entrapass applications before you run the self-extracting file.
- 6 Select the application you want to update (one at a time) and click **Update dictionary** button. The system will automatically copy the vocabulary to the Custom Dictionary directory then merge the custom directory with the application dictionary.




**NOTE:** You **MUST** update all the applications in the system.

**NOTE:** To restore the dictionary back to original default values, follow the same procedures as for updating the dictionary.

- 7 Once you have finished updating the dictionary database for the Primary Server, the Mirror Database and the Redundant Server, start the Primary server.



- 8 Select the Options tab, then select the Select language icon.



- 9 In the Select the language window, select the primary language and the secondary language. The newly integrated language is displayed in the list. It is important to select the language at this stage, otherwise the operators of the system will not be able to use it.



**NOTE:** For example, if your primary language is “English” and your secondary language is “French”: if you select your new language (i.e. Russian) as primary, all operators who have “English” as their display language in the Operator menu will be modified to “Russian”. On the other hand, if you change the secondary language to “Russian” and operators are using “English”, you will have to manually select “Russian” in the Operator definition menu”. To assign the desired language to an operator, use the *System* definition menu, then select the *Operator* definition menu.

- 10 Before you update all the applications, login on the server and verify the display language. If everything seems to be normal, then you can proceed with the system update. Remember, the computers must support the language (display and keyboard).



**NOTE:** For every language you are installing, be sure to select the correct keyboard (*Start > Settings > Control panel > Keyboard*). The selected keyboard is displayed in the system tray.

## To Upgrade the System Vocabulary

When you upgrade your system, the new or modified strings are automatically inserted in the system vocabulary and also in the custom dictionary.

If you have added a custom language to your system, you have to translate the new/modified strings following a system upgrade. Therefore, you have to re-edit the vocabulary and create a new self-extracting file.

When you re-open the vocabulary table, new strings are indicated by a green point. Obsolete strings (no longer used) are tagged red.



**NOTE:** For easier management, we recommend that you always edit your vocabulary from the same computer and integrate it to the system using a self-extracting file.

## Express Setup Program


The Express Setup program offers a quick and simple way to configure all the components of a system Gateway: type of readers used, connection, number of sites, site name, number of controllers on a site, etc. For example, it enables users to modify a door's name by automatically applying default settings to all relays and inputs of controllers connected to the selected door.

### To Configure a NCC 8000/Global Site Using Express Setup


- 1 From Windows Start menu: Start > Programs > EntraPass Global Edition > Server > Express Setup NCC. The system will display the Express setup window with a progress of the startup.




- 2 The Operator login window appears. Enter your operator name and password.



- 3 Select the gateway from the Select gateway drop-down list and the type of reader used on the gateway doors from the Select reader type list, then click on Next to continue.



- 4 From the next window, you can modify the gateway name. Specify the type of connection between the NCC and the Gateway (RS-232 = separate computers or integrated with gateway = same computer as the NCC). Specify the number of controller loops (max: 8) on this gateway and click on Next to continue.



- 5 The system will display the following window. Depending on the number of controller loops you have entered in the previous window, the system will display the next window more than once. Specify the site name and the number of controllers on this site and click on Next to continue

- 6 The system will display the following window. Depending on the number of controllers on the loop you have entered in the previous window, the system will display the next window more than once.
- 7 Specify the controller name, specify if the readers are located on the same door or on separate doors. Select the “define all relays and inputs” boxes if you want the system to automatically label (address) them. Click on Next to continue.
- 8 The system will display the following window. Depending on the number of controllers on the site you have entered in the previous window, the system will display the next window more than once.

- 9 Specify the door names (primary and secondary language) and click on “Finish” to end.




**NOTE:** If you have more than one controller site on the gateway, the system will display the last three windows until all the controllers sites are defined.

## To Configure a Site Under a Corporate Gateway Using Express Setup

- 1 From Windows® Start menu: Start > Programs > EntraPass Global > Workstation/Server > Express Setup. You may also launch Express Setup by clicking the Express Setup icon from the registration window or gateway definition window.



- 2 Click the Login icon. You have to log into the server before you modify the system configuration. Only authorized operators can modify the system parameters.



**NOTE:** The Operator login window appears only when starting Express setup in stand alone mode.

- 3 Enter your Operator user name and password, then click OK. The OK button is enabled when the Password field contains data.



- 4 Select the gateway for which you want to configure a site, then click the New site icon.

The screenshot shows the 'Express setup' dialog box with the 'Site information' tab selected. The fields are as follows:

- Site description:** Main Entrance
- Reader type:** IO Prox KANTECH XSF Format
- Number of controller:** 1
- Connection type:** Direct (selected), TCP/IP, Modem
- Controller type:** KT-200, KT-300 (selected), KT-100
- Port settings:**
  - loop speed: 19200
  - Com port: 1

At the bottom are 'OK' and 'Cancel' buttons.

- 5 Enter the Site name in the Site description field, then select the reader type.
- 6 Set the number of controllers.
- 7 Specify the connection type. This indicates how the site communicates with the gateway computer.
  - Select Direct, if the site is integrated to the gateway computer and connected to it by an RS-232 serial port. If the connection type is direct, then you have to specify the serial port (com:) as well as the controller site baud rate (usually set at either 9600 or 19200). The default value is 19200.
  - Select TCP-IP if the site communicates with the gateway through a terminal server device using a port number. Then you have to specify the terminal server's IP Address and Port number. If the connection type is TCP/IP, the port settings section is disabled. To configure the terminal server, follow the manufacturer's instructions or refer to the terminal server documentation.
  - Select Remote site Modem if applicable. The modem option is enabled only when this option is installed.
- 8 Select the Controller type for this site.
- 9 Click OK.



**NOTE:** When the system is updating the database, the second status flag turns red, indicating that the system database is locked. When you try to access another system menu while the database is locked, an error message appears. Simply wait until the system database becomes available.



The following are default values assigned to controllers by the Express Setup utility.

Controller	Door	Relays	Input zones	Aux. output
KT-100	1	4	4	2
KT-200	2	2	16	4
KT-300	2	2	8	4

The following table summarizes how input zones are used by the system.

Input zones	System use	Controllers
1	Door 1 contact	All
2	Door 1 Rex	All
3	Door 2 contact	KT-100 & KT-300
4	Door 2 Rex	KT-100 & KT-300
9	Door 2 contact	KT-200
10	Door 2 Rex	KT-200

The following table summarizes how output zones are used by the system.

Aux. output	Use	Controllers
1	LED (Door 1)	All
2	Buzzer (Door 1)	All
3	LED (Door 2)	KT-200 & KT-300
4	Buzzer (Door 2)	KT-200 & KT-300



**NOTE:** The remaining components (relays and input zones) are undefined, that is, they have been created but not yet defined. Components that are defined are grayed out. You cannot select them or change their description. You can change their description in their respective definition menu (Devices > Relays/Input zones).

By default, the system assumes that:

- The reader is IoProx Kantech 26 XSF Format,
- The power supervision schedule is always valid,
- The failsoft delay is enabled for 45 seconds,
- The resistor type is single (KT-100 and KT-300),
- The wait for second card delay is 30 seconds.

## To Configure a Controller Using Express Setup


When you add a controller to a site, the system prompts you to use the Express Setup tool to define the controller. You may also launch this tool by selecting a controller and clicking the Express Setup icon in the controller window toolbar.

- 1 From a controller definition window, click the Express Setup icon or click Yes in the system message box.



- 2 Specify if Both readers are on the same door if this is applicable. If two readers are installed on the same door, the REX contact option is disabled.

- Click the More button to define the other devices, such as doors, inputs, relays and outputs.




**NOTE:** Components are listed in the left-hand pane. The related tabs are displayed in the middle of the window. When you select a component, its default name, number and default settings are displayed in the language section. Select a component to enable its tab. Components that are assigned are gray. You cannot modify their description at this stage. You have to go in their definition menu. However, you may later modify any component description in its definition menu (Devices > Relay/Input/Output, etc.).

## Defining Relays

You may configure relays to define their operation mode, activation and deactivation schedules. If you want to assign a name to the relay, you have to select it. When you use the Select All button, the default names are kept.

- Select the first relay if you want to modify its description. The relay tab is enabled. You have to check the box beside the relay name in order to enable the language section.




- Check the appropriate options for the Operating mode and for the Activation mode.

- 3 In the **Automatic** activation schedule drop-down list, choose the appropriate activation Schedule.

## Defining Inputs

By default, the response time for a REX is 250 ms; it is 500 ms for other input zones. The alarm restore time is 150ms by default. The Express Setup program allows you to define the **Input Normal State** and **Monitoring Schedule**.

- 1 Select the first undefined input (its checkbox is not gray). Check its box to enable the language fields, then assign names to it.



- 2 Select the **Monitoring schedule** from the drop-down list. If you want to assign a custom schedule to the selected input, you have to define it. (Definition > Schedule).

## Defining Auxiliary Outputs

By default, all outputs are defined, as follows:

- Auxiliary output 1 is used as a LED for door 1 (all types of controllers)
- Auxiliary output 2 is used as a buzzer for door 1 (all types of controllers)
- Auxiliary output 3 is used as a LED for door 2 (KT-200 and KT-300)
- Auxiliary output 4 is used as a buzzer for door 2 (KT-200 and KT-300).


If you want to change their definition, you may do so while defining a controller or in their definition menu (Devices > Auxiliary Outputs)

## Quick Viewer


The Quick Report Viewer program allows operators to view previously saved reports without having to start EntraPass. It is used to view / display / load reports that were previously saved (in a.QRP format) during a print preview or Quick reports. For details on requesting and generating reports, see *"Reports" on page 431*.

This program is useful when EntraPass is off-line and when a report must be displayed for specific purposes.

- 1 From the Windows® task bar, click Start > Programs > EntraPass > Workstation/Server >Quick Viewer.









- 2 Click the Open button to open a report. The system displays the Open window:



- 3 By default, when a report is saved in a QRP format, the system automatically saves it in "My Documents" folder. If you have saved the report in another folder you have to browse to the folder to select the report.

- 4 Click **Open** to preview the report. Once you have selected the requested report, the system will display your report:
- 5 Use the toolbar buttons to preview the report:

Button	Description
	Use the <b>Zoom out</b> button to zoom out the report view.
	Use the <b>Zoom In</b> button to display details (view closer).
	Use <b>Previous Page</b> and <b>Next Page</b> buttons to change pages.
	Use the <b>Open</b> button to open a report located in any folder on your computer.
	Use the <b>Print</b> button to print the report. There will be no printer setup dialog box, the report will automatically print, to cancel the printing, click <b>Cancel</b> .
	Use the <b>Quit</b> button to quit the application.

## PING Diagnostic


This stand-alone program is used to diagnose network intermittent related problems and/or to determine whether a specific IP address is accessible.

It works by sending a packet (block) to the specified address and waiting for a reply. The PING diagnostic program is used primarily to troubleshoot Internet connections.



***NOTE:** If you want this option to be available, you have to select the "Allow diagnostic on network" field when defining the server parameters. For more information, see "The EntraPass Server Module" on page 499.*

- 1 From the Windows® Start menu, click Start > Programs > EntraPass Global > Workstation/Server PING Diagnostic.



- 2 Select **Server**, **Workstation** or **Redundant Server** depending on which station you want to operate.
- 3 Select the **Block size** from the drop-down list. This field is used to select the amount of data that will be sent. Selections vary from 1KB to 1024KB (1MB).
- 4 In the **TCP/IP address** field, enter IP address of the computer you want to test the communication link.



***NOTE:** See your Network Administrator for the required TCP-IP address.*

- 5 When you have entered the TCP/IP address, click the Test button to execute the command. The information will be sent 16 times. The system displays the number of bytes sent and the number of bytes received and the delay (in milliseconds).



***NOTE:** The delay between attempts should be similar, except for the first attempt which could be longer than the others. If you do not have a response, the message will be displayed in the following format: Sent(block) Bytes, No Answer (1717)*



---

## Workstation—Configuration Program

This utility program is useful when a workstation or gateway needs to be configured. It contains all the menus and features necessary to configure a system with event display, desktops, manual operations or reports.

The system installer can configure all workstations directly from this program without having to go from workstation to workstation.

Start the Workstation config system utility from Windows® start menu Start > Programs > Entrapass Global > Server > Workstation for Configuration. This program can also be launched from a shortcut on the desktop.

When using this option, you must first create the operators and security levels (System menu), then define the gateway, sites, controllers (Devices menu).



**NOTE:** For more information see "Software Installation" on page 7.

## KL-8000 Database Converter Program

The database converter is a program designed to extract a KL-8000 system setup, and transfer this information into the EntraPass Global Edition system. This process will override the information related to the workstation (Gateways, Sites, Controllers, Doors, Relays, Inputs, Outputs, Access levels, Alarm systems, Areas, Controller groups, Door groups, Input groups, Relay groups, Event relays, Floors, Floor groups and Guard tours).

The remaining database setup will be appended to the system wide database, but will only reflect the current workstation.


### Requirements:

- The workstation must be registered with the EntraPass Global Edition Server, in order to proceed with conversion,
- The same workstation must also have a copy of all files contained in the KL-8000's "DAT" directory,
- For security reasons, it is also necessary to have an unlimited access to the KL-8000, using a valid operator number and password. A "Master" level is also required when login at the EntraPass Global Edition System,
- All workstations connected to the EntraPass Global Edition System should be disconnected while converting the database. Option Z-Z (Workstation disconnect) should be used if the KL-8000 workstation is running as well.
- The KL-8000 version 5.7P.


### Preparation:

- 1 Create the directory and sub-directory called "KL8000\DAT" on the computer where the converted files will be installed and copy the.DAT files into the directory you have just created,
- 2 You will need a Server for the conversion.
- 3 Shutdown the Server. Install the EntraPass Global Edition Server using the proper serial number.
- 4 Start the Server.
- 5 Install the Workstation or Workstation & Gateway on the computer where the conversion will be performed using the proper serial number.
- 6 Register the Workstation or Workstation & Gateway to the Server.
- 7 Start-up the database converter. From the Windows task bar, select Start > Programs > EntraPass Global > Server > KL-8000 Database converter.
- 8 Select the directory where the "KL8000\DAT" files are located and click on OK.
- 9 Typically, the directory used for the KL-8000 database is "C:\KL8000\DAT". However, if the KL-8000 was installed in a different directory, the system will enable the user to browse through the various drives and directories of the system.


- 10 You can also browse the system for another drive, in order to find the KL-8000 database.



- 11 Enter the login user name and passwords for both systems. Prior starting conversion, it is necessary to login as a valid operator for both KL-8000 and EntraPass Network systems. The operator must also have a “Master” level.  
(Ex: KL8000 Operator = 01 Password = KL-8000 EntraPass Global Edition Operator = KANTECH Password = KANTECH)




- 12 Select the Workstation name were the converter will create the “Gateway”.



- 13 Select the options.
- **Compress Schedules**—If any logical components have the same programming, the duplicate components will be replaced by the first components converted. For example, if you have a schedule named “Employees” programmed “Monday to Friday from 9H00 to 17H00 and another schedule named “Employee1” programmed exactly the same way as the schedule “Employees”, then all depending which schedule will get converted first will replace the other schedule.
  - **Convert event parameters**—When selected, the system will convert the event parameters of the gateway in order to keep the same event parameter settings as the KL-8000. This means that the events parameters of the NCC 8000 will remain only for this gateway. If you

don't select this option, you will have to manually define the event parameters. For more information. For more information see *"Operations"* on page 223




14 Click on "Start".

### Progress Information:

Two circles display the progress information (percentage). The inner circle displays the progress for the component being converted.

The outer circle displays the progress for the overall conversion. The conversion will be completed when the two circles will be complete.



**Legend**—During conversion, information on the progress of the component is available through the Component status. There are 5 different status possibilities:

- **Available (dark blue)**—The component was not yet requested for conversion. In order to request components, these conditions must be fulfilled: Correct KL-8000 Database directory selected; Logged into the 2 systems; The start button pressed.


- **Requested (pale blue)**—Components, which were not yet converted, are “requested”. In order to link information, some components can be requested twice by the system.
- **Running (yellow)**—Indicates the current component being converted.
- **Error (red)**—If a component is marked with an error symbol after conversion, it is important to verify each link. Information might be missing from the EntraPass Network System, due to a KL-8000 Database corruption or unsuspected error during conversion.
- **Done (green)**—Indicates the component was converted properly.

## Global Updater Program


The Global Updater is used to convert a Global database from version 1 to 3. The latest features are installed to the database after conversion takes place. As well, devices may be redefined as either workstation or gateway.

Preparation:


- Ensure the version 3 database is installed on the same computer as version 1.
  - Start, register, and close the version 3 database.
- 1 Start program from C:\Program Files\Kantech\Server\_GE\Bin\GlobalUpdater.exe



- 2 Verify paths to previous installation and new installation folder conform to EntraPass Global Updater window and click on **Proceed** button.



- 3 Create an output file listing of all system procedures on Output filename window by clicking Yes. (Recommended).




- 4 Choose the new serial-numbered device, either Gateway or Workstation, which will take on information from old device.



**NOTE:** Procedure will repeat itself for each serial-numbered definition of Workstation/Gateway found in the system.

**NOTE:** Important gateway related information may be lost if conversion is made to new Workstation from old Workstation/Gateway definition. Be sure to note gateway information when making this type of update.

- 5 Set the reader type.



- 6 Click OK to close the Reader type window.

## Migration Utility

### To Migrate EntraPass Global Edition Version 1 to Version 3

EntraPass offers the ability to upgrade your EntraPass Global Edition software from Version 1 to Version 3. You will need the installation key (found on the installation CD) and the registration code provided by Kantech.

Before you perform the migration, you must take a backup of your EntraPass database. For details on backing up your database, see *"Backups" on page 505*.

You will then install EntraPass Global Edition Version 3 and register it. For information on installing EntraPass, see *"System Installation" on page 12*.

Then, you will need to migrate the server database from version 1 to version 3 using the **Migration from EntraPass Global Edition V1** utility.

The last step will be to install the updated versions of your system components (Vocabulary Editor, the Oracle/MS-SQL HR interface, etc.). For details on updating the system components, see *"To Add Optional Components/Features" on page 11*.



**NOTE:** Please register the software before running the Migration utility. For details about the Migration Utility, refer to the Application Note DN1541.

### Migrating the Version 1 Server Database

- 1 From the Windows Start menu, go to Programs > EntraPass Global Edition > Server > Migration from EntraPass Global Edition V1.
  - If EntraPass Global Edition Version 1 and EntraPass Global Edition Version 3 are installed on the same computer: the software will automatically locate the previously installed server database; go to step 4.
  - If EntraPass Global Edition Version 1 and EntraPass Global Edition Version 3 are installed on different computers, the Select a directory window appears. You have to manually select the server database; perform step 2 and 3.
- 2 From the Select a directory window, click the **Network** button to locate the Version 1 EpServer.exe file. This exe file is located in the Bin folder of the EntraPass Global Edition Version 1.
- 3 Once you locate the EpServer.exe file, select it, then click **Open**: the Open button is enabled only when you select the installation folder. Once you select the EpServer.exe file, the **Proceed** button is enabled.
- 4 Click the **Proceed** button to launch the migration. The system displays an output file name that will be used as a log file for storing all the migration transactions. It is recommended to accept its default name and location.
- 5 Once you have accepted the default name for the output file, click the **Yes** button to launch the migration.



**NOTE:** The migration operation may take several minutes depending on the size of the source database or your computer configuration. During the database migration, the system displays information related to the operation. At the end, the system displays a list identifying components that have been migrated from Version 1 to Version 3.



- 6 Click OK to close the application.
  - 7 Restart the computer.
  - 8 Start EntraPass Global Edition Version 3 Server to re-install previous system components.
- After the installation, all system components from Version 1 (and their new installation codes) are displayed in the Workstation Registration window. Using the new installation code, you can upgrade your system by re-installing the components on the appropriate computers.



***NOTE:** All EntraPass Global Edition applications that are not upgraded to Version 3 will not communicate with the server. To upgrade other EntraPass Version 1 applications such as the Vocabulary Editor or SmartLink, refer to the Application Note DN1541.*

## The Gateway Interface

A gateway is a software interface that is used to convert the information received from the sites/ gateway (which receives information from the controller loops) to the server.

The server and the gateway communicate in the same protocol while the controllers and the site/ gateway communicate in the same protocol. Usually, the Gateway software are installed on the same computer. Sometimes, the Gateway can be installed on an external computer which is linked to another computer equipped with the Gateway software interface (that communicates the information to the server). The access control system is in fact composed of two different systems:


- Computers are used to enter information and access the database.
- Door controllers (grouped in loops) are managed through the Gateway.

The System menu lets you login/logout and reload the Gateway.

### To Start the Gateway

You can start the Workstation and the Gateway, the workstation only or just the Gateway only interface.

- 1 Click on Start > Programs > EntraPass (software) > Gateway > Gateway. This is when you only have the "Gateway Only" software installed. You may also click Start > Programs > EntraPass (software) > Workstation & Gateway > Gateway (when you have the Workstation & Gateway software installed).



### To Reload the Gateway

This option is used to reload information to a specific Gateway. It is used to refresh all or some parameters relative to the network. Information included in the Server is downloaded to each gateway, then the gateways reload the controllers.

When you perform this operation, the controllers will be working on their own (fail-soft mode) and the gateway will no longer be able to transfer information such as global functions.

Reloading data insures that the communicating gateway has the latest information. However, the information of a connected gateway is updated after each system modification.

The **Help** menu provides context-sensitive help on the interface.

The status bar indicates the system's date and time, the name of the operator who is currently logged, the status (could be any message such as running, etc.) and the IP address of the

EntraPass server (the green square indicates the server state, if yellow then it is the Redundancy Server).

- Configuration data received from the server: The progress bar indicates that configuration data is being received from the EntraPass Server. Configuration data can be information such as “Card modifications, etc.”.
- Data requested by workstation: The progress bar indicates that data is being requested from the EntraPass Workstations of the system (could be any). Data can be information such as “Status Requests, etc.”.
- Messages generated by the Gateway: The progress bar indicates that messages are generated from the Gateway. These messages can be: Access granted, input in alarm, Access denied—bad access level, etc.
- Configuration data sent to the controllers: The progress bar indicates that configuration data (which was received by the EntraPass Server) is being forwarded to the controllers.
- The gateway will send information to the controllers.



**NOTE:** *The progress bars indicate data transfers being executed and that information is being sent back and forth.*

## CardGateway Program

The CardGateway software is a program that creates a mirror copy of the Entrapass card database in the MS-SQL or ORACLE Server. This interface allows user to modify, add or obtain card-related information, all this in real-time, from the MS-SQL or ORACLE Client version. The mirror card database, which contains cardholder information, will be updated automatically as soon as new information is available in the Entrapass card database.

Depending on the client interface that is used (Entrapass or MS-SQL/ORACLE Client) to add or modify a card, the CardGateway software ensures that the modifications is conveyed to the Entrapass Server's database through the Mirror Database and vice versa and that the information, whatever its origin, is updated in both databases. (For more information, see the "exchange data process" diagram).

### To Install the CardGateway

It is recommended to install the CardGateway software on a computer where use is at its minimum, since the data exchange process is processed through the computer running the software.

Depending on the size of the database and the number of transactions, the updating process may require more memory. Furthermore, the computer on which the software will be installed must meet the same requirements as an ordinary Entrapass Workstation (see *"System Requirements" on page 8*).

- 1 Install the CardGateway program by following the installation procedure, see *"System Installation" on page 12* (use the appropriate installation code).
- 2 You MUST install MS-SQL/ORACLE client on the same computer as the CardGateway. You can also install the CardGateway on a computer where an existing MS-SQL/ORACLE client software is already installed,
- 3 To complete the installation, you must create the database in the MS-SQL/ORACLE Server. To do so, you can **manually** create the database or you can use the automatic integrated function to **automatically** create the database in the Server (see CardGateway Configuration below).


### To Configure the CardGateway

For more information on how to configure the CardGateway application in order to create the database automatically or to manually create the database, user name and password in MS-SQL / ORACLE Server, see *"To Create Server Databases Manually" on page 73*.


To Start the Program

- 1 From the Windows® tool bar, click on Start > Program > EntraPass (software) > CardGateway > CardGateway. The display language depends on the settings of the operator that was previously logged in this workstation.

Once you have performed the above steps, the software will try to establish a link with the server. During the process, the following screen will be displayed:



- 2 When the application connects to the MS-SQL/ORACLE server for the first time, it creates 5 tables in the KANCARD database named: tbCard, tbCardType, tbCardAccessGroup, tbTransactionIn and tbTransactionOut.




**NOTE:** Information or data that is being transferred from the EntraPass primary server to the CardGateway database will be compressed for faster transfer.

The first three tables (tbCard, tbCardType, tbCardAccessGroup) are filled at the first connection with all the Cards, Card Access Groups and Card Types. Writing in these tables is not necessary because the CardGateway periodically updates them. They should only be read.

The tbTransactionIn table is used to create, modify or delete cards from the MS-SQL/ORACLE server. The CardGateway scans this table periodically. When it finds a card, it creates, modifies or delete this card in the EntraPass server depending on the value of the State column of the tbTransactionIn record (a state value of 0 will create or modify the card and a state value of 1 will delete the card). Once this is done, the CardGateway will delete the card from the tbTransactionIn table.

The tbTransactionOut table contains the history of all creations, modifications and deletions of cards (since the start of the CardGateway). All successful creations, modifications or deletions of a card done by the CardGateway after reading this card in the tbTransactionIn table will also be found in the tbTransactionOut table.

- Then, the main application screen will be displayed:



### System configuration

- Server name**—This field indicates the name of the SQL or Oracle Server as defined in the workstation definition menu.
- EntraPass State**—This field indicates the real-time status of the EntraPass server. In case of failure, messages would appear here.

### Database

- Database State**—This field indicates the real-time status of the card database.

### Transaction Report


- Data received from the EntraPass Server**—When card-related information are modified within the EntraPass server (database), the information is also forwarded to the CardGateway database where the SQL or Oracle Server will collect the information. This field indicates the number of transactions that were executed and sent to the card database.
- Data updated on SQL Server**—
- Nb of cards sent to EntraPass Server**—This field indicates the number of cards that were added or modified in the SQL or Oracle client application and that were sent to the EntraPass Server's database.

### Transactions

The registry contains the details of the transactions that are processed by the CardGateway interface. You must login to access this screen.

Diagram

The diagram below shows the “DATA EXCHANGE PROCESS” between the CardGateway and the MS-SQL / ORACLE database.



## The SmartLink Interface

The SmartLink interface allow a user to define a message and format type that may be sent on the second COM port or to a disk file. The following pages explain how to build a character string that can be sent through the SmartLink.

Using the SmartLink feature, you can interface to just about any intelligent device such as video matrix switchers, paging systems, etc.

To do this, a RS-232 link is cabled between one of the EntraPass Workstation and the external device. The necessary command strings and protocols can be easily edited on site to fit just about any job.

The SmartLink simplifies the interfacing to "alien" intelligent devices because it provides the system installer all the tools necessary to build and maintain the actual interface without having to purchase "special" drivers from Kantech.

In communications, a link is a line or channel over which data is transmitted. The transmission of data from one computer to another, or from one device to another. A communications device, therefore, is any machine that assists data transmission. For example, modems, cables, and ports are all communications devices.

### Required Material and Installation

- A computer that meets the same requirements as an EntraPass Workstation (*see "System Requirements" on page 8*),
  - Installation CD for the SmartLink application including the serial number.
- 1 Create the new application in the Workstation Registration menu, *see "System Requirements" on page 8* for more information on how to create new applications,
  - 2 Install the SmartLink application on the computer (*see "System Installation" on page 12*).
  - 3 Once the SmartLink application is installed, you need to configure the SmartLink application,
  - 4 If you are using the Message Mode, you will need to create instructions using special macro-commands. For more information on how to create instructions, *see "Instructions Definition" on page 379*.

## To Configure the SmartLink Application

The configuration is done on an ordinary EntraPass workstation or any EntraPass Workstation for configuration (found on the same computer as the Server software).

Depending on the modes that will be used for the SmartLink (Messages or Commands), you must program the workstation accordingly.

## Starting the SmartLink Application

- 1 From the computer where the SmartLink application is installed, click on the Windows® task bar and select Start >Program >Kantech >SmartLink. The SmartLink application will be started. Refer to the **SmartLink Specifications Manual** for more information on the SmartLink Application.



# Network Consumption

The consumption of network time can be divided in many categories:

## Messages: •

A message originating from a Server can generate:

- Minimum: 128 bytes + (# workstations, SmartLinks \* 32 bytes)
- Maximum: 128 bytes + (# workstations \* 416 bytes)
- A message originating from a Workstation, Gateway, etc. generates 56 bytes.
- Using pictures (cardholders) on a system will increase the network traffic. The increase will mainly depend on the number of workstations that are using this option, the number of cards in the system as well as the number of transactions per card.

## Reloads:

Since reloads are sporadic actions that have few impacts on the network, it is possible to break down the reload consumption of the Gateway into commonly used features.

Features	Bytes	Details
System	256	-
Controllers	# * 32	Where # = 0 to 128
Doors	# * 32	Where # = 0 to 256
Relays	# * 16	Where # = 0 to 2048
Inputs	# * 16	Where # = 0 to 2048
Auxiliary outputs	# * 16	Where # = 0 to 512
Areas	# * 32	Where # = 0 to 100
Alarm partitions	# * 64	Where # = 0 to 100
Controller groups	# * 32	Where # = 0 to 100
Door groups	# * 80	Where # = 0 to 100
Relay groups	# * 320	Where # = 0 to 100
Input groups	# * 320	Where # = 0 to 100
Access level groups	# * 80	Where # = 0 to 100
Access levels	# * 640	Where # = 0 to 250
Schedules	# * 64	Where # = 0 to 100
Cards	# * 16	Where # = 0 to 32,000
Holidays	# * 64	-
Event parameters	# * 16	Where # = 0 to 50,000

## Manual Operations:

There are 2 types of manual operations:

- Operations that are used to execute functions such as unlocking a door. These operations, which are occasionally requested, usually involve an insignificant amount of information.
- Operations which are used to recuperate a component or request a card list. Even though these operations can be frequently requested, they usually involve an insignificant amount of information. For example, requesting a door status only requires 16 bytes OUT and 64 bytes IN.

---

## Chapter 17 • Animated Icons

Animated icons indicate the status of physical or logical components in the windows of Entrapass software. They represent the component status in real time and simulate a movement by displaying a series of pictures associated with the component.

If a particular component status is difficult to identify, use this section to identify it.

## Alarm Systems

Alarm systems' icons indicate the status of an alarm system within the Graphic desktop (Desktop > Graphic desktop) or in the "Operation" window.

### Alarm system is in alarm

This animated icon appears when the alarm system is in alarm. It is displayed in:

- the Alarm message box when an acknowledgement is required.
- the "Operation" window
- the Desktop > Graphic desktop.

### Alarm system is armed



This animated icon appears when the alarm system is armed. It is displayed in:

- the Operation window
- the Desktop > Graphic desktop.

### Alarm system is armed and in alarm



This animated icon appears when the alarm system is armed and a surveillance area is in alarm. It is displayed in:

- the Operation window
- the Desktop > Graphic desktop.

### Alarm system is in arming request delay



This animated icon appears when the alarm system is in the "arming request" delay (waiting for confirmation with the arming request input button). It is displayed in:

- the "Operation" window
- the Desktop > Graphic desktop.

### Alarm system is disarmed



This animated icon appears when the alarm system is disarmed. It is displayed in:

- the "Operation" window.
- the Desktop > Graphic desktop.

### Alarm system is in entry delay



This animated icon appears when the alarm system is in “entry” delay. It is displayed in:

- the “Operation” window.
- the Desktop > Graphic desktop.

### Alarm system is in “Exit” delay



This animated icon appears when the alarm system is in “exit” delay. It is displayed in:

- the “Manual Operation” window.
- the Desktop > Graphic desktop.

### Alarm system status is not yet known



This animated icon appears when the status of the alarm system is unknown. It is displayed in:

- the “Graphic” window (the Desktop > Graphic desktop) when the status of the alarm system is unknown.

### Alarm system is in “Postpone” mode



This animated icon appears when the alarm system is in “postpone” mode. Once this delay is over, the system will initiate the exit delay and arm again (if the “no disarm” schedule is still valid). It is displayed in:

- the Operation window.
- the “Graphic” window (the Desktop > Graphic desktop).

## Controllers

Controller animated icons indicate the status of a door controller in the graphic window (Desktop > Graphic desktop) or in the “Operation” window.

### Status unknown



Appears when the EntraPass application has not received the component' status after four (4) attempts. It is displayed in:

- the Operation window (alarms, areas, guard tours, door, elevator door, relay, input, reload data)
- or the Desktop > Graphic desktop.

### Controller AC failure



Appears when the controller is in AC failure. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset Controller AC failure and Tamper Switch in “alarm”



Appears when the controller is in AC failure and the tamper switch is in alarm. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset

### Controller is not communicating



Appears when the controller is not communicating. It is displayed in:

- the “Operation” — “Area”, “Guard Tour” and “Controller Reset” windows.
- the Desktop > Graphic desktop.

### Controller communication is regular (no problem)



Appears when the controller is communicating and the communication is regular. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset.

### Controller status is not yet known



Appears when the status of the controller is not yet known. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)

### Controller is in “Reset” and AC failure



Appears when the controller is in “reset mode” and in “AC failure”. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset.

### Controller is in “Reset”, “AC failure” and “Tamper in alarm”



Appears when the controller is in “reset mode”, in “AC failure” and the tamper is in alarm. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset

### Controller is in reset and tamper in alarm



Appears when the controller is in “reset mode” and the tamper is in alarm. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset.


### Controller tamper in alarm



Appears when the controller tamper is in alarm. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset when the controller tamper is in alarm.

### Controller reloading firmware



Appears when the controller is reloading firmware. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Controller Reset.

## Doors

Icons representing a door state indicate the status of door within the graphic window (from the desktop) or within the “Operation” window.

### Door forced open



This animated icon appears when the door is opened and that no access granted nor request to exit was permitted. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door, Elevator Door

### Door forced open (reader disabled)



This animated icon appears when the door is opened and that no access granted nor request to exit was permitted and the reader is disabled. It is displayed in:

- the “Graphic” window (desktop—graphic)
- the Operation > Door, Elevator Door

### Door closed and locked



This animated icon appears when the door is closed and locked. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door

### Door closed and locked (reader disabled)



This animated icon appears when the door closed and locked and that the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door.

### Door status unknown



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the status of the door is not yet known.



### Door open too long



This animated icon appears when the door is opened more than the permitted delay set in “open time”. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door, Elevator door.

### Door open too long (reader disabled)



This animated icon appears when the door is opened more than the permitted delay set in “open time” and that the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door, Elevator door.

### Door open and unlocked manually



This animated icon appears when the door is opened and it was unlocked by an operator. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.

### Door open and unlocked manually (reader disabled)



This animated icon appears when the door is opened and it was unlocked by an operator and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.

### Door is opened and unlocked by schedule



This animated icon appears when the door is opened and it was unlocked by a schedule. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.


### Door is opened and unlocked by schedule (reader disabled)



This animated icon appears when the door is opened, and it was unlocked by a schedule and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.


### Door pre-alarm on open too long



This animated icon appears when the door is opened more than half the time permitted delay set in “open time”. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.

### Door pre-alarm on open too long (reader disabled)



This animated icon appears when the door is opened more than half the time permitted delay set in “open time” and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.

### Door still opened schedule invalid



This animated icon appears when the door is opened and the unlock schedule is invalid. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/Elevator door.

### Door still opened schedule invalid (reader disabled)



This animated icon appears when the door is opened and the unlock schedule is invalid and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/ Elevator door.

### Door unlocked by an operator



This animated icon appears when the door is unlocked by an operator (manually). It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door > Elevator door.

**Door unlocked by an operator (reader disabled)**

This animated icon appears when the door is unlocked by an operator (manually) and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/Elevator door.

**Door unlocked by a schedule**

This animated icon appears when the door is unlocked by a schedule. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/Elevator door.

**Door unlocked by a schedule (reader disabled)**

This animated icon appears when the door is unlocked by a schedule and the reader is disabled. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/Elevator door.

**Elevator door unlocked and closed**

This animated icon appears when the elevator door is closed and unlocked. It is displayed in:

- the Graphic desktop (Desktop > Graphic desktop window)
- the Operation > Door/Elevator door.

## Relays

Relays icons indicate the status of a relay within the graphic window (from the desktop) or within the “Operation” window.

### Relay activated by alarm system in alarm



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is triggered by an alarm system in alarm.
- the Operation > Relay when the relay is triggered by an alarm system in alarm.

### Relay activated by alarm system function



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is triggered by a function of an alarm system.
- the Operation > Relay when the relay is triggered by a function of an alarm system.

### Relay activated by alarm system delay



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is triggered by the delay of an alarm system.
- the Operation > Relay when the relay is triggered by the delay of an alarm system.

### Relay activated by an event



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is triggered by an event.
- the Operation > Relay when the relay is triggered by an event.

### Relay temporarily activated by an event



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is temporarily activated by an event.
- the Operation > Relay when the relay is temporarily activated by an event.

### Relay activated by an input



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is triggered by an input.
- the Operation > Relay when the relay is triggered by an input.

### Relay temporarily activated by an input



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is temporarily activated by an input.
- the Operation > Relay when the relay is temporarily activated by an input.

### Relay activated by an operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is activated by an operator.
- the Operation > Relay when the relay is activated by an operator.

### Relay temporarily activated by an operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is temporarily activated by an operator.
- the Operation > Relay when the relay is temporarily activated by an operator.

### Relay activated by a schedule



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is activated by a schedule.
- the Operation > Relay when the relay is activated by a schedule.

### Relay deactivated



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the relay is not activated.
- the Operation > Relay when the relay is not activated.

---

### Relay status unknown



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the status of the relay is not yet known.

## Inputs

This section is used to indicate the status of an input within the graphic window (from the desktop) or within the “Operation” window.

### Input in alarm—Not supervised



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in alarm and the monitoring schedule is invalid.
- the Operation > Input when the input is in alarm and the monitoring schedule is invalid.

### Input in alarm—Shunted by operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in alarm and it is shunted by an operator.
- the Operation > Input when the input is in alarm and it is shunted by an operator.

### Input in alarm—Supervised



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in alarm and the monitoring schedule is valid.
- the Operation > Input when the input is in alarm and the monitoring schedule is valid.

### Input in alarm—Supervised by operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in alarm and it is supervised by an operator (continuous supervision).
- the Operation > Input when the input is in alarm and it is supervised by an operator (continuous supervision).

### Input OK—Not supervised



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in normal condition and the monitoring schedule is invalid.

- the Operation > Input when the input is in normal condition and the monitoring schedule is invalid.

### Input OK—Shunted by operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in normal condition and it is shunted by an operator.
- the Operation > Input when the input is in normal condition and it is shunted by an operator.

### Input OK—Supervised



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in normal condition and the monitoring schedule is valid.
- the Operation > Input when the input is in normal condition and the monitoring schedule is valid.

### Input OK—Supervised by operator



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the input is in normal condition and it is supervised by an operator (continuous supervision).
- the Operation > Input when the input is in normal condition and it is supervised by an operator (continuous supervision).

### Input status unknown



This animated icon appears in the “Graphic” desktop when the status of the input is not yet known.



## Sites and Gateways

These icons indicate the status of a site, or gateway within the graphic window (from the desktop) or within the “Operation” window.

**Controller Site:**


### Site status is not yet known



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the status of the controller site is not yet known.

### Controller site connected



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the site is connected and communication is OK.
- the Operation > Reload data when the site is connected and communication is OK.

### Controller site connected and in “Reload Data”



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the site is connected and is in “reload data” state.
- the Operation > Reload data when the site is connected and is in “reload data” state.

### Controller site—Communication Failure




This animated icon appears in:

- the “Graphic” window (Desktop—graphic) when the site is disconnected and there is a communication failure.
- the Operation > Reload data when the site is disconnected and there is a communication failure.

**Gateway:**

### Gateway—Communication Failure



This animated icon appears in:

- the “Operation” (door, elevator door, relay, input, reload gateway) window when the gateway is in communication failure.

- the “Graphic” window (desktop—graphic) when the gateway is in communication failure.

### Gateway in “Reload Data”



This animated icon appears in:

- the “Graphic” window (Desktop—graphic) when the gateway is being reloaded.
- the Operation > (door, elevator door, relay, input, reload gateway) when the gateway is being reloaded.

### Gateway—Communication Failure during Reload Data



This animated icon appears in:

- the “Operation” (reload data gateway) window when the gateway loses communication during a reload data operation.
- the “Graphic” window (desktop—graphic) when the gateway loses communication during a reload data operation.


### Gateway communication is regular (no problem)



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the gateway is communicating and the communication is regular.
- the Operation > Reload data gateway, communication is regular.

### Gateway Trouble



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the gateway is not communicating.
- the Operation > Reload data gateway, the gateway is not communicating.

### Gateway Trouble when Reloading



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the gateway is not communicating.
- the Operation > Reload data gateway is not communicating with the gateway during a reload data operation.

Gateway (Gateway Software Interface):

### Gateway OK—communicating



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the gateway is communicating.
- the Operation > Reload data when the gateway is communicating.

### Gateway in “Reload Data”



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the gateway is being reloaded.
- the Operation > Reload data when the gateway is being reloaded.

### Gateway—Communication Failure



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when gateway is not communicating.
- the Operation > Reload data when the gateway is not communicating.

### Gateway—Reload KT-NCC Firmware



This animated icon appears in

- the “Graphic” window (desktop—graphic) when the system is performing an automatic upgrade of the KT-NCC firmware.
- the “Operation” when the system is performing an automatic upgrade of the KT-NCC firmware.

## EntraPass Application

### Application status is not yet known



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the status of the application is not yet known.

### Application attempts communication



This animated icon appears in:

- the startup window when the workstation attempts to communicate with the server.

### Application—Communication Failure



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the workstation is in communication failure.
- the “Operation” window (alarm, area, guard tour, door, elevator door, relay, input, reload gateway) when the workstation is in communication failure.

## Others

### Database Initialization



This animated icon appears in:

- the startup window when the workstation initializes the database.

### Data not available



This animated icon is used to indicate a transient stage. This could indicate that the requested information is not currently available.

### No state available



This animated icon is used to indicate a transient stage. This could indicate that the requested component status is not currently available.

### Output status is not yet known



This animated icon appears in:

- the “Graphic” window (desktop—graphic) when the status of the output is not yet known.

### Status unknown



This animated icon appears in:

- the “Operation” (alarms, areas, guard tours, door, elevator door, relay, input, reload) window when the workstation has not received the component' status after four (4) attempts.
- the “Graphic” window (desktop—graphic) when the workstation has not received the component' status after four (4) attempts.

### Error in process



This animated icon appears in:

- the “Operation” (alarms, areas, guard tours, door, elevator door, relay, input, reload data) window when a specific error is detected.
- the “Graphic” window (desktop—graphic) when a specific error is detected.

### Undefined Component



This animated icon appears in:

- the “Operation” window (alarm, areas, guard tour, door, elevator door, relay, input, reload data gateway) when the component does not exist.
- the “Graphic” window (desktop—graphic) when the component does not exist.



---

# Appendix A • Entrapass Bandwidth

This chapter was prepared to inform users about the bandwidth usage for an Entrapass system on a TCP/IP network. Tables detailing the number of bytes used for each type of operation and components are available later on in this document.

Operations such as saving and modifying data will be described in details. You must, however, take into account that each operation, such as sending messages to the server and to workstations, can generate additional traffic.

## Transactions between Entrapass Applications

Sixteen bytes must be added for each transaction that takes place between Entrapass applications. Each of these transactions can contain up to 4000 bytes of data.

For example, when uploading cards, you can send up to 125 user/cards per packets to a gateway instead of sending each card individually. (See the **Data Reloading - Global Gateway** table)

### Communication Protocols

In order to get a fair evaluation of the quantity of data used, you must take into account the minimum number of bytes required for each protocol used by the Entrapass system.

#### TCP/IP Protocol

The TCP/IP protocol requires a minimum of 54 bytes for each packet sent on the network. By default, the maximum IP packet size is 1500 bytes (according to the RFC 894 standard).

TCP/IP Protocol	Data
54 bytes	1 - 1460 bytes

#### Serial Communications

For serial communications between the gateway and the controllers, you must add a minimum of 4 bytes per packet of data sent on the network.

Serial Communications	Data
4 bytes	1 - 255 bytes



## Communication between Workstation and Server

The majority of EntraPass operations are directed to the workstation to inform users about the system status. You must take into account that each type of operation will generate event traffic between the server and the workstation.

### Display of Events, Pictures and Graphics on the Workstations

The **Data Transmission between Workstation and Server** table details the number of bytes used when deploying data from the server to the workstation.

**Important:** Pictures and graphical components are transferred only once to the workstations unless they are modified.

Data Transmission Between Workstation and Server		
Component Types	Number of Bytes Using 1 Language	Number of Bytes Using 2 Languages
Per message	330	534
Per picture		
Information	100	100
Image	+29 K (once) **	+29 K (once) **
Per alarm	1286	2206
Per graphic		
Information	207 (once)	207 (once)
Item	53 (once)	53 (once)
Image	+ 100k (once)	+ 100k (once)
Per instruction	250	512

\*\* Add +/- 29 K per image and per signature assigned to each card.


## Component Status Query

Two types of queries can be performed: per component or per list. The **Component Status Query** table details the traffic generated during a status query from a workstation.

Component Status Query	
Query Type	Number of Bytes
Component status query	32
Component status reply	204
List query	32
List reply	152

## Manual Operations

During manual operation queries, data is sent from the workstations to the server at 68 bytes per component, and then is deployed from the server to the gateway. At that point, the controllers send an 8 bytes reply per activate component.



## Saving and Modifying Data

### Between Workstation and Server

When saving a component on a workstation, the saving value for this component must be calculated (see the following table). 39 bytes must also be added for each backup query to the server.

Data Backup		
Type of components	Number of Bytes	Number of Bytes per Sub-Items
Modification query	39	
Information for 1 access level	141	16
Information for 1 group of access level	141	8
Information for 1 id card	162	+ Image
Information for 1 card	991	104 + image + signature **
Information for 1 group of cards	140	8
Information for 1 group of access cards	139	104
Information for 1 visitor card	991	104 + image + signature **
Information for 1 controller	7231	13
Information for 1 group of controller	141	8
Information for 1 door	414	
Information for 1 group of doors	141	8
Information for 1 event parameter	74	
Information for 1 floor	136	
Information for 1 group of floors	141	13
Information for 1 graphic	207	53
Information for 1 gateway	7880	
Information for 1 holiday	146	
Information for 1 input	203	
Information for 1 group of inputs	141	8
Information for 1 instruction	1159	
Information for 1 messages filter	2195	12
Information for 1 Entrapass application	917	12

Data Backup		
Type of components	Number of Bytes	Number of Bytes per Sub-Items
Information for 1 security level	741	29
Information for 1 relay	163	
Information for 1 group of relays	141	8
Information for 1 report	4770	12
Information for 1 time and attendance report	4770	12
Information for 1 operator	17106	
Information for 1 auxiliary output	183	
Information for 1 schedule	185	
Information for 1 site	409	
Information for 1 video server	303	
Information for 1 video view	450	
Information for 1 video recording	169	
Information for 1 video trigger	335	
Information for 1 camera	3040	
Information for 1 type of card	140	
Information for 1 alarm system	311	
Information for 1 area	177	
Information for 1 guard tour	1155	
Information for 1 event relay	63	

**\*\* Add +/- 29 K per image and per signature assigned to each card.**

## Polling Between Server and Applications

Polling is bidirectional. On the one hand, each EntraPass application sends a query to the server every 15 seconds. On the other hand, the server sends a query every 30 seconds to all applications that are in communication.

From the mirror database, queries to the server are done every 5 seconds.

**NOTE:** Query delays vary according to message query and queries between the applications.

The following table indicates the average value of the bandwidth captures between EntraPass applications:

Measure of Bandwidth between Applications	
Applications	Bytes / Sec
Server / Workstation	26
Server / Corporate Gateway	26
Server / Global Gateway	26
Server / Mirror database	56
Server / SmartLink	26
SmartLink / SmartLoop	265

## Communication with Global Gateway (Reloading Data)

With EntraPass, it is possible to reload data at different levels: with controllers and with the gateway.

### With the Controller

The reload is performed during the system hard reset or during gateway reloading. When reloading a controller, the number of data transferred must be evaluated to include the data loaded by default such as system and controller information as well as date and time information (minimum of 106 bytes). Also, all components configured at the controllers must be included. (See the **Data Reload to Controllers** table.)


Data Reload to Controllers	
Components Types	Number of Bytes
Global system information	83
Per controller	16
Per floor definition	64
Per door	27
Per relay	6
Per input	14
Per output	15
Per EntraPass (KT100, 200, 300) card	8
Per EntraPass 32 bits card	8
Per EntraPass PIN 6 car. card	8
Per EntraPass BCD 16 car. Card	17
Per schedule	21
Access level (reload)	249
Access level (save)	3
Per floor group (reload)	249
Per floor group (save)	3
Par floor group mask	33
Per holiday	49
Per relay group	3
Per input group	3
Per reader driver	203

Data Reload to Controllers	
Components Types	Number of Bytes
Date / Time	7
Program download	130

With the Global Gateway

The gateway reload is done manually or during the gateway start up.  
During information reload between the server and the gateway, the amount of data transferred can be calculated according to the gateway type and the number of components configured in the system.

*NOTE: It must be taken into account that all site controllers connected to the gateway will reload automatically when the gateway is reloading.*



Data Reload – Corporate Gateway	
Components Types	Number of Bytes
General information	7028

Data Reload – Corporate Gateway	
Components Types	Number of Bytes
Information for 1 site	392
Information for 1 controller	1648
Information for 1 door	308
Information for 1 relay	32
Information for 1 input	68
Information for 1 auxiliary output	116
Information for 1 access level	528
Information for 1 schedule	36
Information for 1 holiday	16
Information for 1 floor	16
Information for 1 card	20 + 12* Number of sites
Information for 1 controller group	24
Information for 1 door group	28
Information for 1 relay group	84
Information for 1 input group	84
Information for 1 floor group	1080
Information for 1 access level group	52
Message	82
Query per component (on screen)	32
Reply per component (on screen)	204

Data Reload - Global Gateway	
Components Types	Number of Bytes
General information	4096
Information for 1 site	172
Information for 1 controller	1628
Information for 1 door and 1 access level	2188



Data Reload - Global Gateway	
Components Types	Number of Bytes
Information for 1 relay	28
Information for 1 input	72
Information for 1 auxiliary output	116
Information for 1 access level	16396
Information for 1 schedule	48
Information for 1 holiday	16
Information for 1 floor	12
Information for 1 card	76
Information for 1 controller group	144
Information for 1 door group	272
Information for 1 relay group	2064
Information for 1 input group	2064
Information for 1 floor group	1080
Information for 1 access level group	44
Information for an alarm system	244
Information for an area	52
Information for a guard tour	1220

**Example of data reloads:**

For a system with a Corporate Gateway with 2 sites of 10 controllers each, 200 cards, 12 schedules and 20 access levels:

To reload the Corporate Gateway:

General information	= 7028 bytes
Sites	= 392 x 2 = 784 bytes
Controllers	= 20 x 1648 = 32960 bytes
Doors	= 40 x 308 = 12320 bytes
Relays	= 2 x 32 = 64 bytes
Inputs	= 8 x 68 = 544 bytes
Outputs	= 2 x 116 = 232 bytes
Access level	= 20 x 528 = 10560 bytes

Schedules	= 12 x 36 = 432 bytes
Cards	= 20 + (12 x 2) = 200 cards x 44 bytes = 8800 bytes
Total	= 73 724 bytes
To reload controllers:	
Global system information	= 83 bytes
Date/Time	= 7 bytes
Controller	= 16 bytes
Door	= 2 x 27 = 54 bytes
Input	= 8 x 14 = 112 bytes
Relays	= 2 x 6 = 12 bytes
Output	= 2 x 15 = 30 bytes
Card	= 200 x 8 = 1600 bytes
Schedule	= 12 x 21 = 252 bytes
Access level	= 248 bytes
Total= 2414 bytes per controller x 20 = 48280 bytes	

*NOTE: Serial communication protocols and TCP/IP are not included in the calculation.*

## Reloading Firmware to Controllers

Controllers' firmware (KT-100 or KT-300) size is 65 K bytes. During the reload operation, the firmware is transferred from the workstation to the gateway and is then deployed to the selected controllers. It must also be taken into account that the controllers will start reloading data following the firmware reload.

Reloading is done one controller at the time, per packets of 134 bytes (130 for reload and 4 for the protocol).

All together, with the TCP/IP protocol, 500 packets of 188 bytes will be sent to the controllers.

For example, a site with 16 controllers will require:


$$500 \text{ packets} \times 188 \text{ bytes} \times 16 \text{ Controllers} = 500 \times 188 \times 16 = \mathbf{1,504 \text{ Mb to transfer}}$$

*NOTE: Serial communication protocols and TCP/IP are not included in the calculation.*

## Update between Components

Backups or modifications are automatically loaded to the gateway and the controllers. It is possible to evaluate the number of bytes sent to the gateway and the controllers according to the given reload data (see the **Data Reload** tables for **Global Gateways**, and the **Data Reload to Controllers** table).

### Example of Access Level Backup



For an access level backup for 20 doors, calculate 500 bytes per transaction between the workstation and the server, 528 bytes from server to gateway and 60 bytes between the gateway and the controllers.

### Example of Calculations for a Group of 40 Doors:

During a door group backup, calculate 141 bytes for the group and add 8 bytes per door included in that group.

39 bytes per modification query  
 141 bytes per door group  
 8 bytes per door \* 40 = 320 bytes  
 Therefore:  $39 + 141 + 320 = \text{total of 500 bytes}$

**NOTE:** Serial communication protocols and TCP/IP are not included in the calculation.

### Polling Between Gateway and Controllers

During the communication in active mode between gateway and controllers, the gateway queries each controller sequentially with a 4 byte command. Then, if the controller has no message to send, it will transmit a 1 byte presence notification to the gateway. The query sequence is repeated systematically from the first to the last controller.

The following table contains the average value of the bandwidth measured for each of the gateway type with a TCP/IP site:

Bandwidth Gateway / Controller			
Gateway	Default Value	Slowest	Fastest
Corporate	1000 bytes / s	200 bytes / s	7200 bytes / s
Global Gateway	7400 bytes / s	3800 bytes / s	7800 bytes / s

For a Corporate Gateway with 3 TCP/IP sites with default values:

1000 bytes/s x 3 sites = 3000 bytes/s used for querying 3 sites.

Idle Site Query	
Message Type	Number of Bytes
Gateway query	4
Controller reply	1

During the controller query with a TCP/IP site, the packets sent will be at least 54 + 5 bytes for the gateway and 54 + 1 bytes for the controllers. There will be an alternate transmission of 59 bytes and 55 or 60 byte packets for the bandwidth measure for gateway / controllers queries.


***NOTE:** Bandwidth will not increase with the number of controllers connected to the site. In fact, the polling frequency remains the same. The increase is caused by the query delay per controller that increases with the addition of a controller to the site.*

## Controller Events

Controller events are treated directly at the Gateway (See the **Message from the Controller** table.) The gateway sends each event to the main server, in 84 byte packets. The main server will deploy the messages to the workstations. (See the **Data Transmission between Workstation and Server** table, in section 2.)

Example: For an access with a 32 bits card, the information provided will be event date/time, door and the access request that contains the card number.

Packet transmission	= 4 bytes
Date/Time	= 7 bytes
Door	= 1 bytes
Access request	= 5 bytes
<b>Total</b>	<b>= 17 bytes per access</b>



Messages from Controller	
Data Types	Number of bytes
Communication protocol	4
Controller's complete status	63
Date and times	7
System report	4
Report following a command on the network	1
Door Report	1
Inputs in alarm report	1
Shunt inputs report	2
Temporarily shunt inputs report	2
Supervised inputs report	1
Relay activation status	2
Door status	2

Messages from Controller	
Data Types	Number of bytes
Internal/external card number status	4
Output by event activation status	1
Access request results	5 with 32bits card 11 with BCD card
Valid or invalid floor selection results	6 with 32bits card 10 with BCD card
Status on unlocking door in stand-alone mode	2
Status on disabling door in stand-alone mode	1
Status on activating relay in stand-alone mode	2

## Communication between Server and SmartLink

SmartLink is an external application that integrates itself to the EntraPass system allowing users to program and execute command lines that are tailored to their environment.

The structure is composed of two applications: SmartLink and SmartLoop


**SmartLink:** is the direct link with the EntraPass server. It receives instructions attached to an event parameter and sends the commands received by the SmartLoop application to the server.

**SmartLoop:** is the direct link with the program DLL (SmartDll). It receives instructions from SmartLink and then sends back a request to execute a command.

### Interaction between Applications

The query frequency between the server and the SmartLink is the same for all workstations and gateways. (See Section 2.4.2, **Polling between Server and Applications.**)

However, the query frequency between the SmartLink and SmartLoop is much faster. Each application systematically sends an interrogation query every second with a ½ second offset between each of them. This short delay increases the efficiency of response time between the command line transmission and its execution.



Minimum Bandwidth Used with a SmartLink Installation:

Interrogations between the server and SmartLink= 26 bytes / s

Interrogations between SmartLink and SmartLoop = 265 bytes / s

**Total = 291 bytes/s**

---

## Bandwidth Required to Send Command Lines

To calculate the bandwidth used during the execution of a command line, count 1 byte per character used. Example:


<2>"COMMAND=ACTIVATERELAY"<28>"RELAYID=525"<28><3>

50 bytes must be transmitted for the execution of this command line.



# Communication between Main Server and Redundant Server

The mirror database / server application offers resilience to increasing power failures when the EntraPass server shuts down.



## Bandwidth Used by the Mirror Database

Every five seconds, the redundant server replicates the database and the data stored on the main server.

The number of bytes used to replicate the backups and modifications is identical to those used for the main server backups. (See the **Data Backup** table in Section 2.4.1.)

**NOTE:** To obtain the number of transactions and bytes received, see the mirror database **Transaction Report** below. The number on the left indicates the number of transactions and the number on the right indicates the number of bytes sent to the redundant database.

Transactions report	
Transactions to process	0
Nb. of data transactions processed	868 - 2,307,586
Nb. of archive transactions processed	5 - 6,425
Nb. of time and attendance transactions processed	0 - 0
Nb. of Windows registry transactions processed	74 - 2,809
Transaction errors	0

## Bandwidth Used by the Redundant Server

When the application can no longer detect the main server, it starts the redundant server to take charge of the system management. The redundant server is an exact copy of the main server. The bandwidth used for polling, data backup and messages management will be identical to the main server.

## Copy between Mirror Database and Main Server

Once the main server is functional again, the redundant server shuts down and sends the information according to the parameters configured by the operator before the main server power failure.

**Restore database:** Complete copy of mirror database to the main server.

**Restore archived data:** Sends all archived data to the main server.

**Merge archives:** Sends only archived data accumulated since the last redundant server startup.

**Restore time and attendance:** Sends all time and attendance archives.

**Merge time and attendance:** Sends only time and attendance archives accumulated since the last redundant server start up.

**Merge video:** Sends only events related to video recordings accumulated since the last redundant server startup.

## System in Idle Mode

When the communication system is in idle mode, the bandwidth can be calculated as follows:  
For an Entrapass system with 2 workstations, 1 Corporate Gateway and 4 TCIP/IP sites:

Workstation	= 2 x 26 = 52 bytes
Gateway	= 26 bytes/sec.
Sites	= 4 x 1000 = 4000 bytes/sec.
<b>Total</b>	<b>= 4078 bytes/sec for system in idle mode</b>



# Index

## A

### Access Levels

- Additional access levels 266
- Administrator 58
- Arming 199
- Arming access level 202
- Create groups 336
- Disarming 199
- Disarming access level 202
- Schedule 254

### Access levels

- Arming 138
- Bad 136
- Cardholder 133
- Privileged access level (dual custody) 133

### Acknowledging Alarms

- Acknowledge schedule 374
- Alarm sound 470
- Automatic 353
- Set priority 374

### Acknowledging alarms

- Definition and purpose 416
- Using the alarm message box 68

### Additonal system components 24

### Advanced schedule capability 476

### Alarm Message Box 68

### Alarm Sound 470

### Alarm Systems

- Alarm #1 relay state 207
- Alarm #2 relay state 207
- Alarm level #1 input 204
- Alarm level #2 205
- Animated icons 566
- Arming access level 202
- Arming delay state 207
- Arming procedure 251
- Arming reader 203
- Arming reader no unlock 204
- Arming request input 205

### Arming schedule (auto) 201

### Basics

- Arming procedure 199
- Capabilities 198
- Common inputs 198
- Disarming procedure 199
- Disarming when a "no disarm" schedule is valid 200
- Postponed arming procedure 200

### Bell relay 207

### Delays

- Arming delay 202
- Exit delay 202
- Postpone delay 202
- Disarming procedure 251
- Disarming reader 203
- Door disabled when armed 204
- Door to be lock on arming 204
- Entry input 205
- Entry relay 207
- Exit relay state 207
- No disarm schedule 201
- Perimeter and volumetric detection 198
- Postpone count 203
- Postpone procedure 251
- Postpone reader 204
- Postpone relay 207
- Prevent arming input 205
- Shunted on disarming 205
- Status
  - Prevent arming relay state 206
  - System armed 206
  - System disarmed 206
  - System status delay 206
  - Supervised door when armed 204

### Alarms Desktop 411

### Animated Icons

- Alarm systems 566
- Controllers 568
- Doors 570
- Inputs 577
- Others 582
- Site and gateway 579

- Animated icons
  - Relays 574

## Areas

- Activate on opened area 209
- Card position already valid 209
- Disable passback schedule 209
- Normal passback 208
- Number of supervisor inside 210
- Passback type 208
- Supervisor level 209
- Supervisor must be last on exit 210
- Supervisor passback 208
- Supervisor to open area 210
- Transfer schedule 210

- Arming Request 205

- Assign picture from file 270

- Authentication 62

- Auto Acknowledge 353

- Auto-connection 62

## B

- Backup 505

- Backup Scheduler 461

- Badging 2, 257

- Get picture from file 270

- MCI 269

- Paste picture 270

- Video images 269

## Bandwidth

- Between workstation and server 587

- Communication between Main and Redundant server 603

- Communication between server and SmartLink 601

- Communication protocols 586

- Component status query 588

- Controller events 598

- Copy between mirror database and main server 604

## Display

- Events on workstation 587

- Graphics on workstation 587

- Pictures on workstation 587

- Interaction between applications 601

- Manual operations 588

- Mirror database 603

- Modifying data 589

- Polling between gateway and controllers 597

- Redundant server 604

- Reloading

- Data 592

- Firmware to controllers 596

- Saving data 589

- Serial communications 586

- System idle mode 605

- TCP/IP protocols 586

- Update between components 596

- between 596

## Bullet

- Next to a name 101

## Buttons

- Cancel 48

- Enable Animation 49, 224

- Enable Graphic 49, 224

- OK 49

- Select All 224

- Unselect All 49, 224

## C

- Card access group definition 311

- Card format 461

- Card type definition 316

- Card use reports

- Schedule mode 441

## Cards

- Assign a card access group 265

- Assign a picture 269

- Assign access levels to cardholders 265

- Card format 462

- Change format 462

- Copy to visitor card 258

- Create a day pass 317

- Create access level groups 311

- Create card types 316

- Delete when expired 267
- Information #1 to #10 259
- Keep picture on desktop 400
- Last transactions 309
- Modification date 259
- Modifications count 259
- Number 258
- Position already valid (areas) 209
- Print a list of cards 305
- Show cardholder information with picture 66
- Start date 267
- State 268
- Trace 268
- Use count options 269
- User name 258
- Validate Card Access 303
- Wait for keypad 267
- Change card format
  - Decimal 462
  - Hexadecimal 462
  - Octal 462
- Clean Database 517
- Clear alarm messages 66, 68
- Communication timing 102
- Components physical address 359
- Configure system devices 59
- Controller
  - Definition 110
- Controller Events 598
- Controller's Loop baud rate 103, 538
- Controllers 59
  - Animated icons 568
  - Create groups 332
  - Loop RS-232 configuration 90
  - Reset 234
  - Status (graphic view) 345
- Corporate Gateway
  - Configure 86
- CSV files 69
- CSV Import/Export 321
  - Create patterns 322
  - Exporting procedure 323
  - Importing procedure 326

## D

- Database
  - Logical components (view) 389
  - Structure 389
  - Utility Program
    - Swap Descriptions 516
  - Utility program
    - Update database fields 514
    - Verify Database hierarchy 516
    - Verify Database links 515
    - Verify Time and Attendance files 516
- Database Integrity 461
- Database integrity
  - Verify 514
- Database Output Type 434
- Database Status 348
- Day Pass Definition 317
- Define E-mail Parameters 449
- Define E-mail parameters 449
- Desktops
  - Alarms Desktop
    - Acknowledge 414
    - Delete log 414, 424
    - Display graphic screen 421
    - Display instruction screen 419
    - Flag 414
    - Print log 414, 423
    - Purge deleted log 415
  - Historical Reports 407
  - Messages Desktop
    - Auto-rescroll delay 401
    - Background color 401
    - Delete all 402
    - Display events in bold 400
    - Display last message on top 400
    - Display message (in full) 400
    - Display toolbar 400
    - Keep card picture 400
    - Manual properties 400
    - Message type 399
    - Multi-line 400
    - Send to back 403

- Show icons 400
  - View parent 403
- Messages Desktops
  - Play archived video recordings 410
- Network Alarms Desktop 423
- Status bar
  - Server 500
- Diagnostic on Network (Server) 478
- Dial up modem 107
- Dial-up modem 107
- Directory 434
- Disable Door Reader 240, 244
- Disable video 63
- Display
  - Event on workstation 587
  - Picture 587
- Door
  - Return to schedule 238, 241, 245
- Door contact 129
- Door Group 333
- Doors 59
  - Animated icons 570
  - Create groups 333
  - Disabled when armed 204
  - Door contact 129
  - Door unlock (guard tours) 213
  - Door unlock reading 129
  - Doors to be locked when armed 204
  - Elevator cab 127
  - Lock mode 126
  - Open time 127
  - Pre-alarm on door opened too long 129
  - Re-lock on door closing 130
  - Re-lock on door opening 130
  - REX contact 130
  - Supervised door when armed 204
  - Time and Attendance 127
  - Unlock on REX 130
  - Unlock time 127

## E

Editing system components 26

- Elevator Control
  - Create floor groups 337
  - Create floors 214
  - Elevator cab (door) 127
- Elevator control
  - REB-8s 115
  - Select cab for floor group activation 146
  - Unlock schedules (elevator floors) 132
- Elevator controllers 114
- e-mail
  - Options 69
- Enable Door Reader 240, 244
- Enable/Disable Card Readers 238
- Enable/Disable card readers 238, 241
- Encryption 62
- EntraPass Bandwidth 585
- Entry Delay 202
- Ethernet Kantech IP Link 103
- Ethernet polling 106
- Event buffer
  - Controller 109
- Events
  - Acknowledge schedule 374
  - Associate a relay to an event 215
  - Color 373
  - Deleting and restoring associations 376
  - Display (schedule) 373
  - Instructions (assign to events) 374
  - Parameter definition 372
  - Print parameters 378
  - Print schedule 373
  - Set priority 374
  - Viewing associations 374
- Expired 268
- Exported Video 190

## F

- Fail-Soft 388, 400
- Filtered Messages Desktop 406
- Floor
  - Confirmation 118
  - Definition 214



Group 337

## G

### Gateway

- Animated icons 579
- Hard reset 228
- Message filter 64
- Soft reset 228

### Gateway data reload 228

### Global Gateway

- Configure 92

### Global gateway

- External configuration 30

### Graphic Status (controller view) 345

### Graphics

- See also Animated Icons 565

### Groups

- Access levels 336
- Controllers 332
- Doors 333
- Floors 337
- Inputs 335
- Relays 334

### Guard Tours

- Definition 211
- Delay settings 212
- Door unlock 213
- Door/Input 213
- End Guard Tour 253
- End guard tour 252
- Modify delay to next station 253
- Modify next station 253
- Pre-alarm delay 212
- Start Guard Tour 253
- Start guard tour 252

## H

### Hardware

- Definition 101

### Historical Reports

Automatic filename 445

Automatic report schedule screen 440

Desktop 407

Destination 445

Filter mode 436

Output process 443

Output type 442

Preview 459

Report language 445

Schedule mode 441

Selected components 437

State 408

Historical reports 435

Holiday definition 222

Host modem definition 87

## I

Icons, see Animated Icons 565

Import/Export 321

Information #1 to #10 259

### Inputs

- Alarm level #1 204
- Alarm level #2 input 205
- Animated icons 577
- Arming request input 205
- Continuous supervision 248
- Create groups 335
- Entry input 205
- Group 335
- Monitoring schedule 144
- Normal 248
- Normal condition 144
- Prevent arming input 205
- Shunted on disarming 205

Installation 7

Installing the system 12

### Instructions

- Assign to events 374
- Definition 379

Interlock options 131

## K

- Kantech IP Link 103
- Keypad Escape key 113
- Keypad Family 466
- KT Controllers 110
- KT-100 112
- KT-100 controller 112
- KT-200
  - Expansion devices 114
- KT-2252 elevator controllers 114
  - Program 115
- KT-300 112
- KT-NCC 85
  - Configuring 94
  - Configuring KT-100 112
  - Configuring KT-300 119
  - Defining a door 133
- KT-NCC Gateway 94

## L

- Language (operator) 353
- Lock/Unlock
  - Door 238
  - Door temporarily 238
  - Elevator door 241
  - Elevator door temporarily 241
- Login
  - Name 353
  - Schedule 354
- Logout on idle 62

## M

- Mantrap 131
- Manual Operations
  - Alarms 250
  - Areas 254
  - Disable reader 238, 241
  - Enable readers 238, 241
  - Guard tour 252

- Lock door 238
- Lock elevator door 241
- Temporarily lock door 238, 241
- Temporarily unlock door 238, 241
- Unlock doors 238, 241
- Master Password 461, 464
  - New 464
  - Verify 464
- Message mode 79
- Messages Definition (Filters) 385
- Messages Desktop 398
- Modem dial-up 107
- Multimedia Devices 461, 470
  - Alarm sound 470
  - Signature capture 472
  - Video options 471

## N

- NCC 8000 Gateway
  - Configuring 89
  - View program 90
- Network Alarms Desktop 423
- Normal condition 144

## O

- Online help 4
- Operator definition 352
- operator name 352
- Operators
  - Allow login on server 358
  - Bypass workstation message filter 353
  - Definition 352
  - Language selection 353
  - Login name 353
  - Login Restrictions 358
  - Operator login schedule 354
  - Password 353
- Output definition 149
- Output filename 434
- Outputs

- Activation period 150
- Associating door events to auxiliary outputs 150
- Flash 150
- Flash timed 150
- Operating mode 149
- Steady 150
- Steady timed 150

## P

- Passback
  - Option 268
- Passback type 208
- Password
  - Change master password 464
  - Operator 353
- Pending 268
- Picture 270
- PIN number 113, 267
- PING Diagnostic Program 545
- Port number 538
- Power supervision schedule 112
- Print a log 414, 423
- Print cards 305
- Print Event Parameters 378
- Printer, see Log printer 467

## R

- Readers
  - Arming reader 203
  - Arming reader no unlock 204
  - Disarming reader 203
  - Postpone reader 204
- REB-8 Elevator controllers
  - Program 117
- REB-8 relay expansion board modules 114
- Redundancy server address 76
- Register the system 22
- Registration
  - see Workstation Registration 496
- Relay

- Activate 245
- Deactivate 245
- Temporarily activate 245
- Relay Group 334
- Relays 59
  - Activate on entry delay 207
  - Activate on exit delay 207
  - Activate on postpone 207
  - Activation schedule 141
  - Animated icons 574
  - Create groups 334
  - Operation mode 141
  - Prevent arming state 206
  - System armed 206
  - System disarmed 206
  - Temporary activation timer 142
- Remote modem delay 109
- Reset, see Controllers 234
- REX 113
- REX (Request to EXit) 130
- REX contact 130
- REX options 130
- rpf files 69
- RS-232 Gateway Configuration 90
- RS-232 serial port 102, 538

## S

- Schedule definition 194
- Schedules
  - Acknowledge schedule 374
  - Arming schedule 201
  - Days 195
  - Disable passback schedule 209
  - End time 195
  - Login schedule (operators) 354
  - Monitoring schedule (inputs) 144
  - No disarm schedule 201
  - Printing events 373
  - REX schedule 130
  - Start time 195
  - Transfer schedule 210
  - Unlock schedule # 1 (elevator doors) 132

- Security Level
  - Assign to operator 354
  - Read only - (View components) 358
- Security level definition 356
  - Administrator 352
  - Installer 352
  - Restricted 352
- Security parameters 62
- Server
  - Database Utility Program, see Database 512
  - Getting Started 500
  - Login 501
  - Modify the font 510
- Server's IP Address 538
- Shunt delay 146
- Signature capture 472
- Site
  - Retrieving site events 108
- SmartLink 79
  - Create instructions 380
- Sound Notification 470
- Start a session 38
- Startup (see SmarLink) 79
- State (cards), see Cards 268
- Status icon
  - Refresh delay 66
- Supervisor inside (areas) 210
- Supervisor level (areas) 209
- Supervisor must be last on exit 210
- Supervisor to open area 209
- Suspend messages 63
- Swap descriptions 516
- System components 26
- System data 505
- System Date & Time 469
- System idle mode 605
- System Log
  - View 503
- System Parameters 474
- System parameters 461

## T

- TCP/IP protocols 586
- TCP-IP 106, 538
- Technical Support 4
- Terminal server 106
- Time & Attendance Reports
  - Add transactions 455
  - Automatic Report output definition 453
  - Preview 460
  - Select doors 450
  - Use specific card range 451
- Time and Attendance 126
- Trace
  - Option 268

## U

- UDP 106
- Unidirectional mode 79
- Unlock schedules (elevator floors) 132
- Upgrading the system 31
- Usage restriction 269
- User Datagram Protocol (UDP) 106
- User parameters 66, 68
- Users 257

## V

- Validate Card Access 303
- Video 471
- Video Integration 151
- Video server options 487
- Video Vault
  - Configuring EntraPass Video Vault 80
  - File format 82
- View Last Transactions 309
- Visitor definition 315
- Visual feedback
  - see Reader 110

# W

What is access control? 1

Window

- Description 63

Workstation

- Automatic logout on idle 62

- Filters 63

- Suspend messages 63

Workstation registration 496



# ***KANTECH***

---

© 2006 Tyco Safety Products, Canada, Ltd.

Tel.: +1 (450) 444-2030 • Toll Free: +1 888 222-1560 • Fax: +1 (450) 444-2029

Internet: [www.kantech.com](http://www.kantech.com) • E-mail: [kantechsupport@tycoint.com](mailto:kantechsupport@tycoint.com)

DN1613-0612

---

